BWE 8015-Anti

BWE Antique Brass Shower System User Manual

Model: 8015-Anti

1. Product Overview

The BWE Antique Brass Shower System Model 8015-Anti is a wall-mounted bath system featuring an 8-inch rain shower head and a handheld spray. Designed with a two-function water diverter and two cross handles for hot and cold water control, this system offers both functionality and a classic aesthetic. Constructed from solid brass with a premium antique brass finish, it is built to resist corrosion and rust in humid environments. The shower height is adjustable, and all connections include rubber gaskets to prevent leaks.

2. Package Contents

Please verify that all components are present before beginning installation:

- 8-inch Rainfall Shower Head
- Handheld Shower
- Shower Faucet Body
- Brass Diverter
- Shower Hose
- Hand Sprayer Holder
- Installation Hardware (screws, anchors, gaskets)
- Installation Manual



Figure 2.1: All components included in the package.

3. Setup and Installation

This section provides general installation guidelines. For detailed visual instructions, please refer to the installation video below. Professional installation is recommended.

3.1 Pre-Installation Steps

1. Ensure water supply is turned off at the main valve.
2. Clear the installation area of any debris or existing fixtures.
3. Verify all package contents are present and undamaged.

3.2 Installation Video Guide

Your browser does not support the video tag.

Video 3.1: Step-by-step installation guide for the BWE Bathroom Shower Fixtures.

3.3 Key Installation Steps (Summary from video)

1. **Prepare Wall Connections:** Install the eccentric adapters into the wall's hot and cold water outlets. Ensure they are securely tightened and sealed with plumber's tape.
2. **Install Faucet Body:** Attach the main faucet body to the eccentric adapters. Use a cloth to protect the finish while tightening with a wrench.
3. **Attach Diverter and Vertical Pipe:** Screw the brass diverter onto the top outlet of the faucet body. Then, connect the vertical shower pipe to the diverter.
4. **Secure Wall Mount:** Mark and drill holes for the upper wall mount bracket. Insert anchors and secure the bracket to the wall.
5. **Connect Shower Head:** Attach the 8-inch rain shower head to the top of the vertical pipe.
6. **Connect Handheld Shower:** Attach the shower hose to the side outlet of the faucet body and the handheld shower head. Place the handheld shower in its adjustable holder on the vertical pipe.

4. Operating Instructions

4.1 Water Flow Control

The shower system features two cross handles for controlling water temperature and flow:

- The handle marked 'H' controls hot water.
- The handle marked 'C' controls cold water.

Turn the handles to adjust the desired water temperature and flow intensity.




Figure 4.1: Hot and cold water control handles and function selection.

4.2 Function Diverter

The system includes a 2-way water diverter to switch between the rainfall shower head and the handheld shower. Rotate the diverter knob to select your preferred water outlet.

4.3 Adjustable Shower Height

The shower height can be adjusted between 38.97 inches (99 cm) and 53.1 inches (135 cm). To adjust, simply unscrew the knob on the vertical pipe, slide the pipe to the desired height, and then re-tighten the knob. The handheld bracket can also be adjusted independently along the vertical pipe.



Figure 4.2: Adjusting the shower height.



Figure 4.3: Handheld shower sprayer and adjustable bracket.

4.4 Rain Shower Head

The 8-inch rain shower head provides a strong and stable water flow. The angle of the shower head can be rotated 360 degrees for optimal coverage.



Figure 4.4: 8-inch rain shower head features.

5. Maintenance

Proper maintenance will ensure the longevity and performance of your BWE shower system.

5.1 Cleaning the Finish

To maintain the antique brass finish, clean regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish. Mild soap and water can be used for tougher spots, followed by rinsing and drying.

5.2 Shower Head Maintenance

The rain shower head includes a filter to prevent clogging. Periodically check and clean the filter as needed to ensure optimal water flow. The silicone nozzles on the shower head can be gently rubbed to dislodge mineral deposits.

5.3 Leak Prevention

All connections are equipped with rubber gaskets to prevent water leakage. If you notice any leaks, first ensure all connections are securely tightened. If leaks persist, check the condition of the rubber gaskets and replace if necessary.

6. Troubleshooting

This section addresses common issues you might encounter with your shower system.

6.1 Low Water Pressure

- **Check Water Supply:** Ensure the main water supply valve is fully open.
- **Clean Shower Head:** Mineral deposits can reduce water flow. Clean the nozzles of the rain shower head and check the internal filter for blockages.
- **Inspect Hose:** Ensure the handheld shower hose is not kinked or obstructed.

6.2 Leaks from Connections

- **Tighten Connections:** Gently tighten all visible connections, especially where the faucet body meets the wall and where the hose connects. Do not overtighten.
- **Check Gaskets:** Ensure all rubber gaskets are properly seated and not damaged. Replace any worn or damaged gaskets.
- **Plumber's Tape:** For threaded connections, ensure sufficient plumber's tape was applied during installation.

6.3 Difficulty Adjusting Shower Height

- **Loosen Knob:** Ensure the height adjustment knob on the vertical pipe is sufficiently loosened before attempting to slide the pipe.
- **Lubrication:** If the pipe is stiff, a small amount of silicone grease can be applied to the sliding surfaces (ensure it is safe for plumbing materials).

7. Specifications

Feature	Detail
Brand	BWE
Model Number	8015-Anti
Color	Antique Brass
Material	Brass
Finish Type	Antique
Number of Handles	2
Mounting Type	Wall Mount
Head Size	8 inches
Item Weight	4.06 Kilograms
Adjustable Shower Height	38.97 inch - 53.1 inch (99 cm - 135 cm)




Figure 7.1: Product dimensions.

8. Warranty and Support

BWE is committed to providing quality products and customer satisfaction. If you encounter any problems with your product or during installation, please contact us through Amazon or via e-mail. We aim to respond within 24 hours to assist you with your concerns.

Please retain your proof of purchase for any warranty claims or support inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question