

XINDADA SK4 Pro

SK4 Pro MAX Men Luxury Smart Watch User Manual

Model: SK4 Pro | Brand: XINDADA

1. INTRODUCTION

Welcome to the user manual for your new SK4 Pro MAX Smart Watch. This guide provides essential information on how to set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your smartwatch.

2. PRODUCT OVERVIEW

The SK4 Pro MAX is a luxury smartwatch designed for men, featuring a 1.6-inch HD large screen, AI voice capabilities, and Bluetooth call functionality. It is equipped with advanced sensors for comprehensive health and fitness tracking.


Key Features:

- 1.62-inch HD TFT Touch Screen (466*466 resolution)
- Bluetooth 5.2 for stable connectivity and calls
- Heart Rate Monitor, Sleep Monitor, Blood Pressure Monitor
- Steps Tracker, Calorie Tracker, Activity Tracker
- AI Voice Assistant (built-in)
- Durable ALLOY case and Fine Steel band (detachable)
- 220-300mAh Battery Capacity
- Life Waterproof grade

Components:



The SK4 Pro MAX Smart Watch, showcasing its elegant design and digital display with fitness metrics.



Double the texture with black and gold
All show extraordinary bearing

Detailed view emphasizing the premium black and gold finish of the watch casing and strap.



Beyond the horizon touch the future
1.62 inch, 466*466PX

The 1.62-inch HD screen, providing a clear and vibrant display with 466x466 pixel resolution.

**High capacity
strong endurance**

300mAh



Illustration of the watch's internal components, highlighting its high-capacity 300mAh battery for extended endurance.

**Silicone strap to help you
on your athletic journey**

**The perfect combination of
sports and fashion**



The smartwatch with a silicone strap, ideal for athletic activities, displaying various fitness metrics.



A lifestyle image of the SK4 Pro MAX Smart Watch, showcasing its robust and stylish design in an outdoor setting.

3. SETUP GUIDE

3.1 Initial Charging

1. Connect the magnetic charging cable to the charging points on the back of the watch.
2. Plug the USB end of the cable into a standard USB power adapter (5V/1A recommended) or a computer USB port.
3. Charge the watch fully before first use. A full charge typically takes 2-3 hours. The battery icon on the screen will indicate charging status.

3.2 App Installation and Pairing

1. Scan the QR code provided in the watch packaging or search for the companion app (e.g., 'WearFit Pro' or similar, check packaging for exact name) on your smartphone's app store (App Store for iOS, Google Play Store for Android).
2. Download and install the app.
3. Ensure Bluetooth is enabled on your smartphone.
4. Open the app and follow the on-screen instructions to create an account or log in.
5. In the app, navigate to 'Device' or 'Add Device' and select your SK4 Pro MAX Smart Watch from the list of discoverable devices.
6. Confirm the pairing request on both your watch and smartphone.

3.3 Basic Settings

- **Time and Date:** Once paired with your smartphone, the watch will automatically synchronize time and date.
- **Personal Information:** Enter your personal details (age, height, weight, gender) in the app for accurate fitness tracking.
- **Notifications:** Enable desired app notifications (calls, messages, social media) through the companion app.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Interface

- **Touch Screen:** Swipe left/right, up/down to navigate through menus and functions. Tap to select.
- **Side Buttons:** Use the physical buttons on the side for power on/off, returning to the home screen, or quick access to specific functions (refer to watch settings for customization).

4.2 Bluetooth Call Function

1. Ensure your watch is connected to your smartphone via Bluetooth.
2. To make a call: Access the dial pad on the watch or select a contact from your synchronized phonebook.
3. To answer a call: When an incoming call rings, tap the 'Answer' icon on the watch screen.

4.3 Health Monitoring

- **Heart Rate:** Access the heart rate monitor function on the watch. Ensure the watch is snug on your wrist for accurate readings.
- **Blood Pressure:** Follow the on-screen instructions for blood pressure measurement. Note: This is for reference only and not for medical diagnosis.
- **Sleep Monitor:** Wear the watch to bed. It will automatically track your sleep patterns (deep sleep, light sleep, awake time). View detailed reports in the app.

4.4 Activity Tracking

- **Steps & Calories:** The watch automatically tracks your daily steps, distance, and calories burned.
- **Sport Modes:** Select from various sport modes (e.g., running, cycling) to track specific workout data.

4.5 AI Voice Assistant

- Activate the AI voice assistant by tapping its icon or using a designated gesture/button (refer to watch settings).
- Speak your commands clearly to perform tasks like setting alarms, checking weather, or initiating calls.

5. MAINTENANCE

5.1 Cleaning

- Wipe the watch screen and body with a soft, lint-free cloth.
- For stubborn stains, dampen the cloth slightly with water. Do not use harsh chemicals or abrasive materials.
- Clean the charging contacts regularly to ensure good connection.

5.2 Water Resistance

The SK4 Pro MAX Smart Watch has a 'Life Waterproof' grade. This means it is resistant to splashes, rain, and brief immersion in shallow water. It is not suitable for swimming, diving, or high-pressure water activities. Avoid exposing the watch to hot water or steam.

5.3 Battery Care

- Avoid completely draining the battery frequently.
- Charge the watch regularly, even if not in use, to maintain battery health.
- Store the watch in a cool, dry place when not in use for extended periods.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not turning on	Low battery; Power button not pressed long enough	Charge the watch for at least 30 minutes; Press and hold the power button for 3-5 seconds.
Unable to pair with phone	Bluetooth off; App not open; Watch not discoverable; Interference	Ensure phone Bluetooth is on; Open the companion app; Restart watch and phone; Move closer to phone.
Inaccurate health data	Watch too loose/tight; Sensor dirty; Incorrect personal info in app	Adjust watch fit; Clean sensor; Update personal data in app.
Notifications not received	App permissions not granted; Notifications disabled in app/phone settings	Check app permissions for notifications; Enable notifications in the companion app and phone settings.
Bluetooth call issues	Watch too far from phone; Bluetooth connection unstable	Keep watch within Bluetooth range of phone; Reconnect Bluetooth.

7. SPECIFICATIONS

Feature	Detail
Model Number	SK4 Pro
Display Size	1.62 inches
Resolution	466*466 PX
Screen Material	TFT
Touch Screen	YES
Bluetooth Version	5.2
CPU Model	RTL8763EWE

Feature	Detail
Battery Capacity	220-300mAh (Lithium Polymer)
Waterproof Grade	Life Waterproof
Case Material	ALLOY
Band Material	Fine Steel (Detachable)
Compatibility	Android OS, iOS
Metrics Measured	Heart Rate, Sleep, Blood Pressure
Activity Tracked	Steps, Calories, General Activity
Special Features	AI Voice Assistant, Bluetooth Call, Notifications

8. WARRANTY AND SUPPORT

Your SK4 Pro MAX Smart Watch is covered by a standard manufacturer’s warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact the seller or manufacturer directly through the platform where you purchased the product. Keep your purchase receipt or order number handy as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D6R7ZW87>

More documents and user manuals: <https://manuals.plus/>