

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RBROHANT](#) /

› [RBROHANT Polished Chrome Exposed Shower System with Tub Spout Instruction Manual](#)

RBROHANT RWSTT81005

RBROHANT Polished Chrome Exposed Shower System with Tub Spout Instruction Manual

Model: RWSTT81005

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your RBROHANT Polished Chrome Exposed Shower System with Tub Spout. Please read these instructions carefully before installation and use to ensure proper function and longevity of the product.

PRODUCT OVERVIEW AND FEATURES

The RBROHANT Polished Chrome Exposed Shower System is designed to provide a versatile and comfortable showering experience. Key features include:

- **10-inch Thickened High-Pressure Shower Head:** Utilizes Air-in technology to mix water with air, delivering a full-body, high-pressure bubble water shower while conserving water by at least 30%.
- **Length Adjustable Shower Pipe:** The exposed shower pipe (slide bar) can be adjusted from 85cm to 120cm (33 1/2 inches to 47 1/4 inches) to accommodate various user heights, ensuring a suitable rain shower experience for everyone.
- **Angle Adjustable Tub Spout:** Features a high water flow tub spout with a NEOPERL aerator for quick and quiet bathtub filling, minimizing noise and splash. The adjustable angle provides flexibility for different filling needs.
- **Solid Brass 3-Functional Shower Valve:** This multi-function valve allows selection between the overhead rain shower head, a handheld sprayer with a 59-inch hose (ideal for washing or showering without wetting hair), and the tub spout for filling a bathtub.
- **CEC & cUPC Certification:** Ensures safety and durability, with each shower system checked and tested before packaging.
- **Material Composition:** The 10-inch rain shower head, shower pipe, and 59-inch shower hose are made of 304SUS stainless steel. The shower valve, trim kit, and handheld are brass, while the handheld holder is ABS and handles are zinc alloy.
- **Easy Installation and Maintenance:** Designed for standard US 1/2" NPT connection and wall-mounted installation. A detailed guide and necessary tools are included. The exposed structure simplifies maintenance.





Image: The complete RBROHANT Polished Chrome Exposed Shower System, showcasing the rain shower head, adjustable shower pipe, handheld sprayer, and main valve with tub spout.

SPECIFICATIONS

Feature	Detail
Brand	RBROHANT
Color	Polished Chrome
Material	Brass, Stainless Steel
Finish Type	Polished
Number of Handles	1
Handle Material	Metal
Item Weight	5.78 Kilograms (12.72 pounds)
Mounting Type	Wall Mount
Included Components	10 Inch Square Stainless Steel Rain Shower Head, 3-Functional Brass Valve and Handle Trim Kit, 304SUS Stainless Steel Shower Arm, Brass Handheld and Holder, and SUS304 59-Inch Hose, Height Adjustable Exposed Shower Pipe
Head Size	10 inches
Product Dimensions	35.8 x 16.9 x 4.1 inches
Item Model Number	RWSTT81005
Certifications	CEC, cUPC



Image: Detailed dimensions of the RBROHANT shower system, showing adjustable height and various component measurements.

INSTALLATION INSTRUCTIONS

This section provides a general guide for installing the RBROHANT Exposed Shower System. For detailed visual instructions, please refer to the installation video below and the included installation guide.

- 1. Prepare the Wall Connections:** Ensure your wall has standard US 1/2" NPT connections for hot and cold water at the appropriate distance for the main valve.
- 2. Assemble Offset Connectors:** Screw the offset connectors into the decorative covers, then insert the rubber rings into the main body, and finally screw the offset connectors into the main body.
- 3. Mount the Main Body:** Fix the main body of the shower system to the wall, ensuring a secure connection to the water inlets.
- 4. Install Switch Handle:** Attach the switch handle to the main valve and tighten it using a hexagon key.
- 5. Attach Shower Rod:** Install the top spray shower rod onto the main body and secure it with the provided fixing seat.
- 6. Connect Shower Heads:** Install the top spray (rain shower) head and the handheld shower separately. Ensure all

connections are tight to prevent leaks.

7. **Test for Leaks:** After installation, slowly turn on the water supply and check all connections for any leaks.

Your browser does not support the video tag.

Video: Official RBROHANT installation tutorial for the exposed shower system. This video demonstrates the step-by-step process of assembling and mounting the shower system components to the wall, including connecting water lines and attaching the shower heads.



Image: Diagram illustrating the adjustable height feature of the shower pipe and handheld shower, showing minimum and maximum height settings.




Image: Close-up of the 3-functional valve, highlighting the tub spout, handheld shower, and rain shower options, along with hot and cold water indicators.

OPERATING INSTRUCTIONS

Your RBROHANT shower system offers three distinct water outlets for a customized experience:

- **Temperature Control:** Use the main handle on the valve to adjust the water temperature. Move it left for hotter water and right for colder water.
- **Function Selection:** The central knob on the valve allows you to switch between the three functions:
 - Turn to activate the **Tub Spout** for filling the bathtub.
 - Turn to activate the **Handheld Shower** for targeted washing.
 - Turn to activate the **Rain Shower Head** for a full-body shower experience.
- **Adjusting Shower Head Height:** The rain shower head's height can be adjusted by loosening the fixing screw on the slide bar, moving the shower arm up or down, and then re-tightening.

- **Adjusting Handheld Shower Height:** The handheld shower holder can be slid up or down the main pipe to adjust its height. Press and hold the button on the holder to slide it, then release to lock.
- **Adjusting Shower Head Angle:** The rain shower head features a 360-degree rotatable ball joint, allowing you to adjust its angle for optimal water coverage.
- **Tub Spout Angle Adjustment:** The tub spout's angle can be adjusted to suit different filling requirements.



Adjustable Tub Spout Flow Angle



High-end aerator makes the flow more gentle and quiet.



More flexible angle to different filling needs.
Larger water flow, fills up your tub more quickly.







Image: Illustration demonstrating the adjustable flow angle of the tub spout and the NEOPERL aerator for gentle, quiet water flow.

RBROHANT®

10 Inch High Pressure Rain Shower Head



Made from long lasting SUS304 stainless steel, adopts air-in technology, higher pressure and less water.

Soft silicon nozzles, easy to clean, just rub it with your finger to remove the scale.

Image: Close-up of the 10-inch rain shower head, showing the Air-in technology for high-pressure water flow and soft silicone nozzles for easy cleaning.

MAINTENANCE

Regular maintenance will help preserve the finish and functionality of your RBROHANT shower system.

- Cleaning the Finish:** Clean the polished chrome finish with a soft, damp cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- Cleaning Shower Head Nozzles:** The rain shower head features soft silicone nozzles. To remove mineral buildup or scale, simply rub the nozzles with your finger. For more stubborn deposits, a mixture of white vinegar and water can be used.
- Hose Maintenance:** Periodically check the shower hose for kinks or damage. Clean the hose with a soft cloth.
- General Inspection:** Regularly inspect all connections for any signs of leaks or wear. Tighten any loose connections as needed.

TROUBLESHOOTING

If you encounter issues with your shower system, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Low Water Pressure	Clogged shower head nozzles; partially closed shut-off valve; mineral buildup in pipes.	Clean shower head nozzles by rubbing them. Ensure shut-off valves are fully open. Consider professional plumbing inspection if problem persists.
Leaks at Connections	Loose connections; worn out washers/gaskets; improper thread sealant.	Tighten connections. Replace worn washers/gaskets. Reapply thread sealant if necessary.
Water Temperature Issues	Improper adjustment of hot/cold supply; water heater issues.	Adjust the main handle for desired temperature. Check water heater settings.
Difficulty Switching Functions	Mineral buildup in the diverter valve.	Flush the system by running water through all functions. If persistent, contact customer support.

WARRANTY AND SUPPORT

RBROHANT offers a lifetime warranty for all its bathroom shower fixtures. If you encounter any problems with this exposed shower faucet set, please contact RBROHANT customer service. They commit to replying within 12 hours and will resend free new replacement parts if necessary.




Image: Graphic detailing RBROHANT's customer-oriented services, including lifetime warranty, free replacement parts, parts customization, and a 12-hour response time for inquiries.

For further assistance, please refer to the contact information provided with your product packaging or visit the official RBROHANT website.



Related Documents - RWSTT81005

 User's Manual www.rb Rohant.com	<p>RBROHANT RB0746 Bathtub Faucet Installation and User Manual</p> <p>Comprehensive installation guide and user manual for the RBROHANT RB0746 matte black bathtub faucet with handheld shower. Includes parts list, installation steps, cleaning instructions, and technical specifications.</p>
	<p>RBROHANT RB0746 Matte Black Roman Tub Faucet with Handshower User Manual and Installation Guide</p> <p>Detailed user manual and installation guide for the RBROHANT RB0746 matte black Roman tub faucet with handshower. Includes troubleshooting, lifetime warranty information, and product specifications.</p>
 User's Manual www.rb Rohant.com	<p>RBROHANT Arletto RB0945 Shower System Installation Manual</p> <p>Installation and user guide for the RBROHANT Arletto RB0945 shower system. Includes parts list, step-by-step installation instructions, dimensions, and cleaning recommendations.</p>
 User's Manual www.jiaotianfeng.com	<p>RBROHANT Bathroom Accessories User Manual and Installation Guide</p> <p>Comprehensive user manual and installation guide for RBROHANT bathroom accessories, including installation steps, cleaning care instructions, and product specifications. Features model RB0859 and IAPMO certifications.</p>
 User's Manual	<p>RBROHANT RB1184 Kitchen Faucet Installation Manual</p> <p>Detailed installation manual and user guide for the RBROHANT RB1184 kitchen faucet, covering setup, dimensions, and maintenance. Features step-by-step instructions and care tips.</p>
	<p>RBROHANT JK0145 Shower Mixer Technical Specifications</p> <p>Detailed technical specifications for the RBROHANT JK0145 shower mixer, including dimensions, connection types (NPT, G3/4), and control functions for hot and cold water.</p>