



[Manuals.plus](#) /

> [SIMPLUS](#) /

> SIMPLUS 20 Oz Portable Personal Blender Instruction Manual

## SIMPLUS LLJH004GY00-US

# SIMPLUS 20 Oz Portable Personal Blender Instruction Manual

Model: LLJH004GY00-US

### PRODUCT OVERVIEW

---

Thank you for choosing the SIMPLUS 20 Oz Portable Personal Blender. This compact and powerful appliance is designed for quick and easy preparation of smoothies, shakes, baby food, and more. Its user-friendly design and efficient blending capabilities make it an ideal addition to any kitchen.

## Ultra-Fast Blender

### 8-Second Smoothness!

High quality motor upgraded blades

Over-heat Protection

4-Edge Blade

BPA Free

Premium Quality

Image: The SIMPLUS 20 Oz Personal Blender, showcasing its compact design and versatility with various ingredients.

### IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender.
- Blades are sharp. Handle with care.
- Ensure the blender is unplugged when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always operate the blender with the lid in place.

- Do not blend hot liquids as this may cause pressure buildup and result in scalding.

## PRODUCT COMPONENTS

Your SIMPLUS Personal Blender comes with the following components:

- Motor Body (Power Base)
- 20oz High Cup (BPA-Free ABS body)
- 4 Stainless Steel Blades (integrated into the base of the cup)
- Seal Cover/Lid



Image: An exploded view of the SIMPLUS Personal Blender showing the power base, 20oz high cup, and the 4-leaf cross blade assembly.



Voltage:  
**110-130V**

Net weight:  
**1kg**

Power:  
**250W**

In the box:



Image: The blender with key dimensions (11.2"H x 4.1"D x 4.1"W) and a list of items included in the box: motor body, cup with blade, lid, and manual.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Wash:** Before first use, wash the 20oz high cup, lid, and blade assembly with warm, soapy water. Rinse thoroughly and dry. The motor body should only be wiped clean with a damp cloth.
3. **Assemble Blade:** Ensure the 4 stainless steel blades are securely attached to the base of the high cup.
4. **Place on Base:** Place the assembled cup onto the motor body. Ensure it is properly aligned and locked into place for safe operation. The blender features a safety lock mechanism; it will only function when the cup is correctly secured.
5. **Connect Power:** Plug the power cord into a standard 120V AC outlet.

## OPERATING INSTRUCTIONS

The SIMPLUS Personal Blender features a convenient one-touch operation for easy blending.

1. **Add Ingredients:** Place your desired ingredients into the 20oz high cup. Do not fill it too full to avoid spills. For best results with frozen fruits or ice, ensure there is sufficient liquid to cover the blades.
2. **Secure Lid:** Place the lid firmly onto the cup.
3. **Attach to Base:** Twist the cup onto the power base until it locks securely in place. The blender will not operate if the cup is not correctly locked.
4. **Blend:** Press the single button on the front of the motor body to start blending. For optimal results and to prevent motor strain, use short bursts, especially when blending harder ingredients like ice or frozen fruit. Do not continuously press for more than 1 minute.
5. **Add During Blending:** If you need to add ingredients while blending, carefully remove the small center cap from the lid and add items through the opening. Replace the cap immediately.
6. **Stop Blending:** Release the button to stop the blending process.



Image: Visual guide showing the four simple steps to blend: add ingredients, secure lid, blend in short bursts, and clean.

### Blending Capabilities:

- **Smoothies & Shakes:** Ideal for fruits, vegetables, protein powders, and liquids.
- **Baby Food:** Create smooth purees from cooked ingredients.
- **Ice Crushing:** The 4 durable stainless steel blades can handle ice cubes for refreshing drinks.



Baby Food



Juice



Ice and frozen fruit



Puree



Smoothie



Shake



Dressing

## Powerful & Multi-Mode Blending



Image: The blender demonstrating its multi-mode blending capabilities for various food items.

## MAINTENANCE AND CLEANING

Keeping your SIMPLUS Personal Blender clean is effortless.

1. **Immediate Rinse:** After each use, detach the cup from the motor base. Rinse the jar, blades, and lid with clean water to remove food residues.
2. **Self-Cleaning Function:** For a quick clean, add warm water and a drop of dish soap to the cup. Secure the lid and attach it to the motor base. Press the blend button for a few seconds to activate the self-cleaning process. Rinse thoroughly afterward.
3. **Hand Wash:** The jar, blades, and lid can be washed by hand with warm, soapy water. Use a brush to safely clean around the blades.
4. **Motor Body:** Wipe the motor body with a damp cloth. Never immerse the motor body in water or any other liquid.
5. **Storage:** Store the blender in a dry place. Its slim design allows for easy storage in small spaces.

# Easy To Clean



## Rinse

Use water to flush away food residues



## Dishwasher

DO NOT put base and blade in dishwasher



## Self-Cleaning

Add water and press start for self-cleaning process

Image: A visual guide to cleaning the blender, showing rinsing the jar, dishwasher compatibility for the cup and lid (but not the base), and the self-cleaning method.

## TROUBLESHOOTING

Here are some common questions and solutions for your blender:

### Q1: What if the blender doesn't work?

1. Check whether the side buckle between the cup body and the machine is in place; otherwise, it will not work.
2. When the plug is removed from the stripping board, make sure that it is fully inserted and does not shake.

### Q2: What if the blade doesn't stir?

1. The cooking mechanism for fruit and vegetable juice needs to add water, generally about 150mL, and ingredients cannot be directly put into the food ingredients without liquid.
2. Ingredients need to be cut into small pieces (1-1.5cm in size); large ingredients do not work.

### Q3: Can I keep pushing the button?

It is best not to. The machine power is low, the switch needs to be clicked, and continuous pressing cannot exceed 1 minute.

### Q4: Can the blender be disassembled and cleaned?

You cannot remove the mixing blade. It can only be washed with water; otherwise, it is not easy to reinstall, which may cause the machine to not work.

## Q1: What if the juicer doesn't work?

1. Check whether the side buckle between the cup body and the machine is in place, otherwise it will not work.
2. When the plug is removed from the stripping board, make sure that it is fully inserted and does not shake.

## Q2: What if the blade doesn't stir?

1. The cooking mechanism for fruit and vegetable juice needs to add water, generally about 150mL, and can not be directly put into the food ingredients.
2. Ingredients need to be cut into small pieces 1-1.5cm in size, large ingredients do not work

## Q3: Can I keep pushing the button?

It is best not to, the machine power is low, the switch needs to be clicked, and the continuous press cannot exceed 1 minute.

## Q4: Can the juicer be disassembled and cleaned?

You can't. Cleaning can not remove the mixing blade, can only be washed with water, otherwise it is not easy to install back, resulting in the machine does not work.

Image: A visual representation of common troubleshooting questions and answers for the blender.

## SPECIFICATIONS

Feature	Detail
Brand	SIMPLUS
Model Number	LLJH004GY00-US
Color	White
Capacity	20 Oz (approx. 1.3 Pounds)
Power	300 Watts
Voltage	120 Volts
Blade Material	Stainless Steel (4-edge cutter)
Container Material	BPA-Free ABS Plastic
Control Type	Single Button (Touch Function)
Product Dimensions	4.1"D x 4.1"W x 11.2"H
Item Weight	1.85 pounds

## WARRANTY

This SIMPLUS Personal Blender comes with a Limited Warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage details and duration.

## CUSTOMER SUPPORT

For any questions, concerns, or assistance with your SIMPLUS Personal Blender, please contact our customer support team. Refer to the contact information provided in your warranty documentation or visit the official SIMPLUS website for support options.