

[Manuals.plus](#) /

> [Lamshaw](#) /

> Lamshaw Silicone Sport Replacement Straps for Kuizil T70 1.91" Smartwatch - Instruction Manual

Lamshaw T70 1.91" Smartwatch Bands

Lamshaw Silicone Sport Replacement Straps for Kuizil T70 1.91" Smartwatch - Instruction Manual

Model: T70 1.91" Smartwatch Bands

1. PRODUCT OVERVIEW

The Lamshaw Silicone Sport Replacement Straps are designed for compatibility with the Kuizil T70 1.91" Smartwatch. These bands are crafted from soft, durable silicone, offering a comfortable and secure fit for daily wear and various activities. They feature a quick-release pin mechanism for easy installation and removal.



Image 1.1: A set of three Lamshaw silicone sport replacement straps for the Kuizil T70 smartwatch, showcasing black, gray, and blue color options.

2. PACKAGE CONTENTS

Verify that your package contains the following items:

- Lamshaw Silicone Sport Replacement Straps (quantity as per pack)
- Quick-release pins (pre-installed or included separately)

3. INSTALLATION GUIDE

Follow these steps to install or replace your smartwatch bands:

1. **Remove Existing Band (if applicable):** Locate the quick-release pin on the underside of your current watch band where it connects to the smartwatch. Pull the pin inwards to detach the band from the watch lug. Repeat for the other side.

2. **Prepare New Band:** Take one half of the new Lamshaw silicone strap. Ensure the quick-release pin is properly seated within the band.
3. **Attach First Side:** Insert one end of the quick-release pin into the corresponding lug hole on the smartwatch.
4. **Secure Band:** While holding that end in place, pull the quick-release lever inwards to retract the other end of the pin. Align the retracted pin with the opposite lug hole and release the lever. The pin should snap securely into place. Gently tug on the band to ensure it is firmly attached.
5. **Attach Second Side:** Repeat steps 2-4 for the second half of the watch band.




Image 3.1: Components of a single silicone watch band, highlighting the quick-release pin mechanism for easy attachment.




Image 3.2: Another view of a silicone watch band, in blue, demonstrating the two parts and the quick-release pins.




Image 3.3: A black silicone watch band, disassembled, illustrating the quick-release pin design for secure attachment to the smartwatch.

Your browser does not support the video tag.

Video 3.1: This video demonstrates the step-by-step process of installing a silicone replacement band onto a smartwatch using the quick-release pins.

4. OPERATING INSTRUCTIONS

Once installed, the Lamshaw silicone sport straps are ready for use. Adjust the band to a comfortable fit on your wrist using the buckle and strap holes. Ensure it is snug enough for accurate sensor readings from your smartwatch, but not so tight as to restrict circulation.



Image 4.1: A user wearing the grey silicone sport band, demonstrating a comfortable fit during an activity.



Image 4.2: A user wearing the black silicone sport band, illustrating its suitability for everyday use and activities like typing.



Image 4.3: A user wearing the blue silicone sport band, showing its casual and comfortable appearance.



Image 4.4: Features of the silicone band, including breathability, sweat resistance, lightweight design, and skin-friendliness, shown with water splashes.

5. MAINTENANCE AND CARE

To ensure the longevity and hygiene of your silicone watch bands, follow these care instructions:

- **Regular Cleaning:** Clean the bands regularly with mild soap and water. Rinse thoroughly and dry with a soft cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the silicone material.
- **Drying:** Ensure the bands are completely dry before reattaching them to your smartwatch or wearing them to prevent skin irritation.
- **Storage:** Store bands in a cool, dry place away from direct sunlight when not in use to prevent discoloration or degradation of the material.

6. TROUBLESHOOTING

If you encounter any issues with your watch bands, refer to the following common solutions:

- **Band Not Attaching Securely:**
 - Ensure the quick-release pins are fully retracted and properly aligned with the lug holes.
 - Verify that both ends of the pin snap into place. Gently wiggle the band to confirm it is secure.
 - Check for any debris in the lug holes that might obstruct the pin.
- **Skin Irritation:**
 - Ensure the band is clean and dry. Residue from sweat, soap, or lotions can cause irritation.
 - Adjust the band to a looser fit if it feels too tight.
 - If irritation persists, discontinue use and consult a dermatologist.

- **Discoloration:**

- Silicone bands can sometimes absorb dyes from clothing or other materials. Clean immediately with mild soap and water.
- Avoid prolonged exposure to direct sunlight or harsh chemicals.

7. SPECIFICATIONS

Brand	Lamshaw
Compatibility	Kuizil T70 1.91" Smartwatch
Material	Soft Silicone
Clasp Type	Buckle
Metal Type	No Metal Type
Item Type Name	Watch band

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the retailer's return policy or contact Lamshaw customer service directly through their official channels. Specific warranty details are not provided in this manual.

9. ADDITIONAL INFORMATION

Your browser does not support the video tag.

Video 9.1: An overview showcasing the various colors and styles of Lamshaw silicone watch bands.



Image 9.1: A display of multiple Lamshaw silicone watch bands in a range of colors, highlighting the available variety.



Image 9.2: Smartwatches equipped with various colored Lamshaw silicone bands, showcasing different style options.