

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Baby Einstein](#) /
- › [Baby Einstein + Hape Discovery Radio Toy \(Model 17011\) Instruction Manual](#)

### Baby Einstein 17011

# Baby Einstein + Hape Discovery Radio Toy (Model 17011) Instruction Manual

Model: 17011

## 1. INTRODUCTION AND OVERVIEW

The Baby Einstein + Hape Discovery Radio Toy is designed to engage babies aged 6 months and up in real-world learning through music and sound. This Montessori-inspired toy features over 40 melodies and sounds, colorful lights, and encourages the development of fine motor skills and cause-and-effect understanding. Crafted from FSC certified wood, it offers a durable and portable design with adjustable volume levels for comfort and peace of mind.



Image 1: The Baby Einstein + Hape Discovery Radio Toy, showcasing its design and colors.

## 2. SAFETY INFORMATION

---

To ensure safe use of the Discovery Radio Toy, please observe the following:

- Keep the toy away from fire or direct heat sources.
- Always supervise infants and toddlers during play.
- Ensure the battery compartment is securely closed to prevent access to batteries.

## 3. SETUP

---

### 3.1 Battery Installation

The Discovery Radio Toy requires 2 AA batteries, which are included with the product. To install or replace batteries:

1. Locate the battery compartment on the underside of the toy.
2. Using a Phillips head screwdriver, loosen the screw on the battery compartment cover.
3. Remove the cover.
4. Insert 2 AA batteries, ensuring correct polarity (+/-).
5. Replace the cover and tighten the screw.

### 3.2 Initial Checks

Before first use, ensure all parts are securely attached and free from damage. The flexible strap should be firmly connected to the toy.

## 4. OPERATING INSTRUCTIONS

---

The Discovery Radio Toy offers interactive features to stimulate your child's senses and development.

### 4.1 Power On/Off and Volume Control

Locate the power and volume switch on the side of the toy. Slide the switch to select between high volume, low volume, or off, according to your preference.

## Volume control



*Image 2: Adjusting the volume on the Discovery Radio Toy.*

### 4.2 Exploring Melodies and Sounds

The toy features a central dial that controls various sounds and melodies:

- **Turn the Dial:** Rotate the large blue dial to cycle through 6 different stations, playing a total of 30 classic melodies. The dial lights up with colorful lights as it plays, attracting your baby's attention.
- **Press the Dial:** Press down on the central dial to discover up to 12 curious animal sounds. This action helps teach cause and effect.

**Twist for classical melodies**



**40+ Melodies  
& sounds**

*Image 3: A child twisting the dial to activate melodies.*



**Press for  
animal  
sounds**

**6-36  
m**



*Image 4: A child pressing the dial to activate animal sounds.*

### **4.3 Portability**

The Discovery Radio Toy is designed with a flexible strap, making it easy for small hands to grip and carry, allowing for discovery on the go.



*Image 5: The toy's portable design with a flexible strap.*

## 5. MAINTENANCE

---

To clean the Discovery Radio Toy, wipe it with a clean, damp cloth. Do not immerse the toy in water or use harsh cleaning agents.

## 6. TROUBLESHOOTING

---

- **No Sound/Lights:** Ensure the power/volume switch is set to either high or low volume, not off. Check that the batteries are correctly installed and not depleted. Replace batteries if necessary.
- **Intermittent Function:** Verify that the battery compartment is securely closed and the batteries are making proper contact.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Number	17011
Recommended Age	6 months - 3 years
Dimensions	16.1 x 5.36 x 10.01 cm
Weight	317.51 g
Material Composition	58% Plastic, 39% Wood, 3% Electronic Parts
Batteries Required	Yes (2 AA batteries)
Batteries Included	Yes
Educational Objective(s)	Discovering sounds and learning about cause and effect




Image 6: Product dimensions for the Discovery Radio Toy.

## 8. WARRANTY AND SUPPORT

---

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service. Keep your purchase receipt for proof of purchase.

