

JBL JBL LIVE BUDS 3

JBL LIVE BUDS 3 Smart Touch Display Wireless Earbuds User Manual

Model: JBL LIVE BUDS 3

Brand: JBL

1. INTRODUCTION

Thank you for choosing the JBL LIVE BUDS 3 Smart Touch Display Wireless Earbuds. These earbuds offer a premium audio experience with advanced features such as Hi-Res Audio Wireless support, LDAC compatibility, and advanced noise-canceling technology. The innovative smart touch display on the charging case provides intuitive control over various functions.

This manual provides detailed instructions on how to set up, operate, and maintain your JBL LIVE BUDS 3 earbuds to ensure optimal performance and longevity.

2. WHAT'S IN THE BOX

- JBL LIVE BUDS 3 Earbuds (Left and Right)
- Smart Charging Case with Touch Display
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (XS, S, M, L - M size pre-installed)
- Instruction Manual (this document)
- Safety Sheet
- Warranty Card



Image: JBL LIVE BUDS 3 earbuds and their smart charging case.

3. SETUP

3.1 Initial Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.

2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Select "JBL LIVE BUDS 3" from the list of available devices.
4. Once connected, the earbuds will indicate successful pairing.

3.2 Installing the JBL Headphones App

For full customization and access to all features, download the JBL Headphones app from your device's app store. The app allows you to:

- Customize touch controls.
- Adjust equalizer settings.
- Control noise canceling and ambient sound modes.
- Perform a fit check for optimal sound and comfort.
- Update firmware.




Image: Screenshot of the JBL Headphones app showing equalizer settings.

3.3 Fitting the Earbuds


Proper fit is crucial for sound quality and noise cancellation. Follow these steps:

1. **Choose the correct ear tip size:** Experiment with the included ear tips (XS, S, M, L) to find the size that provides a snug and comfortable seal in your ear canal. The M size is pre-installed.
2. **Hold the earbud securely:** Grasp both sides of the earbud body.
3. **Insert and twist:** Gently push the earbud into your ear and twist it towards the back of your head until it fits securely.
4. **Check fit with the app:** Use the "Fit Check" feature in the JBL Headphones app to confirm optimal fit and ensure there is no sound leakage.

イヤホンの装着方法


- 1** イヤーチップのサイズを4つの中から選びます。

(お買い上げ時はMサイズが装着されています。)



- 2** イヤホン本体の両側をしっかりと手で持ちます。

- 3** そのまましっかり耳に押し込み、後頭部方向にひねり、フィットするように装着します。



- 3** JBL Headphonesアプリで「フィット感」をチェックし、音漏れがないか確認します。



Image: Visual guide on selecting ear tips and correctly fitting the earbuds.

▶ Personi-Fi 3.0



▶ 空間サウンド



▶ フィット感チェック



Image: Screenshot of the JBL Headphones app demonstrating the fit check feature.

4. OPERATING

4.1 Smart Charging Case Display Functions

The 1.45-inch smart touch display on the charging case allows for direct control without needing your phone. Functions include:

- Volume control.
- Noise Cancelling ON/OFF.
- Equalizer (EQ) switching.
- "Find My Earbuds" function.
- Customizing the lock screen wallpaper with your own photos.
- Strap hole for enhanced portability.

便利なスマートディスプレイ付充電ケース

1.45インチの日本語対応 タッチディスプレイ搭載

音量・ノイズキャンセリングのON/OFF、EQ切替、イヤホンを見つけるなどの操作が可能です。



オリジナルロック画面壁紙を 設定可能

家族・ペットなどの自分の好きな写真を壁紙に
設定し、自分だけのオリジナルケースに！



ストラップホールを搭載

日本からの要望により搭載。
ストラップなどをつけることで
持ち運びや着用の利便性が高まります。



Image: The smart charging case display interface, demonstrating controls for volume, noise cancellation, EQ, and other settings.




Image: The "Find My Earbuds" feature in the JBL Headphones app, showing how to locate misplaced earbuds.

4.2 Earbud Touch Controls

The touch controls on each earbud can be customized via the JBL Headphones app. You can assign functions such as playback control, volume adjustment, ambient sound modes, and voice assistant activation to single tap, double tap, triple tap, and tap & hold gestures.

イヤホンのタッチ操作もカスタマイズ可能



左右のイヤホンにそれぞれ、再生コントロールや、音量調整、
外音取込、ボイスアシスタントなどの自分の好きな機能を割り当て可能です。

※機能の割当は、各操作内の組み合わせになります。

Image: Screenshots from the JBL Headphones app illustrating the customization options for earbud touch controls.


4.3 Noise Cancelling and Ambient Sound Modes

The JBL LIVE BUDS 3 feature Hybrid Noise Cancelling with real-time correction, which monitors ambient noise and adjusts noise cancellation across various frequency bands. This results in up to 15dB improvement in mid-range noise cancellation compared to previous models.

You can switch between Noise Cancelling, Ambient Aware, and TalkThru modes using the smart charging case or the JBL Headphones app:

- **Noise Cancelling:** Blocks out ambient noise for an immersive listening experience.
- **Ambient Aware:** Allows you to hear your surroundings while still enjoying your audio.
- **TalkThru:** Lowers music volume and amplifies speech, allowing you to converse without removing your earbuds.

進化したノイズキャンセリング性能



リアルタイムで周囲のノイズ成分を監視し、ノイズキャンセリングをかける周波数帯とその度合いを調整する「リアルタイム補正」機能を搭載したハイブリッドノイズキャンセリング。

耳内の騒音レベルを検出し、騒音レベルが安定した最小値に達するまで ANCフィルタリングを繰り返します。前作LIVE FREE 2では9バンドのEQでANCの最適化をはかりましたが、**LIVE BUDS 3は13バンドを使用し、特に中音域において最大約15dBのANC改善を実現しました。**

Image: A graph demonstrating the effectiveness of noise cancellation across various noise frequencies, from low (vehicle noise) to high (human voices, street noise).



- ▶ アンビエントアウェア
- ▶ トークスルー
- ▶ ボイスアウェア



4.4 Multipoint Connection

The JBL LIVE BUDS 3 support multipoint connection, allowing you to seamlessly switch between two Bluetooth devices simultaneously. For example, you can listen to music on your tablet and instantly answer a call on your smartphone.

- **Remote Work:** Participate in a remote meeting on your PC while staying ready to receive calls on your smartphone.
- **Work & Private:** Connect to two smartphones for separate use.
- **Entertainment:** Automatically switch from listening to music on your smartphone to watching a movie on your tablet.

マルチポイント対応で 2台のデバイスに同時接続/使用可能



Image: Illustration of multipoint connectivity, showing earbuds connected to a laptop and a smartphone, and two smartphones, or a smartphone and a tablet.

4.5 Charging

To charge the earbuds, place them back into the charging case. The case itself can be charged via the included USB-C cable or wirelessly using a Qi-compatible wireless charger.

- The smart display on the case will show the battery levels of both the earbuds and the case.
- A full charge provides up to 40 hours of combined playback time (earbuds + charging case).

5. MAINTENANCE

To ensure the longevity and optimal performance of your JBL LIVE BUDS 3, follow these maintenance guidelines:

- **Cleaning Earbuds:** Regularly clean the ear tips and the mesh grilles of the earbuds with a dry, soft cotton swab to remove earwax and debris. Do not use liquids directly on the earbuds.
- **Cleaning Charging Case:** Wipe the charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds or case to extreme temperatures, humidity, or direct sunlight.
- **Water Resistance:** The earbuds are water-resistant (IP55 rated), meaning they can withstand splashes and sweat. However, they are not designed for submersion in water. Ensure they are dry before placing them back in the charging case.

6. TROUBLESHOOTING

If you encounter any issues with your JBL LIVE BUDS 3, refer to the following common troubleshooting steps:

- **No Sound / Intermittent Sound:**
 - Ensure earbuds are charged.
 - Check Bluetooth connection on your device. Try re-pairing.
 - Ensure the earbuds are clean and free of debris.
 - Try resetting the earbuds (refer to the JBL Headphones app or JBL support website for specific instructions).
- **Earbuds Not Charging:**
 - Ensure the charging case is charged.
 - Verify the earbuds are correctly seated in the charging case.
 - Check the USB-C cable and power adapter for damage.
 - Clean the charging contacts on both the earbuds and the case.
- **Poor Noise Cancelling Performance:**
 - Ensure a proper seal by trying different ear tip sizes. Use the "Fit Check" feature in the app.
 - Make sure Noise Cancelling mode is activated.
- **Smart Case Display Not Responding:**
 - Ensure the case has sufficient battery.
 - Try restarting the case by closing and reopening it, or connecting it to a power source.

7. SPECIFICATIONS

Feature	Detail
Brand	JBL

Feature	Detail
Model Number	JBLLIVEBUDS3
Color	Black
Ear Placement	In-Ear
Headphone Style	True Wireless
Impedance	16 Ohms
Battery Average Life	40 Hours (earbuds + charging case)
Noise Control	Hybrid Noise Cancelling with Real-time Correction
Sensitivity	100 dB
Audio Driver Type	Dynamic Driver
Audio Driver Size	10 mm
Compatible Devices	Smartphones, Tablets, Laptops
Waterproof Type	Water Resistant (IP55 rated)
Wireless Type	Bluetooth
Bluetooth Version	5.3
Product Weight	82.2 grams
Additional Features	Qi charging compatible, Smart Touch Display charging case, Ambient sound capture, Hi-Res Wireless (LDAC), Built-in microphone, Multipoint, Single-ear use possible, Customizable EQ via app.

8. WARRANTY & SUPPORT

8.1 Warranty Information

Your JBL LIVE BUDS 3 come with a **1-year warranty** from the date of purchase for new products bought from authorized domestic retailers. Proof of purchase (receipt or invoice) is required for warranty claims.

Please note the following conditions:

- The warranty is valid only for products used within the country of purchase.
- For used or resale items, repairs are subject to a fee.
- Battery degradation over time is normal and not covered under warranty.

8.2 Customer Support

For further assistance, technical support, or warranty claims, please contact JBL customer service through their official website or the contact information provided on your warranty card.

You can also visit the official JBL website for FAQs, updated manuals, and software downloads www.jbl.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question