

Manuals.plus /
› [WLIVE](#) /
› WLIVE Black Dresser & TV Stand User Manual

WLIVE ASNG114DK2

WLIVE Black Dresser & TV Stand User Manual

Model: ASNG114DK2
Brand: WLIVE

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your WLIVE Black Dresser, which also functions as a TV stand. Designed for versatility, this unit features ample storage, integrated charging capabilities, and customizable LED lighting, making it a functional addition to bedrooms, living rooms, or closets.



Figure 1: WLIVE Black Dresser functioning as a TV stand with LED lighting.

PRODUCT FEATURES

- **Spacious Storage:** Features 8 separate foldable drawers, including 2 different sizes, designed for classified storage of various items.
- **Integrated TV Stand:** The sturdy wood top is suitable for placing TVs up to 55 inches, keeping frequently used items within easy reach.
- **Built-in Charging Station:** Equipped with a power strip featuring 2 AC outlets and 2 USB ports for convenient charging of electronic devices.
- **Smart RGB LED Lights:** Includes LED lights with multiple color options, allowing customization to suit mood and environment.

- **Durable Construction:** Made with eco-friendly wood panels that are scratch-resistant and easy to clean. Features a sturdy steel frame and a five-legged design for stability.
- **Enhanced Safety:** Includes an anti-tipping device to ensure stability and safety for household members and pets.
- **Adjustable Feet:** Equipped with adjustable feet to maintain stability on uneven surfaces.



Figure 2: Illustration of the dresser's spacious 8-drawer storage capacity.

Your browser does not support the video tag.

Video 1: Overview of the WLIVE Dresser for Bedroom with Charging Station, showcasing its design and functionality.

DIMENSIONS AND SPECIFICATIONS

Specification	Value
Brand	WLIVE

Product Dimensions	11.7"D x 47.2"W x 31"H
Color	Charcoal Black Wood Grain
Mounting Type	Floor Mount
Room Type	Bedroom, Hallway, Living Room, Office
Model Name	ASNG114 Fabric dresser/DK2
Item Weight	29.5 Pounds
Assembly Required	Yes



Figure 3: Detailed product dimensions for planning placement.

SETUP AND ASSEMBLY INSTRUCTIONS

The WLIVE dresser is designed for easy assembly. All necessary parts and accessories are coded, and precise holes ensure accurate and faster installation. Please follow the detailed installation instructions provided in the packaging. For visual guidance, refer to the official installation video below.

Your browser does not support the video tag.

Video 2: Step-by-step installation guide for the WLIVE Dresser with Charging Station.

Key Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the main metal frame structure according to the diagrams.
3. Secure the wooden top panel and internal shelves.
4. Install the built-in charging station into the designated slot on the top panel.
5. Attach the LED light strip to the underside of the top shelf in the open compartment.
6. Insert the fabric drawers into their respective slots. Ensure the bottom board is placed inside each drawer for stability.
7. Install the anti-tipping device to a wall stud for enhanced safety.
8. Adjust the five adjustable feet to level the dresser on uneven floors.



Figure 4: Illustration of the anti-tilt device and adjustable feet for stability.

OPERATING INSTRUCTIONS

Using the Charging Station:

The built-in power strip provides convenient access to power. Plug the dresser's main power cord into a standard wall outlet. You can then use the 2 AC outlets for devices like TVs or sound systems, and the 2 USB ports for charging smartphones, tablets, or other USB-powered devices.



Figure 5: Close-up of the recessed charging station.

Controlling the RGB LED Lights:

The LED lights can be controlled to change colors and modes. Refer to the separate LED light remote control or app instructions included with your product for detailed operation. You can select from multiple colors and various lighting effects to create your desired ambiance.

RGB LED LIGHT STRIP



Figure 6: Demonstrating the RGB LED light strip and its control.

MAINTENANCE AND CARE

- **Cleaning:** The eco-friendly wood panel top and fabric drawers have smooth surfaces that are easy to clean. Use a soft, damp cloth to wipe down surfaces. Avoid harsh chemicals or abrasive cleaners, which may damage the finish.
- **Drawer Care:** The fabric drawers are foldable. If they become misshapen, gently reshape them. Ensure the bottom board is always properly inserted to maintain drawer rigidity.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain the dresser's stability.
- **LED Lights:** If the LED lights are not functioning, check the power connection and ensure the remote control batteries are not depleted.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dresser is wobbly/unstable.	Uneven floor; loose connections.	Adjust the leveling feet at the bottom of the frame. Check and tighten all screws. Ensure the anti-tipping device is securely installed.
Drawers do not slide smoothly or are misshapen.	Drawer bottom board not properly inserted; overloaded drawer.	Remove the drawer, ensure the bottom board is fully inserted and flat. Reduce the weight of items in the drawer.
Charging station not working.	Dresser not plugged in; power strip issue.	Ensure the dresser's main power cord is securely plugged into a working wall outlet. Check if the power strip has a reset button (if applicable).
LED lights not turning on/changing colors.	Loose connection; remote control battery dead.	Check the connection of the LED strip to the power source. Replace batteries in the remote control. Refer to the LED light manual for specific troubleshooting.

WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and customer satisfaction. If you encounter any questions or issues regarding your dresser, please do not hesitate to contact WLIVE customer support. Contact information can typically be found on the product packaging or the official WLIVE website. Please have your model number (ASNG114DK2) and purchase details ready when contacting support.

© 2025 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D6V7S744>

More documents and user manuals: <https://manuals.plus/>