

[Manuals.plus](#) /

> [Wielio](#) /

> Wielio Mini Projector User Manual - Model B0D6VP2BZP

Wielio Mini Projector B0D6VP2BZP

Wielio Mini Projector User Manual

Model: B0D6VP2BZP

1. INTRODUCTION

Thank you for purchasing the Wielio Mini Projector. This manual provides essential information for setting up, operating, and maintaining your projector. Please read it thoroughly before use to ensure optimal performance and safety.



Image 1.1: Wiello Mini Projector displaying a high-quality image, highlighting its native 1080P resolution, 18000 Lumens brightness, 5G/2.4G WiFi, and Bluetooth 5.0 capabilities.

2. IMPORTANT SAFETY INSTRUCTIONS

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Use only the power adapter supplied with the projector.
- Keep the projector away from water or other liquids.
- Do not attempt to repair the projector yourself. Contact customer support for assistance.
- Place the projector on a stable, level surface.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Wielio Mini Projector
- Remote Control
- Power Cable
- HDMI Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the projector's components and connection ports.



Image 4.1: Overview of the Wielio Mini Projector's compatibility with multiple devices, including HDMI cable, USB, AV, TF Extend, Headset, Bluetooth Speaker, Laptop, DVD Player, TV Stick, Game consoles, Miracast, Smartphone, and Tablet PC.

4.1. Ports and Controls

- **HDMI Port:** Connect to laptops, gaming consoles, TV sticks, etc.
- **USB Port:** Connect USB flash drives for media playback.
- **AV Port:** Connect to older devices using an AV cable.
- **Audio Out (3.5mm):** Connect external headphones or speakers.
- **Power Input:** Connect the power adapter.
- **Focus Ring:** Adjust image clarity.
- **Keystone Correction:** Adjust image shape.

5. SETUP

5.1. Placement

Choose a suitable location for your projector. The projection distance and screen size can vary. The projector supports various mounting options:



Image 5.1: The projector supports a maximum screen size of 300 inches and can be placed on a table, mounted on the ceiling, or

installed on a tripod.

- **Table Placement:** Place the projector on a flat, stable surface.
- **Ceiling Mount:** Securely attach the projector to the ceiling using a compatible mount (not included).
- **Tripod Installation:** Mount the projector on a tripod for flexible positioning.

5.2. Power Connection

1. Connect the power cable to the projector's power input port.
2. Plug the other end of the power cable into a power outlet.
3. Press the power button on the projector or remote control to turn it on.

5.3. Focus and Keystone Adjustment

- **Focus:** Rotate the focus ring on the projector lens until the image appears clear and sharp.
- **Keystone:** Use the keystone correction dial or menu option to adjust the image shape if it appears trapezoidal.

6. OPERATING INSTRUCTIONS

6.1. Basic Operation

- **Power On/Off:** Press the power button on the projector or remote.
- **Navigation:** Use the arrow keys and OK button on the remote or projector to navigate menus.
- **Source Selection:** Press the 'Source' button to select input methods (HDMI, USB, AV, Screen Mirroring).

6.2. Connectivity

6.2.1. HDMI Connection

Connect an HDMI cable from your device (e.g., laptop, TV stick, PS4) to the HDMI port on the projector. Select HDMI as the input source.

6.2.2. USB Media Playback

Insert a USB flash drive into the USB port. Select 'USB' as the input source and navigate to your media files.

6.2.3. Wireless Screen Mirroring (WiFi)

The projector supports 2.4G and 5G WiFi for screen mirroring from iOS and Android devices.

5G WiFi Wireless Screen Mirroring

Ultra-fast casting, say goodbye to delay!



Image 6.1: Wireless screen mirroring via 5G WiFi, compatible with Android, iOS, and Windows devices for ultra-fast casting.

1. Select 'Screen Mirroring' or 'Wireless Display' from the projector's input source menu.
2. Ensure your mobile device and the projector are connected to the same WiFi network.
3. On your iOS device, open Control Center and tap 'Screen Mirroring'. Select the projector from the list.
4. On your Android device, enable 'Wireless Display', 'Smart View', or 'Cast' (names may vary) and select the projector.
5. *Note: Due to copyright restrictions, some streaming services (e.g., Netflix, Hulu, Amazon Prime) may not support screen mirroring via WiFi. An HDMI cable connection from a laptop or TV stick is often required for these services.*

6.2.4. Bluetooth Audio Output

Connect external Bluetooth speakers or headphones for enhanced audio.

Bluetooth 5.2 & Hi-Fi Stereo Speaker

Let you enjoy ultimated Sound Experience!




Airpods



Bluetooth Headphone



Bluetooth Loudspeaker



Bluetooth Function only sends audio to bluetooth speakers unable to pair projector with Phone/PC

Image 6.2: The projector features Bluetooth 5.2 and a built-in Hi-Fi stereo speaker. It can connect to various Bluetooth audio devices for an enhanced sound experience. The Bluetooth function only sends audio to Bluetooth speakers, not to phones or PCs.

1. Go to the projector's 'Settings' menu and select 'Bluetooth'.
2. Turn on Bluetooth and scan for available devices.
3. Select your Bluetooth speaker or headphones from the list to pair.

7. MAINTENANCE

7.1. Cleaning

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Casing:** Wipe the projector's exterior with a soft, dry cloth. Avoid using harsh chemicals.
- **Ventilation:** Regularly check and clean the ventilation openings to ensure proper airflow and prevent dust buildup.

7.2. Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the original packaging or a protective case to prevent dust and damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image displayed	Power cable loose, incorrect input source, device not connected	Check power connection, select correct input source, ensure device is properly connected.
Image blurry	Focus not adjusted, projector too close/far from screen	Adjust the focus ring, reposition the projector.
Image trapezoidal	Projector not perpendicular to screen	Adjust keystone correction.
No sound	Volume too low, external audio device not connected, incorrect audio output selected	Increase volume, check external audio connections, ensure correct audio output is selected in settings.
Screen mirroring not working	Not on same WiFi, device compatibility, app restrictions	Ensure both devices are on the same WiFi. Check device's screen mirroring function. Use HDMI for restricted content.

9. SPECIFICATIONS

1080P Native More Realistic, Detailed Color Reproduction



Image 9.1: The Wielio projector offers native 1080P resolution and 18000 lumens for more realistic and detailed color reproduction compared to standard 720P projectors.

Feature	Detail
Brand	Wielio
Model	B0D6VP2BZP
Native Resolution	1920 x 1080 (Native 1080P Full HD)
Supported Resolution	Up to 4K
Brightness	18000 Lumens
Connectivity Technology	HDMI, USB, AV, 2.4G/5G WiFi, Bluetooth 5.2
Projection Size	Maximum 300 inches
Speakers	2*Speakers (Built-in)

Feature	Detail
Lamp Life	50,000 Hours

10. WARRANTY AND SUPPORT

10.1. Warranty Information

The Wielio Mini Projector comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

10.2. Customer Support

If you encounter any issues or have questions regarding your Wielio Mini Projector, please contact our customer support team. We are committed to providing 100% satisfaction. Our team will respond to inquiries within 24 hours. For support, please refer to the contact information provided on the product packaging or the official Wielio website.

