

Fussion UGL0097_B

Fussion Galaxy Projector UGL0097_B Instruction Manual

Model: UGL0097_B | Brand: Fussion

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective operation of your Fussion Galaxy Projector UGL0097_B. Please read this manual thoroughly before use and retain it for future reference.

2. WHAT'S IN THE BOX

Verify that all items listed below are included in your package:

- Galaxy Projector for Bedroom x1
- Film Discs x13 (1 disc built into the projector)
- USB-C Cable x1
- Cleaning Cloth x1
- User Manual x1




Image: Contents of the Fussion Galaxy Projector package.

3. PRODUCT FEATURES

- **13-in-1 Film Discs:** Includes a variety of celestial scenes such as Solar System, Earth, Moon, Milky Way, and various nebulae.
- **Wide Coverage & 360° Rotation:** Projects images up to 16.4ft away, covering 135-754 sq ft, with full 360° rotation.
- **Adjustable Focal Length:** Top knob allows for clear imaging on various surfaces and distances.
- **Timing Function:** Automatic shut-off options for 1, 2, or 4 hours (default).
- **USB Powered:** Convenient power source for versatile placement.



Image: Key features and improvements of the projector.



Image: Enhanced projection capabilities of the Fussion Galaxy Projector.

4. SETUP

1. **Power Connection:** Connect the provided USB-C cable to the projector and a suitable USB power adapter (not included).
2. **Insert Film Disc:** Gently pull out the disc slot from the side of the projector. Place your desired film disc into the slot, ensuring it is oriented correctly (usually with the 'UP' arrow facing upwards). Push the disc slot back into the projector until it clicks into place.
3. **Adjust Focus:** Use the top knob on the projector to adjust the focal length until the projected image is clear on your desired surface (wall or ceiling).

4. **Positioning:** Place the projector on a stable surface, aiming it towards the desired projection area. The 360° rotation feature allows for flexible positioning.




Image: Steps for inserting film discs and adjusting the projector.

Video: Disc Insertion and Operation Overview

Video demonstrating the unboxing, disc insertion process, and initial operation of the Fussion Galaxy Projector.


5. OPERATING INSTRUCTIONS

The projector features intuitive controls for a customized experience:

- **Power ON/OFF:** Press the power button to turn the projector on or off.
- **Timer Function:** Press the timer button to cycle through 1-hour, 2-hour, or 4-hour (default) automatic shut-off settings. The projector will turn off automatically after the selected duration.
- **Rotation Control:** Use the speed control button to adjust the rotation speed of the projected image. Press the stop rotation button to pause the rotation.

- **Focal Adjustment:** Rotate the top knob to achieve a clear and sharp image on your projection surface.

Timing Function



Accompanies you to sleep quietly and switches off automatically, so you don't need to switch it on all night.

Image: Timer function settings for automatic shut-off.

6. FILM DISCS

Your projector comes with 13 unique film discs, allowing you to explore various celestial wonders:

- Solar System
- Earth
- Moon
- Virgo Supercluster
- Centaurus A
- Black Hole
- Antennae Galaxies
- Wormhole

- The Milky Way
- Mystic Mountain
- Sharpless 2-308
- Small Magellanic Cloud
- Laniakea Supercluster

Fall Asleep Under Different Skies

13 Themed Film Discs




Image: Overview of the 13 themed film discs included with the projector.



Image: A selection of interchangeable film discs, including Solar System, Earth, and various galaxies.

Watch Different Galaxies at Home

13 Interchangeable Film Discs



Solar System



Earth



Sharpless 2-308



Centaurus A



Antennae Galaxies



Black Hole

Image: Another selection of interchangeable film discs, featuring superclusters and nebulae.

7. MAINTENANCE

To ensure the longevity and optimal performance of your projector, follow these maintenance guidelines:

- **Cleaning the Lens and Discs:** Use the provided cleaning cloth to gently wipe the projector lens and film discs. Avoid using abrasive materials or harsh chemicals, as these can scratch or damage the surfaces.
- **Dust Removal:** Regularly wipe the exterior of the projector with a soft, dry cloth to remove dust.
- **Storage:** When not in use, store the projector and film discs in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

If you encounter any issues with your Fussion Galaxy Projector, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No projection	Power cable not connected; Projector not turned on.	Ensure USB-C cable is securely connected and the projector is powered on.
Image is blurry	Focal length not adjusted correctly.	Rotate the top knob to adjust the focus until the image is clear.
Disc not rotating	Rotation function is off; Disc not inserted correctly.	Press the rotation control button to activate rotation. Ensure the film disc is properly seated in its slot.
Projector turns off unexpectedly	Timer function is active.	Check the timer settings. The projector will automatically turn off after 1, 2, or 4 hours if the timer is set.

9. SPECIFICATIONS

- **Model Number:** UGL0097_B
- **Brand:** Fussion
- **Color:** Black
- **Shape:** Round
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Light Source Type:** Light Emitting Diode
- **Power Source:** Corded Electric (USB-C)
- **Item Weight:** 1.34 pounds (0.61 Kilograms)
- **Product Dimensions:** 5.7"L x 4.33"W x 5.7"H
- **Number of Light Sources:** 13 (referring to disc scenarios)
- **Special Features:** 3D-Ready, Lightweight, Portable, Timer
- **UPC:** 767119731279

10. WARRANTY AND SUPPORT

The Fussion Galaxy Projector UGL0097_B comes with a **12-month warranty**. If you encounter any issues during installation or operation, or if you receive a defective item, please contact our customer service for prompt assistance. We aim to resolve all inquiries within 24 hours.

For customer service, please refer to the contact information provided in your product packaging or on the official Fussion website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question