

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [CWOWDEFU](#) /
- › [CWOWDEFU Kids Tablet 10 inch Pro User Manual](#)

CWOWDEFU Kids Tablet 10 inch Pro

CWOWDEFU Kids Tablet 10 inch Pro User Manual

Model: Kids Tablet 10 inch Pro

INTRODUCTION

This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your CWOWDEFU Kids Tablet 10 inch Pro. Please read this manual thoroughly to ensure proper use and to maximize your tablet's features.



Image: The CWOWDEFU Kids Tablet 10 inch Pro, encased in its protective blue EVA cover, showcasing its vibrant display with a child-friendly interface. The image highlights the tablet's design and its primary use for children.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- 10 inch kids tablet
- Charger
- EVA protective cover

- Protective film
- USB cable

Cosa Riceverete?

- 1* Cwow Kid's Tab
- 1* Protect Case
- 1* Screen Protector
- 1* Charger
- 1* Type-C Cable
- 1* User Guide



Image: An overview of the package contents for the CWOWDEFU Kids Tablet, showing the tablet, charger, USB cable, protective film, and the EVA protective cover.

SETUP

1. Initial Charging

Before first use, fully charge the tablet using the provided charger and USB cable. Connect the USB cable to the tablet's charging port and the charger to a power outlet. The charging indicator will show the charging status.

2. Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options on the screen.

3. Connecting to Wi-Fi

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle **Wi-Fi On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the network password if prompted, then tap **Connect**.

4. Parental Control Setup (Cwow Kids+ and Android 14)

The tablet features robust parental controls through both the native Android 14 OS and the pre-installed Cwow Kids+ application. This allows you to manage screen time, content access, and app usage.

1. **Cwow Kids+ App:** Launch the Cwow Kids+ app. Follow the on-screen instructions to create a child profile, set time limits, and select appropriate content.
2. **Android 14 Parental Controls:** Navigate to **Settings > Digital Wellbeing & parental controls**. Here you can set up Google Family Link to manage your child's device from your own.

Easy to Parental Control



Image: A visual representation of the parental control settings on the tablet, demonstrating how parents can set a password and manage access to websites and applications.

5. Face ID Setup

For enhanced security, you can set up Face ID recognition:

1. Go to **Settings > Security & privacy > Face unlock**.
2. Follow the on-screen prompts to register your face. Ensure good lighting during the setup process.

OPERATING INSTRUCTIONS

1. Basic Navigation

- **Touch:** Tap an icon to open an app or select an item.
- **Swipe:** Slide your finger across the screen to scroll through pages or lists.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images and web pages.
- **Home Screen:** Tap the home button (usually a circle or house icon) to return to the main screen.



Image: The tablet's interface showcasing the Android 14 operating system, along with icons for Bluetooth 5.0 and WiFi 6, indicating modern connectivity features.

2. Using Cwow Kids+ Platform

The Cwow Kids+ platform offers a curated selection of child-friendly applications for learning and entertainment. Access it directly from the home screen. Parental controls within this app allow for customization of content and usage limits.

Customized for kids



Image: The tablet screen filled with various applications, including popular streaming services and educational games, demonstrating the range of content available for children.


3. App Management

- **Installing Apps:** Use the Google Play Store (if enabled by parental controls) or the Cwow Kids+ platform to download and install new applications.
- **Uninstalling Apps:** Press and hold an app icon on the home screen or app drawer, then drag it to the "Uninstall" option, or go to **Settings > Apps > See all apps**, select the app, and tap **Uninstall**.

4. Storage Management

The tablet comes with 128GB of internal storage, expandable up to 1TB using a microSD card (not included). To manage storage:

1. Go to **Settings > Storage** to view storage usage.
2. Insert a microSD card into the designated slot to expand storage.



EVA Standing Case

You don't have to worry about being damaged due to falling. The case is made of premium EVA material with a thickness of up to 10mm which comes within the package.

Image: A graphic illustrating the tablet's 128GB built-in storage, expandable up to 1TB, surrounded by icons of popular applications, emphasizing ample space for content.

5. Battery Usage and Charging

The 6000mAh battery provides extended usage. For optimal battery life:

- Charge the tablet fully before significant use.
- Avoid extreme temperatures.
- Close unused applications to conserve power.
- The tablet supports PD fast charging via its Type-C port.

Accompany Kid on Trip Day to Night



 7.5 Hours Video  12 Hours Web  300 Hours Standby




Image: A child using the tablet on an airplane, highlighting the device's portability and long-lasting 6000mAh battery, suitable for travel.

6. Camera Usage

The tablet is equipped with 5MP and 8MP cameras. Open the Camera app to take photos or record videos. Ensure adequate lighting for best results.

MAINTENANCE

1. Cleaning the Tablet and EVA Case

- Use a soft, lint-free cloth to clean the screen and tablet body. Avoid abrasive materials.
- For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner.
- The EVA protective case can be wiped clean with a damp cloth and mild soap if necessary. Ensure it is completely dry before reattaching to the tablet.

Protective case specially designed for CWOWDEFU C18W Kids Tablet.

4 Thickened anti-bumping corners, bring the tablet all-round protection.



Portable handle + retractable stand



Image: Detailed view of the EVA protective case, highlighting its robust design with reinforced corners, an integrated handle for carrying, and a retractable stand for hands-free viewing.

2. Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Go to **Settings > System > System update**.

3. Storage Optimization

To maintain performance, periodically clear unnecessary files and apps. Use the built-in storage manager in **Settings > Storage** to identify and remove large files or rarely used applications.

TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common solutions:

Problem	Solution
Tablet freezes or is unresponsive	Press and hold the Power button for about 10-15 seconds to force a restart. If the issue persists, try a factory reset (see below).
Wi-Fi disconnects frequently	Ensure you are within range of your Wi-Fi router. Try forgetting the network and reconnecting. Restart your Wi-Fi router.
Tablet overheats	Avoid using the tablet in direct sunlight or poorly ventilated areas. Close background applications. If using the EVA case, ensure it does not obstruct ventilation. Reduce screen brightness.
Battery drains quickly	Reduce screen brightness, disable Wi-Fi/Bluetooth when not in use, close background apps, and limit usage of power-intensive applications.
Screen is black or won't turn on	Ensure the tablet is charged. Connect it to the charger and wait a few minutes, then try powering it on. If it still doesn't respond, perform a force restart.

Factory Reset

A factory reset will erase all data on your tablet and restore it to its original factory settings. Back up important data before proceeding.

1. Go to **Settings > System > Reset options**.
2. Select **Erase all data (factory reset)**.
3. Confirm your decision when prompted.

SPECIFICATIONS

Feature	Detail
Model Name	CWOWDEFU Kids Tablet 10 inch Pro
Operating System	Android 14.0
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 pixels
Processor	Octa-core 2.0 GHz (Allwinner)
RAM	8 GB
Internal Storage	128 GB
Expandable Storage	Up to 1 TB (via microSD card)
Wireless Connectivity	Wi-Fi 802.11ax (Wi-Fi 6), Bluetooth 5.0
Battery Capacity	6000 mAh
Battery Life (Standby)	Up to 300 Hours
Charging Port	USB Type-C (supports PD fast charging)
Cameras	Front: 5MP, Rear: 8MP
Dimensions (LxWxH)	10.45 x 6.3 x 0.35 inches
Item Weight	1.21 pounds




Image: A schematic showing the tablet's powerful Allwinner A523 Octa-Core 2.0GHz processor and 8GB RAM, indicating strong data processing capabilities for smooth operation.

WARRANTY AND SUPPORT

Warranty Information

Your CWOWDEFU Kids Tablet 10 inch Pro is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage duration and claim procedures. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact CWOWDEFU customer support. Contact information can typically be found on the official CWOWDEFU website or on the warranty card.

© 2025 CWOWDEFU. All rights reserved.

Related Documents - Kids Tablet 10 inch Pro

	<p>CWOWDEFU F10W Android Tablet User Manual</p> <p>Comprehensive user manual for the CWOWDEFU F10W Android Tablet, covering setup, basic settings, features, troubleshooting, and technical specifications.</p>
	<p>CWOWDEFU KIDS Tablet 10.1" User Manual & Instructions</p> <p>Download the official CWOWDEFU KIDS Tablet 10.1" user manual. Get step-by-step instructions for setup, software overview, managing Kid's Place, and troubleshooting for your CWOWDEFU kids tablet.</p>
	<p>CWOWDEFU HY300 LCD LED Projector: Specifications and Features</p> <p>Explore the CWOWDEFU HY300, an LCD LED projector with HDTV 1280x720 resolution, 1500:1 contrast, and 30,000-hour LED life. Features include integrated media player, Wi-Fi, Android 11.0, and keystone correction for versatile home use.</p>
	<p>Headwolf FPad User Guide</p> <p>User guide for the Headwolf FPad tablet, covering setup, features, network settings, troubleshooting, and safety information.</p>

	<p>Blackview Tab 7 WiFi Tablet User Guide</p> <p>This guide provides instructions on using the Blackview Tab 7 WiFi Tablet, including setup, language settings, safety precautions, and maintenance.</p>
	<p>Blackview Rugged Tablet User Manual and Safety Information</p> <p>Comprehensive guide for the Blackview Rugged Tablet, covering device overview, setup instructions for SIM cards and hand straps, basic functions, safety precautions, and maintenance tips.</p>