

[manuals.plus](#) /

› [Bose](#) /

› [Bose SoundLink Flex Bluetooth Speaker \(2nd Gen\) Instruction Manual](#)

Bose 887612-0200

Bose SoundLink Flex Bluetooth Speaker (2nd Gen) Instruction Manual

Model: 887612-0200

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Bose SoundLink Flex Bluetooth Speaker (2nd Gen). Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: The Bose SoundLink Flex Bluetooth Speaker (2nd Gen) in Blue Dusk, showcasing its compact and durable design.

2. WHAT'S IN THE Box

Verify that all items are present before proceeding with setup:

- Bose SoundLink Flex (Gen. 2) Bluetooth Speaker
- USB Type-C cable

3. PRODUCT FEATURES

The Bose SoundLink Flex (2nd Gen) offers a range of features designed for portable, high-quality audio:

- **High-Fidelity Audio:** Delivers clear, balanced sound with deep bass.
- **Durable Design:** IP67 rated for water and dust resistance, with a tough silicone-wrapped body. It also floats.
- **Long Battery Life:** Up to 12 hours of playtime at typical listening levels.
- **PositionIQ Technology:** Automatically adjusts sound based on the speaker's orientation for optimal audio.
- **Advanced Bluetooth 5.3:** Ensures a stable connection up to 30 feet and supports multipoint technology for connecting to multiple devices.
- **Stereo & Party Mode:** Link two compatible Bose speakers for stereo sound or party mode.
- **Built-in Microphone:** For hands-free calls and voice assistant activation.
- **Utility Loop:** Integrated nylon loop for easy portability and attachment.



Image: Top view of the speaker highlighting the control buttons and the integrated utility loop.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB Type-C cable to connect the speaker to a USB power source. The battery indicator lights will show charging status.



Image: Close-up of the speaker's side, showing the USB-C charging port.

4.2 Powering On/Off

- To power on, press the **Power button** (💡).
- To power off, press and hold the **Power button** until the speaker turns off.

4.3 Bluetooth Pairing

1. Power on the speaker.
2. The speaker will automatically enter pairing mode if it's the first time using it, or if no device is connected. The Bluetooth indicator light will blink blue.
3. On your device (smartphone, tablet, computer), enable Bluetooth and select "Bose SoundLink Flex" from the list of available devices.
4. Once connected, the speaker will announce "Connected to [Device Name]" and the Bluetooth indicator light will glow solid white.
5. To pair a new device, press and hold the **Bluetooth button** (💡) until the Bluetooth indicator blinks blue.

5. OPERATING THE SPEAKER

5.1 Controls

The top panel of the speaker features intuitive controls:

- **Power Button:** Turns the speaker on/off.
- **Volume Up/Down:** Adjusts the playback volume.
- **Multi-function Button:**
 - Press once to Play/Pause.
 - Press twice to skip forward.
 - Press three times to skip backward.
- **Bluetooth Button:** Initiates Bluetooth pairing mode.
- **Microphone:** For hands-free calls and voice assistant activation.

5.2 PositionIQ Technology

The SoundLink Flex automatically detects its orientation (standing, lying flat, or hanging) and optimizes the audio output to ensure consistent, high-quality sound in any position.



Image: A person holding the Bose SoundLink Flex, illustrating its compact size and portability.

5.3 Stereo and Party Mode

For an enhanced audio experience, you can link two compatible Bose Bluetooth speakers:

- **Stereo Mode:** Designates one speaker as the left channel and the other as the right channel for true stereo separation.
- **Party Mode:** Plays the same audio simultaneously through both speakers for a louder, more expansive sound.

Refer to the Bose Connect app for detailed instructions on setting up Stereo or Party Mode.



Image: Two Bose SoundLink Flex speakers held side-by-side, demonstrating the ability to pair them for a larger sound experience.

6. MAINTENANCE

6.1 Cleaning

To clean the speaker, use a soft, damp cloth. Do not use any solvents, chemicals, or cleaning sprays. Ensure the USB-C port cover is securely closed before cleaning or exposing to water.

6.2 Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to maintain battery health.

7. TROUBLESHOOTING

Problem	Solution

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
Cannot pair with a Bluetooth device.	<ul style="list-style-type: none"> Ensure Bluetooth is enabled on your device. Move the speaker closer to your device. Press and hold the Bluetooth button on the speaker to enter pairing mode. Clear the Bluetooth device list on your device and try again.
No sound or low volume.	<ul style="list-style-type: none"> Increase the volume on both the speaker and your connected device. Ensure the speaker is properly connected via Bluetooth. Check for obstructions between the speaker and your device.
Audio quality is poor.	<ul style="list-style-type: none"> Move the speaker closer to your device. Avoid placing the speaker near metal objects or other wireless devices that may cause interference. Ensure the speaker's battery is not critically low.

8. SPECIFICATIONS

Feature	Detail
Model Name	Bose SoundLink Flex Portable Speaker 2nd Gen
Model Number	887612-0200
Connectivity	Bluetooth 5.3
Wireless Range	Up to 30 feet (9 meters)
Battery Life	Up to 12 hours (typical listening levels)
Battery Type	1 Lithium Ion battery (included), 3100 mAh
Charging Port	USB Type-C
Water & Dust Resistance	IP67 rated
Dimensions (D x W x H)	3.56" x 7.93" x 2.06" (9.04 cm x 20.14 cm x 5.23 cm)
Weight	1.3 pounds (0.59 kg)
Material	Plastic, Silicone
Color	Blue Dusk

9. OFFICIAL PRODUCT VIDEOS

Bose SoundLink Flex Speaker Review

Your browser does not support the video tag.

Video: A detailed review of the Bose SoundLink Flex speaker, highlighting its features and performance.

Bose SoundLink Flex Unboxing and First Impressions

Your browser does not support the video tag.

Video: An unboxing and initial impressions video of the Bose SoundLink Flex, demonstrating its packaging and physical attributes.

Bose SoundLink Flex Features Overview

Your browser does not support the video tag.

Video: A brief overview of the key features of the Bose SoundLink Flex speaker, including its portability and sound quality.

10. WARRANTY AND SUPPORT

The Bose SoundLink Flex Bluetooth Speaker (2nd Gen) comes with a limited warranty. For detailed warranty information, product registration, and technical support, please visit the official Bose website or contact Bose customer service.

Online Support: www.bose.com/support