

EDISLIVE EDIS6088NK60W

EDISLIVE Modern Wave LED Vanity Light Fixture

Model: EDIS6088NK60W

- Safety Information
- Package Contents
- Specifications
- Setup & Installation
- Operating
- Instructions
- Maintenance
- Troubleshooting
- Warranty & Support

Product Overview

The EDISLIVE Modern Wave LED Vanity Light is a contemporary lighting fixture designed to enhance the aesthetic and functionality of various indoor spaces. Its unique curved-wave design and integrated LED technology provide efficient and adjustable illumination. This fixture is suitable for bathrooms, bedrooms, and other areas requiring stylish and practical lighting.



Exquisite Wave Lamp Body

Figure 1: Close-up of the EDISLIVE Modern Wave LED Vanity Light.

Safety Information

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage.

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installing or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring installations.
- Ensure the mounting surface is structurally sound and can support the weight of the fixture.
- Do not attempt to alter the fixture in any way. Any alterations may void the warranty and create a safety hazard.
- This fixture is designed for indoor use only. Do not expose to water or moisture.
- The LED light source is integrated and not replaceable. Do not attempt to disassemble the LED module.

Package Contents

Carefully unpack the fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact customer service for assistance.

- LED Vanity Light Fixture (1 unit)
- Mounting Bracket (1 unit)
- Mounting Hardware (screws, wire nuts)
- Instruction Manual (this document)

Specifications

Brand	EDISLIVE
Model Number	EDIS6088NK60W
Color	Gold-Curve Warm
Material	Iron, Acrylic
Style	Modern
Light Fixture Form	Vanity
Room Type	Bathroom, Bedroom
Product Dimensions	23.6"L x 2.8"W x 4.7"H (60cm L x 7cm W x 12cm H)
Power Source	AC
Installation Type	Flush Mount
Special Feature	Dimmable
Light Source Type	LED
Finish Type	Polished
Shade Material	Acrylic
Number of Light Sources	1
Voltage	120 Volts
Light Color	Warm (3000K)
Wattage	15 Watts
Brightness	90 Lumens
Average Life	50,000 Hours
Item Weight	2.29 pounds




Figure 2: Product Dimensions.

Setup & Installation

This fixture is designed for hardwired installation. It can be mounted horizontally or vertically to suit your preference. Always ensure power is disconnected at the circuit breaker before beginning installation.

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Clear the work area and gather necessary tools (screwdriver, wire strippers, electrical tape, etc.).
2. **Remove Old Fixture (if applicable):** Carefully remove any existing light fixture, ensuring all wires are disconnected.
3. **Install Mounting Bracket:** Attach the provided mounting bracket to the junction box in the wall using the screws. Ensure the bracket is securely fastened.
4. **Connect Wiring:** Connect the fixture's wires to the corresponding house wires using wire nuts.
 - Connect the **black** wire (Live) from the fixture to the **black** wire (Live) from the junction box.
 - Connect the **white** wire (Neutral) from the fixture to the **white** wire (Neutral) from the junction box.
 - Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the junction box.

Ensure all connections are secure and covered with wire nuts.

5. **Mount the Fixture:** Carefully tuck all wires into the junction box. Align the fixture with the mounting bracket and secure it in place using the provided screws.
6. **Restore Power:** Once the fixture is securely mounted, restore power at the main circuit breaker.

Note: For detailed visual instructions, refer to the installation guide included in your package. Professional installation is recommended if you are unsure about any steps.

Operating Instructions

The EDISLIVE Modern Wave LED Vanity Light is designed for simple operation via a standard wall switch. This fixture is dimmable, allowing you to adjust the light intensity to your preference.

1. **Turning On/Off:** Use your existing wall switch to turn the light fixture on or off.
2. **Dimming Function:** To utilize the dimming feature, a compatible wall dimmer switch (not included) must be installed. Once installed, adjust the dimmer switch to achieve the desired brightness level. The fixture supports brightness adjustment from 10% to 100%.

3. **Color Temperature:** This fixture provides a warm white light at 3000K, offering a cozy and inviting ambiance.



Figure 3: Dimmable Operation with an external dimmer switch.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your LED vanity light fixture.

- **Cleaning:** To clean the fixture, first ensure the power is turned off. Use a soft, dry cloth to wipe down the surfaces. Avoid using abrasive cleaners, solvents, or polishes as they may damage the finish or acrylic shade.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician or contact customer service.
- **LED Care:** The integrated LED light source does not require bulb replacement. Do not attempt to open or modify the LED module.

Troubleshooting

If you experience issues with your EDISLIVE LED Vanity Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	• Power is off at the circuit breaker or wall switch. • Loose wire connections. • Faulty fixture.	• Ensure power is on. • Check wire connections (with power off). • Contact customer service.
Light flickers or dims unexpectedly.	• Incompatible dimmer switch. • Loose wire connections. • Voltage fluctuations.	• Ensure a compatible LED dimmer is used. • Check wire connections (with power off). • Consult an electrician.
Light is not bright enough.	• Dimmer setting is too low. • Fixture is not suitable for the room size.	• Adjust dimmer to maximum brightness. • Consider additional lighting if needed.

If the problem persists after trying these solutions, please contact EDISLIVE customer service.

Warranty & Support

The EDISLIVE Modern Wave LED Vanity Light comes with a Limited Warranty, as specified by the manufacturer. For detailed warranty terms and conditions, please refer to the documentation provided with your purchase or contact EDISLIVE customer service.

Customer Service: If you have any questions, require technical assistance, or need to report an issue with your product, please reach out to the EDISLIVE customer service team. Contact information can typically be found on the product packaging or the official EDISLIVE website.

"If any problems of this light, please feel free to reach out to EDISLIVE customer service team."

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question