

[Manuals.plus](#) /

› [umeiluce](#) /

› umeiluce mys515 31.5 Inch 5-Light Flush Mount Ceiling Fixture Instruction Manual

umeiluce mys515

umeiluce 31.5 Inch 5-Light Flush Mount Ceiling Fixture Instruction Manual

Model: mys515 | Brand: umeiluce

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your umeiluce 31.5 Inch 5-Light Flush Mount Ceiling Fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.

SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical fixtures to reduce the risk of fire, electric shock, and personal injury.

- **WARNING:** To avoid electric shock, disconnect power at the circuit breaker or fuse box before installation.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about the installation process.
- Use only the specified bulb type and wattage.
- Do not install this fixture in wet locations. It is designed for indoor use only.
- Ensure the fixture is securely mounted to a structural part of the building.

PACKAGE CONTENTS

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, contact customer service before proceeding.

- Ceiling light fixture (1)
- Mounting hardware kit (1)
- Instruction manual (1)



Image: Contents of the umeiluce ceiling light package, including the fixture and installation components.

SPECIFICATIONS

Feature	Specification
Brand	umeiluce
Model Number	mys515
Dimensions (L x W x H)	31.5"L x 10.2"W x 8.7"H
Material	Metal (Iron)
Number of Lights	5
Bulb Base	E26
Max Wattage per Bulb	60 Watts
Voltage	110 Volts (AC)
Dimmable	Yes (with compatible bulbs and dimmer switch, not included)
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor Only

INSTALLATION INSTRUCTIONS

Before you begin, ensure the power is turned off at the circuit breaker. This fixture is designed for simple and quick installation.

1. **Prepare for Installation:** Turn off the main power supply at the circuit breaker. Clear the work area and gather necessary tools (screwdriver, wire strippers, electrical tape).
2. **Mount the Crossbar:** Attach the mounting crossbar to the junction box in the ceiling using the provided screws. Ensure it is secure.
3. **Wire the Fixture:** Connect the fixture's wires to the corresponding house wires. Connect the black wire (live) to the black wire, the white wire (neutral) to the white wire, and the ground wire to the ground wire. Secure connections with wire nuts and electrical tape.
4. **Attach the Fixture:** Carefully lift the fixture and align the mounting holes on the fixture with the screws on the crossbar. Secure the fixture to the crossbar using the provided nuts or screws.
5. **Install Bulbs:** Screw five E26 base bulbs (max 60W, not included) into the sockets.
6. **Restore Power:** Once the installation is complete and all connections are secure, restore power at the circuit breaker.



Image: The umeiluce 5-Light Flush Mount Ceiling Fixture installed, providing ample illumination.

Installation Video Guide

Your browser does not support the video tag.

Video: This video demonstrates the umeiluce 5-Light Farmhouse Rustic Ceiling Light installed in a kitchen island setting, showcasing its design and illumination.

OPERATING INSTRUCTIONS

To operate the light fixture, simply use the wall switch connected to the circuit. If you have installed dimmable E26 bulbs and a compatible dimmer switch (not included), you can adjust the light intensity to your preference.

MAINTENANCE

To maintain the appearance and functionality of your fixture, follow these guidelines:

- Always disconnect power before cleaning.
- Wipe the fixture with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- Regularly check for loose connections or damaged wiring.

TROUBLESHOOTING

If you experience issues with your light fixture, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the power is on at the circuit breaker.
 - Ensure bulbs are screwed in tightly and are not burnt out.
 - Verify all wire connections are secure.
- **Flickering lights:**
 - Ensure bulbs are compatible with the fixture and any dimmer switch used.
 - Check for loose wire connections.
- **Dimming not working:**
 - Confirm that you are using dimmable bulbs and a compatible dimmer switch.
 - Check the dimmer switch wiring.

WARRANTY AND SUPPORT

This umeiluce product comes with a **1-year limited manufacturer warranty**. For warranty claims, technical support, or any questions regarding your product, please contact umeiluce customer service. Keep your purchase receipt as proof of purchase.