

[Manuals.plus](#) /

› [Mytrix](#) /

› Mytrix Sakura Wireless Gaming Headset User Manual

Mytrix GL-553

Mytrix Sakura Wireless Gaming Headset User Manual

Model: GL-553 | Brand: Mytrix

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Mytrix Sakura Wireless Gaming Headset. Designed for an immersive audio experience, this headset features 50mm drivers, 7.1 surround sound, and versatile connectivity options for various gaming platforms.

WHAT'S IN THE BOX

- Mytrix Sakura Wireless Gaming Headset
- 2.4GHz USB Transmitter
- 3.5mm Audio Cable
- Type-C Charging Cable
- User Manual



Image: The Mytrix Sakura Wireless Gaming Headset displayed with its accompanying accessories, including the USB transmitter, 3.5mm audio cable, and Type-C charging cable.

PRODUCT FEATURES

Superb Audio Quality

The headset is equipped with 50mm drivers and supports 7.1 surround sound technology, providing precise audio cues for an enhanced gaming experience. This allows for accurate sound localization, crucial for competitive gaming, and delivers an immersive audio experience for movies and music.

3D STEREO SURROUND

50MM DRIVERS
for immersive enjoyment
games/music/movies



Image: An exploded view illustrating the 50mm drivers within the headset, emphasizing the stereo surround sound capability.

Noise-Cancelling Microphone

The flexible and detachable microphone features noise-cancelling technology, filtering out ambient sounds to ensure clear voice pickup. This facilitates high-quality communication with teammates, friends, and family during gameplay or calls. The microphone is 360° retractable for flexible positioning and can be detached for easy transport.

Your browser does not support the video tag.

Video: An overview of the Mytrix Sakura Wireless Gaming Headset, showcasing its design and key features, including the microphone.

Comfort and Design

The headset features superior soft and breathable memory foam ear cushions and an adjustable headband, designed to minimize sweat and heat during extended use. The skin-friendly durable leather material ensures comfort for long gaming sessions. Pink Sakura LED lights on the earcups enhance the aesthetic and gaming atmosphere.

LONG-LASTING BATTERY LIFE

The headset turns on the default lighting mode. If you need a longer battery life, please turn off the lighting.



Image: Detailed view of the headset's comfortable design elements, including the breathable memory foam earcups and adjustable headband.

Long-lasting Battery Life

Enjoy up to 45 hours of continuous playtime on a single charge. The headset fully charges in approximately 3 hours. For extended battery life, the LED lighting can be turned off.

MULTI-PLATFORM COMPATIBILITY



MULTI-CONNECTION METHODS



2.4G USB Transmitter



Bluetooth Wireless



3.5mm Audio Cable-Wired



Image: Visual representation of the headset's battery performance, showing 45+ hours of gaming time and a 3-hour charging time.

SETUP & CONNECTION

Multi-Platform Compatibility

This gaming headset supports dual wireless connection modes (Bluetooth and 2.4GHz USB) and a 3.5mm wired connection, making it compatible with a wide range of devices including PS5, PS4, Switch, PC, Laptop, Tablet, iPad, iOS, and Mobile Phones. Xbox Series X/S controllers are supported via the 3.5mm cable (older versions may require an additional Microsoft adapter, not included).

STYLISH AND COMFORTABLE DESIGN



Image: An illustration detailing the headset's multi-platform compatibility and connection methods.

2.4GHz USB Wireless Connection (for PS5, PC, Switch Docked)

1. Ensure the headset is fully charged.
2. Insert the 2.4GHz USB transmitter into an available USB port on your PS5, PC, or Switch dock.
3. Turn on the headset by holding the Play/Pause button. The headset will default to 2.4GHz connection mode.
4. The headset should automatically connect to the transmitter. Confirm audio output settings on your device if necessary.

Bluetooth Wireless Connection (for Mobile, Tablet, Switch Handheld)

1. Ensure the headset is fully charged.
2. Turn on the headset by holding the Play/Pause button.
3. Long-press the "M" button for 3 seconds to switch to Bluetooth mode. The headset will enter pairing mode.
4. On your device (mobile phone, tablet, Nintendo Switch), go to Bluetooth settings and select "G900" (or similar name) from the list of available devices to pair.
5. Once paired, the headset will indicate a successful connection.

Your browser does not support the video tag.

Video: Demonstrates connection procedures for PS4/PS5 and Nintendo Switch, including both 2.4GHz USB and Bluetooth methods.

3.5mm Wired Connection (for Xbox, PS4/PS5 Controller, PC/Laptop)

- 1. Connect one end of the 3.5mm audio cable to the headset's 3.5mm jack.
- 2. Connect the other end of the 3.5mm audio cable to the 3.5mm port on your Xbox controller, PS4/PS5 controller, PC, or laptop.
- 3. Note: When using a wired connection, only audio output is supported. The volume button on the headset will not function, and the microphone will not work. The LED lights on the earcups will also be off.

OPERATING INSTRUCTIONS (CONTROLS)

Control	Function
Microphone Button (M) - Single Press	Microphone On/Off
Microphone Button (M) - Double Press	LED Lights On/Off
Microphone Button (M) - Long Press (3 seconds)	Switch between Bluetooth and 2.4G modes
Volume + Button - Single Press	Increase Volume
Volume + Button - Long Press (3 seconds)	Next Song
Play/Pause Button - Single Press	Play/Pause Audio
Play/Pause Button - Long Press (3 seconds)	Turn Headset On/Off
Volume - Button - Single Press	Decrease Volume
Volume - Button - Long Press (3 seconds)	Previous Song

MAINTENANCE & CARE

- Clean the headset regularly with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not expose the headset to water or excessive moisture.
- Handle the microphone and cables with care to prevent damage.
- When charging, ensure the headset is turned off. The 2.4G function is not available during charging, and only 3.5mm wired connection is supported.

TROUBLESHOOTING

No Sound / Disconnection Issues

- Ensure the headset is fully charged.
- Verify the correct connection mode (2.4GHz or Bluetooth) is selected by long-pressing the "M" button.
- For 2.4GHz connection, ensure the USB transmitter is securely plugged into the device and the device's audio output is set to the headset.
- For Bluetooth connection, ensure the headset is paired and connected in your device's Bluetooth settings. Try unpairing and re-pairing if issues persist.
- If using a 3.5mm wired connection, confirm the cable is fully inserted into both the headset and the device. Remember that the headset's volume controls and microphone do not function in wired mode.

Microphone Not Working

- Ensure the microphone is securely attached to the headset.
- Press the Microphone button (M) once to toggle the microphone on.
- Check your device's audio input settings to ensure the headset microphone is selected.
- The microphone does not work when the headset is connected via the 3.5mm wired cable.

Headset Automatically Shuts Down

- The headset will automatically shut down when charging. This is normal operation.

SPECIFICATIONS

Feature	Detail
Model Name	Gaming Headset
Item Model Number	GL-553
Connectivity Technology	Wireless (Bluetooth, 2.4G Receiver), Wired (3.5 mm Jack)
Audio Driver Type	Dynamic Driver (50mm)
Battery Life	Up to 45 Hours
Charging Time	3 Hours
Audio Latency	<20ms (2.4GHz)
Ear Placement	Over Ear
Color	Pink
Item Weight	14.4 ounces
Product Dimensions	7 x 3.5 x 8 inches

WARRANTY & SUPPORT

For warranty information and technical support, please refer to the official Mytrix website or contact their customer service directly. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question