Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM B0D6YX8J5S

JOYROOM Magnetic Suction Cup Phone Mount User Manual

Product Overview

The JOYROOM Magnetic Suction Cup Phone Mount is designed to provide a versatile and hands-free solution for holding your smartphone on various smooth surfaces. It features both magnetic and suction cup attachment methods, making it suitable for a wide range of applications.



Figure 1: Hands-free use of the phone mount for activities like makeup.



Figure 2: Detailed view of the mount's 18 strong suction cups and magnetic surface.

Setup Instructions

1. **Prepare Your Phone:**

- If your phone or phone case is MagSafe compatible (e.g., iPhone 12/13/14/15 series), the mount will attach directly via magnetism.
- For other Android phones or non-MagSafe cases, use the provided metal ring. Clean the back of your phone or case thoroughly with the included wipes (wet then dry). Use the alignment tool to accurately position and adhere the metal ring to ensure magnetic compatibility.

2. **Prepare the Mounting Surface:**

- Ensure the surface where you intend to attach the mount is clean, smooth, and dry. Compatible surfaces include mirrors, windows, metal, and tiles.
- If the suction cups feel less sticky due to oil or dust, wash them with water or an alcohol wipe and allow them to dry before use.

3. **Attach the Mount:**

- Press the suction cup side of the mount firmly against the prepared surface. Apply pressure to expel any air from under the suction cups to maximize grip.
- Once the mount is securely attached to the surface, align your phone (with its MagSafe compatibility or attached metal ring) to the magnetic side of the mount. It will snap into place.




Figure 3: Illustration of compatible surfaces and phone attachment methods.




Figure 4: Demonstrates MagSafe compatibility and the use of metal rings for other devices.



Figure 5: Visual guide for proper surface preparation and mount application.

Operating Instructions

Attaching and Detaching Your Phone

- To attach your phone, simply bring the back of your MagSafe-compatible phone or case (or a phone/case with the metal ring) close to the magnetic side of the mount. The strong magnets will securely hold your phone in place.
- To detach your phone, gently pull it away from the magnetic surface. The mount is designed for quick installation and reinstallation, allowing you to easily remove your phone for wireless charging or other accessories.

Using the Suction Cup Grip

- The mount features 18 strong silicone suction cups that provide a stable grip on slick, non-porous surfaces.
- When applying the mount to a surface, press firmly to ensure all air is expelled from the suction cups. This maximizes the suction effect and prevents slipping.
- The soft silicone grip can also function as a comfortable handle, helping to secure your phone in hand and making it easier to pull the mount off surfaces.

Versatile Usage

The JOYROOM Magnetic Suction Cup Phone Mount allows for hands-free use in various scenarios:

- **Content Creation:** Attach your phone to mirrors or windows for hands-free selfies, video calls, or recording content for social media platforms like TikTok and Instagram.
- **Daily Routines:** Use it in the kitchen to follow recipes while cooking, in the bathroom for makeup tutorials or entertainment while showering, or at the gym for watching shows on a treadmill.
- **Orientation:** The mount supports both horizontal and vertical phone orientations, adapting to your specific usage needs.

Your browser does not support the video tag.

Video 1: Official JOYROOM demonstration of the magnetic suction cup phone mount's features and various applications.

Your browser does not support the video tag.

Video 2: A short official video showcasing the quick magnetic attachment and suction capabilities of the mount.

Your browser does not support the video tag.

Video 3: Another brief official video demonstrating the magnetic suction phone mount in action.



Figure 6: Examples of versatile and reliable use cases for the phone mount.

Maintenance

To ensure optimal performance and longevity of your JOYROOM Magnetic Suction Cup Phone Mount, follow these maintenance guidelines:

- **Cleaning Suction Cups:** Over time, oil from hands and dust can reduce the stickiness of the suction cups. To restore their grip, simply wash the silicone suction cups with water or an alcohol wipe. Allow them to air dry completely before reuse.
- **Storage:** When not in use, store the mount in a clean, dry place to prevent dust accumulation on the suction cups.

Troubleshooting

- **Mount Not Sticking:**
  - Ensure the mounting surface is completely clean, smooth, and dry. Any residue, dust, or unevenness can prevent proper suction.
  - Press the mount firmly against the surface, applying pressure to expel all air from the suction cups.
  - Clean the suction cups as described in the Maintenance section.
- **Phone Not Attaching Magnetically:**
  - Verify that your phone or case is MagSafe compatible.
  - If using a non-MagSafe phone/case, ensure the metal ring is correctly installed and aligned on the back of your device.

Specifications

Brand	JOYROOM
Model (ASIN)	B0D6YX8J5S
Color	White
Material	Plastic
Grip Type	Phone Suction Magnetic Grip
Special Feature	Hands-Free
Item Weight	2.39 ounces
Package Dimensions	5.04 x 2.76 x 0.75 inches

Warranty & Support

Each JOYROOM Magnetic holder product undergoes rigorous quality control testing. For any inquiries or assistance, please feel free to contact the JOYROOM support team. Specific warranty duration details are not provided in this manual; please refer to your purchase documentation or the official JOYROOM website for comprehensive warranty information.

© 2024 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6YX8J5S

More documents and user manuals: **https://manuals.plus/**