Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VIXOLYN H03

VIXOLYN Air Tracker (Model H03) User Manual

Compatible with Apple Find My

1. Introduction

The VIXOLYN Air Tracker (Model H03) is a compact item finder designed to help you locate your personal belongings using the Apple Find My network. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.



Image 1.1: The VIXOLYN Air Tracker can be attached to keys, backpacks, pet collars, and luggage for tracking.

2. What's Included

Your VIXOLYN Air Tracker package includes the following items:

- VIXOLYN Air Tracker (Model H03) x 2
- Silicone Protective Case x 2
- Keychain x 2
- Lithium Metal Battery (pre-installed) x 2



Image 2.1: Two VIXOLYN Air Trackers with their protective cases and keyrings.

3. Key Features

- **Apple Find My Compatibility:** Seamlessly integrates with the Apple Find My network for tracking on iOS devices.
- **Audible Alert:** Emits a sound up to 100 decibels to help locate items within Bluetooth range.
- **Left-Behind Notifications:** Receive alerts on your iOS device if you leave your tracked item behind.
- **IP67 Water Resistance:** Designed to withstand splashes and brief immersion in water.
- **Data Privacy:** MFi certified chip ensures location data is anonymous and encrypted.
- **Durable Design:** Includes a protective silicone case and keychain for secure attachment.



Image 3.1: The tracker features robust privacy settings and IP67 water resistance.

4. Setup Guide

Follow these steps to pair your VIXOLYN Air Tracker with your Apple iOS device:

1. Ensure Bluetooth is enabled on your iOS device.
2. Open the **Find My** application on your iOS device.
3. Navigate to the **Items** tab.
4. Tap the **+** icon, then select **Add Other Item**.
5. Press the button on your VIXOLYN Air Tracker to activate it. You should hear a beep.
6. Your iOS device will detect the "Finder tag". Tap **Connect**.
7. Follow the on-screen prompts to name your item and choose an emoji.
8. Confirm the connection. Your VIXOLYN Air Tracker is now paired and ready for use.



Image 4.1: Visual steps for connecting your VIXOLYN Air Tracker to the Find My app.

5. Operating Instructions

5.1 Finding Nearby Items

When your VIXOLYN Air Tracker is within Bluetooth range (approximately 50m/164ft), you can use the Find My app to play a sound:

1. Open the **Find My** app.
2. Select the VIXOLYN Air Tracker from your **Items** list.
3. Tap **Play Sound**. The tracker will emit a loud sound (up to 100dB) to help you locate it.
4. Tap **Stop Sound** once found.



Image 5.1: Using the Find My app to play a sound for nearby items and view location on a map for far away items.

5.2 Finding Far Away Items

If your VIXOLYN Air Tracker is outside Bluetooth range, the Find My network can help you locate it:

1. Open the **Find My** app.
2. Select the VIXOLYN Air Tracker from your **Items** list.
3. The app will display the item's last known location on a map, or its current location if detected by another Apple device on the Find My network.
4. You can get directions to the item's location directly from the app.

5.3 Left-Behind Notifications

To receive alerts when you leave an item behind:

1. In the **Find My** app, select your VIXOLYN Air Tracker.
2. Under the **Notifications** section, enable **Notify When Left Behind**.

3. You will receive a notification on your iOS device within 10 minutes if the tracker moves out of Bluetooth range.




Image 5.2: An example of a 'Left Behind' notification on an iPhone.

5.4 Lost Mode

If your item is lost, you can activate Lost Mode:

1. In the **Find My** app, select your VIXOLYN Air Tracker.
2. Scroll down to **Lost Mode** and tap **Enable**.
3. Follow the instructions to enter a contact phone number or email address. If someone finds your item, they can use an NFC-enabled smartphone to view your contact information.

6. Maintenance

6.1 Battery Replacement

The VIXOLYN Air Tracker uses a replaceable Lithium Metal battery (CR2032). To replace the battery:

1. Gently twist the back cover of the tracker counter-clockwise to open it.
2. Remove the old CR2032 battery.
3. Insert a new CR2032 battery with the positive (+) side facing up.
4. Align the back cover and twist clockwise to secure it.

Note: Dispose of used batteries responsibly according to local regulations.

6.2 Cleaning and Care

- Wipe the tracker with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials.
- The silicone protective case can be washed with mild soap and water. Ensure it is completely dry before reattaching the tracker.

6.3 Water Resistance

The VIXOLYN Air Tracker has an IP67 rating, meaning it is resistant to splashes, water, and dust. It can withstand immersion in up to 1 meter of water for 30 minutes. However, it is not recommended for prolonged submersion or use during water sports.

7. Troubleshooting

- **Tracker not connecting or pairing:**
  - Ensure Bluetooth is enabled on your iOS device.
  - Verify the tracker's battery is not depleted. Replace if necessary.
  - Make sure the tracker is powered on (press the button to check for a beep).
  - Try restarting your iOS device and repeating the pairing process.
- **Cannot hear the tracker's sound:**
  - Ensure the tracker is within Bluetooth range of your iOS device.
  - Check that your phone's volume is turned up.
  - The sound may be muffled if the tracker is deeply embedded in an item.
- **Left-Behind Notifications not working:**
  - Verify that "Notify When Left Behind" is enabled for the tracker in the Find My app.
  - Check your iOS device's notification settings to ensure Find My app notifications are allowed.
  - Ensure your device has a stable internet connection.

8. Specifications

Feature	Detail
Model Number	H03
Dimensions	1.26 x 0.35 x 0.35 inches
Item Weight	0.37 ounces
Connectivity	Bluetooth
Compatible Devices	iOS Devices (Apple Find My App)

Feature	Detail
Battery Type	1 x Lithium Metal (CR2032)
Water Resistance	IP67
Material (Case)	Silicone Protective Case

9. Warranty Information

VIXOLYN products are covered by a manufacturer's warranty. For specific details regarding your warranty period and terms, please refer to the product packaging or contact VIXOLYN customer support.

10. Support

For further assistance, technical support, or to provide feedback, please visit the official VIXOLYN website or contact our customer service team through the contact information provided on your product packaging or purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6YXFMW8

More documents and user manuals: **https://manuals.plus/**