

Tefal FV5772E2

Tefal Easygliss Plus Steam Iron FV5772E2 User Manual

MODEL: FV5772E2

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Tefal Easygliss Plus Steam Iron FV5772E2. Please read all instructions carefully before using the appliance and retain this manual for future reference.

The Tefal Easygliss Plus steam iron is designed for effective garment care, featuring a powerful 2700W heating element, a Durilium Airglide soleplate, and various steam functions to simplify your ironing tasks.

2. Safety Instructions

- Always ensure the voltage indicated on the iron matches your mains voltage.
- Do not leave the iron unattended while it is switched on or connected to the mains.
- Keep the iron and its cord out of reach of children and persons with reduced physical, sensory, or mental capabilities.
- Never immerse the iron, power cord, or plug in water or any other liquid.
- Do not operate the iron if it has been dropped, if there are visible signs of damage, or if it is leaking.
- Always place the iron on a stable, heat-resistant surface when resting.
- Unplug the iron from the electrical outlet before filling with water, cleaning, or after each use.
- The soleplate can become extremely hot and cause burns. Avoid direct contact.
- Use caution when turning the iron upside down, as there may be hot water in the reservoir.

3. Product Components

Familiarize yourself with the main parts of your Tefal Easygliss Plus Steam Iron:

- **A.** Water filling inlet
- **B.** Spray nozzle

- **C.** Steam control (Dry/Steam/Max Steam)
- **D.** Spray button
- **E.** Steam boost button
- **F.** Temperature control dial
- **G.** Self-clean button (if applicable)
- **H.** Water tank
- **I.** Durilium Airglide Soleplate
- **J.** Power cord
- **K.** Stable rest hill



Image 3.1: Overview of the Tefal Easygliss Plus Steam Iron FV5772E2. This image displays the iron from a top-front angle, highlighting its turquoise and white design, handle, water tank, and control buttons.



Image 3.2: Underside view of the Durilium Airglide soleplate. This image shows the intricate pattern of steam holes and the smooth, durable surface designed for efficient gliding.

4. Setup

4.1. Unpacking

Carefully remove the iron from its packaging. Remove any protective films or stickers from the soleplate. Retain the packaging for storage or transport.

4.2. First Use

During the first use, a small amount of smoke or a harmless odor may be produced. This is normal and will disappear after a short period. It is recommended to iron an old piece of fabric for a few minutes to remove any manufacturing residues from the soleplate.

5. Operating Instructions

5.1. Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Set the steam control to the 'Dry Ironing' position (no steam).
3. Open the water filling inlet (A).
4. Fill the water tank (H) with clean tap water up to the 'MAX' level indicator. The tank capacity is 270 ml.
5. Close the water filling inlet securely.

5.2. Temperature and Steam Settings

The iron features an Automatic Steam Setting, which adjusts the steam output based on the selected temperature for optimal results and fabric protection.

1. Plug the iron into a suitable power outlet.

2. Turn the temperature control dial (F) to the desired setting according to the fabric type (refer to garment care labels).
3. The indicator light will illuminate, indicating the iron is heating. It will turn off when the desired temperature is reached.
4. For steam ironing, ensure the steam control (C) is set to the desired steam level (e.g., 'Steam' or 'Max Steam'). For dry ironing, set it to 'Dry Ironing'.

5.3. Steam Ironing

Once the iron has reached the selected temperature, you can begin steam ironing. The continuous steam output is up to 50 g/min.



Image 5.1: The Tefal Easygliss Plus iron emitting steam during operation. This illustrates the steam function in action, showing steam being released from the soleplate.

5.4. Steam Boost

For stubborn creases or thicker fabrics, press the steam boost button (E). This provides an extra-powerful burst of steam up to 240 g/minute. Wait a few seconds between each burst to allow the iron to reheat.

5.5. Vertical Steaming

The vertical steam feature is ideal for smoothing creases from hanging garments, curtains, or delicate fabrics. Hold the iron vertically a few centimeters away from the fabric and press the steam boost button (E) repeatedly.

5.6. Spray Function

To moisten dry areas of fabric, press the spray button (D). This releases a fine mist of water from the spray nozzle (B).

5.7. Auto-Off Safety Feature

For enhanced safety and energy saving, the iron is equipped with an Auto-Off feature. If left unattended on its heel for more than 8 minutes, or flat on its soleplate for more than 30 seconds, the iron will automatically switch off. To restart, simply move the iron.

5.8. Sanitary Steam

The iron utilizes heat and steam to sanitize linens, effectively killing 99.9% of viruses, bacteria, and germs. Use the steam function as described for general steam ironing to benefit from this feature.

6. Maintenance

6.1. Cleaning the Soleplate

To maintain the gliding performance of the Durilium Airglide soleplate, clean it regularly. Ensure the iron is unplugged and completely cool. Wipe the soleplate with a damp cloth or a non-abrasive sponge. Do not use abrasive cleaners or metallic scouring pads.

6.2. Descaling (Anti-Scale Setting)

The iron has an anti-scale setting to help prevent limescale buildup. For optimal performance, perform the self-clean function periodically (refer to your iron's specific self-clean button (G) instructions if available, or consult the full product manual for detailed descaling procedures).

6.3. Storage

After each use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron upright on its stable rest hill (K) in a dry, safe place, with the cord neatly wrapped.

7. Troubleshooting

Problem	Possible Cause	Solution
Water drips from the soleplate.	Temperature is too low for steam; Anti-Drip system not activated.	Set a higher temperature suitable for steam ironing. Wait for the indicator light to go out before using steam.
No steam is produced.	Water tank is empty; Steam control is set to 'Dry Ironing'; Temperature is too low.	Fill the water tank. Set the steam control to a steam position. Increase the temperature setting.
Iron does not heat up.	Iron is unplugged; Auto-Off feature activated.	Check if the iron is properly plugged in. Move the iron to reactivate it if Auto-Off has engaged.
White flakes come out of the soleplate.	Limescale buildup.	Perform the self-clean/descaling procedure as outlined in the full product manual.

8. Specifications

- Model:** FV5772E2
- Power:** 2700 Watt
- Continuous Steam Output:** 50 g/min

- **Steam Boost:** 240 g/min
- **Water Tank Capacity:** 270 ml
- **Power Cord Length:** 2 m
- **Soleplate Technology:** Durilium Airglide (Ceramic)
- **Special Features:** Auto Shutoff, Limescale Prevention (Anti-scale setting), Vertical Steaming, Anti-Drip, Spray, Sanitary Steam
- **Color:** Turquoise
- **Item Weight:** 200 Grams (Note: This might be package weight, actual product weight may vary slightly)
- **Country Of Origin:** Egypt

9. Warranty and Support

Your Tefal Easygliss Plus Steam Iron FV5772E2 comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the official Tefal website for your region.

Related Documents - FV5772E2

	<p><u>Tefal FV49xxxx Smart Protect Steam Iron User Guide and Safety Instructions</u></p> <p>User guide for the Tefal FV49xxxx Smart Protect steam iron, covering safe operation, fabric settings (normal/eco), steam functions, Auto-Off safety, anti-calc, and maintenance. Includes detailed instructions and tips for optimal ironing.</p>
	<p><u>Tefal Easygliss Plus / Ultragliss Plus Series User Guide & Instructions</u></p> <p>Comprehensive user guide for Tefal Easygliss Plus, Ultragliss Plus, Ultraglide Plus, and Ultragliss Anti-Calc Plus steam irons. Learn how to operate, maintain, and safely use your appliance, including filling the water tank, setting temperature and steam, utilizing special features like Turbo and Eco modes, and understanding the auto-off safety function.</p>
	<p><u>Tefal Easygliss Plus Steam Iron User Guide</u></p> <p>Essential safety recommendations and usage instructions for the Tefal Easygliss Plus steam iron, covering safe operation, water usage, and troubleshooting.</p>



[TEFAL EasyGliss Eco FV5781E1: Safe Use & Operating Guide](#)

Comprehensive safety instructions, usage guidelines, and troubleshooting tips for the TEFAL EasyGliss Eco FV5781E1 steam iron, designed for domestic use.



[Tefal Ultragliss Anti-Calc FV49xxxx Steam Iron User Manual](#)

Comprehensive user guide for the Tefal Ultragliss Anti-Calc FV49xxxx steam iron. Learn about operation, features like Auto-Off and Anti-Calc, maintenance, and safety instructions.