Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lomoky 3-Light Brushed Nickel Vanity Light

Lomoky 3-Light Brushed Nickel Bathroom Vanity Light Fixture

Model: 3-Light Brushed Nickel Vanity Light

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your new Lomoky 3-Light Brushed Nickel Bathroom Vanity Light Fixture. Designed with rustproof materials and milky white glass shades, this modern fixture is a perfect addition to various rooms including bathrooms, laundry rooms, and living spaces. Please read all instructions carefully before beginning installation.



Figure 1: Lomoky 3-Light Brushed Nickel Bathroom Vanity Light Fixture.

What's in the Box

Please verify that all components are present and undamaged before proceeding with installation.

- 1 x Brushed Nickel Bathroom Light Fixture
- 3 x Milky White Glass Lampshades
- 1 x User Manual for Installation

Setup and Installation

The Lomoky vanity light fixture is designed for easy installation. All necessary mounting hardware is included. Ensure power is turned off at the circuit breaker before beginning any electrical work.

Dimensions and Components Overview




Figure 2: Product Dimensions and Bulb Compatibility. The fixture measures 18.35 inches in length, 5.5 inches in width, and 8.27 inches in height.



Figure 3: Key Components of the Light Fixture. Features include a sturdy metal plate, standard E26 ceramic sockets, and milky white glass shades.

Installation Steps

1. **Safety First:** Before starting, turn off the power to the light fixture at your main circuit breaker to prevent electrical shock.
2. **Mounting Bracket Installation:** Attach the mounting bracket to your wall junction box using the provided screws. Ensure it is securely fastened and level.
3. **Wiring Connections:** Connect the fixture's wires to your household wiring according to standard electrical codes (black to black, white to white, ground to ground). Use wire nuts to secure connections.
4. **Fixture Attachment:** Secure the light fixture body to the mounting bracket. The fixture can be installed facing upward or downward to suit your preference.
5. **Shade and Bulb Installation:** Carefully attach the milky white glass lampshades to the fixture. Insert compatible E26 base bulbs (MAX 60W, not included) into the sockets. The open bottom design allows for easy bulb changes.



Figure 4: Installation Direction Options (Upward or Downward).

Operating Instructions

Your Lomoky vanity light fixture is designed for optimal illumination and versatility.

Bulb Compatibility and Dimmability

This fixture is compatible with standard E26 base bulbs, with a maximum wattage of 60W per bulb. Suitable bulb types include Incandescent, CFL, Halogen, and LED. For dimming functionality, ensure you use dimmable E26 bulbs and a compatible dimmer switch (both not included).



Figure 5: Bulb Compatibility and Dimmable Functionality. Choose light bulbs with different color temperatures to achieve various brightness levels.

Maintenance

To ensure the longevity and appearance of your light fixture, follow these simple maintenance guidelines:

- **Cleaning:** Always turn off the power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass shades.
- **Bulb Replacement:** Ensure the fixture is cool before replacing bulbs. The open bottom design of the shades allows for easy access.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

Troubleshooting

If you encounter any issues with your Lomoky light fixture, please refer to the following common troubleshooting steps:

- **Light does not turn on:**
  - Check if the power switch is in the 'ON' position.
  - Verify that the circuit breaker for the fixture is not tripped.
  - Ensure bulbs are correctly installed and not burnt out. Test with a known working bulb.
  - Confirm all wiring connections are secure.
- **Lights flicker:**
  - Ensure bulbs are fully screwed into the sockets.
  - If using dimmable bulbs, ensure they are compatible with your dimmer switch.
  - Check for loose wiring connections.
- **Fixture is loose:**
  - Tighten the mounting screws securing the fixture to the wall.

If these steps do not resolve the issue, please contact customer support for further assistance.

Specifications

Feature	Detail
Brand	Lomoky
Model Name	Vanity Light Fixture
Item Model Number	3-Light Brushed Nickel Vanity Light
Color	Brushed Nickel
Material	Rustproof Brushed Nickel Finish, Glass, Metal, Eye-protection Milky White Glass Shade
Style	Modern Bathroom Light Fixtures
Light Fixture Form	Vanity
Product Dimensions	18.35"L x 5.5"W x 8.27"H
Item Weight	3.96 pounds
Power Source	Corded Electric
Installation Type	Semi Flush Mount

Feature	Detail
Special Feature	Dimmable, Easy Installation, Rustproof, Anti-Rust
Light Source Type	LED, Incandescent, Halogen
Number of Light Sources	3
Voltage	120 Volts (AC)
Wattage	60 watts (MAX per bulb)
Bulb Base	E26
Shade Material	Glass
Water Resistance Level	Not Water Resistant
Assembly Required	No
Country of Origin	China

Warranty and Support

Lomoky is committed to providing high-quality products and excellent after-sales service. If your brushed nickel bathroom lighting has any defects or stops working, please contact us. We aim to respond and assist you within 24 hours.

For support, please visit the official Lomoky store or contact customer service through your purchase platform.

Visit the Lomoky Store on Amazon

© 2024 Lomoky. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7259BQ7

More documents and user manuals: **https://manuals.plus/**