



Manuals.plus /

› LINSY HOME /

› LINSY HOME Farmhouse 9-Drawer Dresser (Model LH618) User Manual

LINSY HOME LH618

LINSY HOME Farmhouse 9-Drawer Dresser User Manual

Model: LH618

1. INTRODUCTION

Thank you for choosing the LINSY HOME Farmhouse 9-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser, model LH618, features a farmhouse design with nine spacious drawers, measuring 15.7 inches deep, 53.5 inches wide, and 36.8 inches high. It is designed for use in bedrooms, nurseries, living rooms, entryways, and hallways.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- **Anti-Tip Kit:** Always install the included wall anchor kit to prevent tip-over incidents. This is crucial for the safety of children and pets.
- **Assembly:** Assembly should ideally be performed by two adults. An electric screwdriver is recommended for efficiency and to ensure all fasteners are securely tightened.
- **Drawer Safety Stops:** Each drawer is equipped with safety stops to prevent accidental pulling out. Ensure these are properly engaged during assembly and use.
- **Weight Limits:** Do not exceed the maximum load capacity of 66 lbs on the tabletop. Distribute weight evenly within drawers.
- **Placement:** Place the dresser on a level, stable surface. Avoid placing it near heat sources or in direct sunlight to prevent material damage.

Anti-tip kit adds extra stability

Protect your kids and pets



Figure 2.1: Illustration of the anti-tip kit installation for enhanced stability and safety.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser Panels (top, bottom, sides, back, drawer fronts, drawer sides, drawer bottoms)
- Drawer Handles (Antique style)
- Drawer Slides (Metal runners)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tip Wall Anchor Kit
- User Manual (this document)

4. SETUP AND ASSEMBLY

Estimated assembly time: Approximately 3 hours for two people.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts on a soft, clean surface to prevent scratches. Organize hardware by type.

2. **Identify Parts:** Refer to the included assembly instructions to identify each panel and hardware piece.
3. **Assemble Frame:** Follow the step-by-step diagrams in the separate assembly guide to construct the main dresser frame. Ensure all connections are tight and secure.
4. **Assemble Drawers:** Construct each of the nine drawers, ensuring the metal runners are correctly installed and aligned. Pay close attention to the small screws on the drawer rails; they must be completely flush for smooth operation.
5. **Install Drawers:** Carefully insert the assembled drawers into the dresser frame, ensuring they slide smoothly and the safety stops engage properly.
6. **Attach Handles:** Securely attach the antique handles to each drawer front.
7. **Install Anti-Tip Kit:** This is a critical safety step. Attach the anti-tip bracket to the back of the dresser and secure it to a wall stud using the provided hardware. Ensure the dresser is stable and cannot tip forward.



Figure 4.1: Product dimensions and estimated assembly time.

5. OPERATING INSTRUCTIONS

The LINSY HOME Farmhouse Dresser is designed for versatile storage and can serve multiple functions in

your home.

- **Drawer Use:** Utilize the nine drawers for organized storage of clothing, linens, nursery items, or other personal belongings. The drawers feature smooth metal runners for easy opening and closing.
- **Tabletop Functionality:** The sturdy tabletop can support up to 66 lbs, making it suitable for displaying decorative items, lamps, or even as a TV stand.



| Can be a TV dresser for bedroom

Figure 5.1: The dresser functioning as a TV stand in a bedroom.



Figure 5.2: Detail of a drawer demonstrating smooth glide operation.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the laminated finish.
- **Spills:** The dresser features an exquisite sealing process for a waterproof surface. In case of spills, wipe them immediately with a dry cloth to prevent water damage.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Environmental Conditions:** Avoid prolonged exposure to direct sunlight or extreme temperature changes, which can cause fading or warping.

Premium Edge Sealing Process



Exquisite sealing edge,
longer service life



No edge sealing,
easy to crack and mold



Figure 6.1: Illustration of the premium edge sealing process for durability.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Drawers do not slide smoothly:**
 - Ensure all screws on the drawer rails are completely flush and not protruding.
 - Verify that the drawer slides are correctly aligned and installed on both the drawer and the dresser frame.
 - Check that the drawers are properly seated in the sliding mechanisms.
- **Drawers fall out when opening:**
 - Confirm that the drawer safety stops are correctly installed and engaged.
 - Inspect the drawer slides for any damage or misalignment.
- **Wobbly dresser:**
 - Ensure all assembly hardware is securely tightened.
 - Verify the dresser is placed on a level surface. Adjust if necessary.
 - Confirm the anti-tip kit is properly installed and secured to the wall.

- **Laminate peeling or chipped:**

- If this occurs upon unboxing or during careful assembly, it may indicate a manufacturing defect or shipping damage. Contact customer support for assistance.

8. SPECIFICATIONS

Brand	LINSY HOME
Model Name	LH618
Product Dimensions	15.7"D x 53.5"W x 36.8"H
Color	Black
Item Weight	130 Pounds
Material	CARB P2 & TSCA certified manufactured wood, Laminated finish
Number of Drawers	9
Tabletop Load Capacity	66 lbs
Assembly Required	Yes
Care Instructions	Wipe with Dry Cloth

9. WARRANTY INFORMATION

Specific warranty details for the LINSY HOME Farmhouse 9-Drawer Dresser are not provided in this manual. For information regarding product warranty, please refer to the documentation included with your purchase or contact LINSY HOME customer support directly. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

For further assistance, missing parts, or technical support, please contact LINSY HOME customer service. Refer to the contact information provided on the packaging or the official LINSY HOME website.