

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KENNETH COLE](#) /

› [Kenneth Cole Quartz Chronograph Watch Model KCWGO0035501MN User Manual](#)

KENNETH COLE NTKCWGO0035501MN

Kenneth Cole Quartz Chronograph Watch Model KCWGO0035501MN User Manual

Comprehensive Instructions for Operation and Care

1. PRODUCT OVERVIEW

This manual provides detailed instructions for the Kenneth Cole Quartz Chronograph Watch, Model KCWGO0035501MN. This timepiece features a precise quartz movement, chronograph functionality, and a date display. Its design includes a silver dial with contrasting black and green subdials, a black bezel, and a durable black silicone strap.

- Chronograph Function:** Multiple subdials for accurate time measurement.
- Silver Dial:** Features contrasting black and green subdials for clear readability.
- Black Bezel:** A fixed bezel frames the dial.
- Silver Hands and Markers:** Designed for clear time indication.
- Silicone Strap:** Provides a comfortable and secure fit.

2. WATCH COMPONENTS

Familiarize yourself with the key components of your Kenneth Cole watch:



Figure 2.1: Front View. This image displays the watch face, including the silver dial, black bezel, chronograph subdials, and the main hour, minute, and second hands.



Figure 2.2: Angled View. This image shows the watch from an angle, highlighting the crown and pushers on the side of the case, as well as the texture of the silicone strap.



Figure 2.3: Rear View. This image presents the watch's case back, detailing the stainless steel construction, water resistance rating (3 ATM), and brand engravings.

- A. Crown:** Used for setting the time and date. Located on the right side of the watch case.
- B. Pushers:** Buttons located above and below the crown, used to operate the chronograph functions.
- C. Dial:** The watch face, displaying time, date, and chronograph subdials.
- D. Hands:** Hour, minute, and second hands, along with subdial hands for chronograph functions.
- E. Strap:** Black silicone strap for wearing the watch.

3. SETUP INSTRUCTIONS

3.1 Setting the Time

1. Pull the crown (A) out to the second click position.
2. Turn the crown (A) clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown (A) back to the normal position to start the watch.

3.2 Setting the Date

1. Pull the crown (A) out to the first click position.
2. Turn the crown (A) clockwise to set the date. Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown (A) back to the normal position.

3.3 Chronograph Hand Reset (If Misaligned)

If the chronograph hands do not return to the zero position after resetting, they may need to be

recalibrated:

1. Pull the crown (A) out to the second click position.
2. Press the upper pusher (B) repeatedly to advance the chronograph second hand to the 12 o'clock position.
3. Press the lower pusher (B) repeatedly to advance the chronograph minute and 24-hour hands to their respective zero positions.
4. Once all chronograph hands are aligned, push the crown (A) back to the normal position.

4. OPERATING INSTRUCTIONS

4.1 Using the Chronograph

The chronograph function allows for precise measurement of elapsed time.

1. **Start:** Press the upper pusher (B) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher (B) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press the lower pusher (B) to reset all chronograph hands to their zero positions.
4. **Split Time (Intermediate Measurement):** While the chronograph is running, press the lower pusher (B) to take a split time. The chronograph hands will stop to show the intermediate time. The chronograph continues to run internally. Press the lower pusher (B) again to display the ongoing elapsed time.

5. MAINTENANCE AND CARE

5.1 Cleaning

Regularly wipe your watch with a soft, dry cloth to remove dust and dirt. For the silicone strap, a mild soap solution and water can be used, followed by thorough rinsing and drying.

5.2 Water Resistance

This watch is water resistant to 3 ATM (30 meters/100 feet). This rating means the watch is suitable for everyday use and can withstand splashes or brief immersion in water. It is not suitable for swimming, showering, or diving. Ensure the crown is fully pushed in before any contact with water.

5.3 Battery Replacement

The watch is powered by a Lithium Polymer battery. When the battery is depleted, it should be replaced by a qualified watch technician to ensure proper sealing and function. Do not attempt to replace the battery yourself.

5.4 Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid exposing the watch to strong magnetic fields.

6. TROUBLESHOOTING

6.1 Watch Not Running

- Check if the crown is fully pushed in.

- The battery may be depleted. Refer to section 5.3 for battery replacement.

6.2 Chronograph Hands Not Resetting to Zero

- Refer to section 3.3 for chronograph hand reset instructions.

6.3 Date Not Changing

- Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight.
- Avoid setting the date during the automatic change period (9:00 PM to 3:00 AM).

If issues persist, please contact customer support.

7. SPECIFICATIONS

Model Number	NTKCWGO0035501MN
Movement Type	Quartz
Case Diameter	43 Millimetres
Band Material Type	Silicone
Band Color	Black
Water Resistance	3 ATM (30 meters / 100 feet)
Battery Type	1 Lithium Polymer (included)
Product Dimensions	13 x 9 x 6 cm
Item Weight	200 Grams
Country of Origin	China

8. WARRANTY INFORMATION

This Kenneth Cole watch comes with a Limited Warranty. For specific terms, conditions, and duration of the warranty, please refer to the warranty card included with your purchase or visit the official Kenneth Cole website. The warranty typically covers manufacturing defects under normal use.

9. CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries regarding your Kenneth Cole watch, please contact Kenneth Cole customer service. Contact details can typically be found on the official Kenneth Cole website or on your product packaging.

You may also visit the [KENNETH COLE Store on Amazon](#) for additional product information.

	<p>Kenneth Cole Wellness Watch: Instruction Manual and Warranty Official instruction manual and warranty booklet for the Kenneth Cole Wellness Watch, providing setup, usage, and support information.</p>
	<p>BriskHeat Silicone Rubber Heating Blankets Instruction Manual Instruction manual for BriskHeat Silicone Rubber Heating Blankets, covering safety, installation, troubleshooting, and warranty information. Designed for Cole-Parmer and Davis Instruments.</p>
	<p>Traceable 24-Hour Digital Stopwatch Instructions and Specifications User manual and specifications for the Traceable 24-Hour Digital Stopwatch, detailing operation modes, time/date/alarm settings, battery replacement, and warranty information.</p>
	<p>Traceable Jumbo Display Dial Thermometer Instructions and Specifications This document provides instructions, specifications, troubleshooting, and warranty information for the Traceable Jumbo Display Dial Thermometer, model 92-4049-00. It details temperature range, accuracy, operation, battery replacement, and contact details for service.</p>
	<p>King Cole Merino Blend DK Knitting Patterns Collection (6366-6373) Explore the King Cole Merino Blend DK knitting pattern collection, featuring stylish sweaters, cardigans, scarves, and hats for men and women. This guide includes detailed measurements, materials, and needle requirements for patterns 6366 through 6373, designed for knitters using King Cole yarns.</p>