

CYBORIS S10

CYBORIS S10 Portable Splittable Bluetooth Speaker User Manual

Model: S10

INTRODUCTION

Thank you for choosing the CYBORIS S10 Portable Splittable Bluetooth Speaker. This 2-in-1 speaker system offers versatile audio experiences, allowing for both immersive surround sound when combined and distinct left/right stereo sound when separated. Designed for home, outdoor, and travel use, it features Bluetooth V5.3 connectivity, IPX6 waterproofing, and a long-lasting battery. Please read this manual carefully to ensure proper use and maintenance of your speaker.



Image: The CYBORIS S10 speaker shown in its combined form, highlighting its sleek black design and control buttons.

SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from medical devices, as its magnetic components may interfere with their operation.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for assistance.
- Ensure charging ports are dry before connecting the charging cable.
- Use only the provided charging cable and adapter (if included) to prevent damage.

PACKAGE CONTENTS

Verify that all items are present in your package:

- CYBORIS S10 Splittable Bluetooth Speaker (2 units)
- TYPE-C Charging Cable
- 3.5mm Audio Cable
- Strap
- Instruction Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls:

BUTTON DESCRIPTION

ILLUSTRATE



Image: A detailed view of one speaker unit, illustrating the location and function of each button.

Controls:

- **Power On/Off Button:** Press and hold to power on or off. Short press to switch modes.
- **Volume + / Next Track Button:** Short press for volume up, long press for next track.
- **Volume - / Previous Track Button:** Short press for volume down, long press for previous track.
- **Play/Pause Button:** Short press to play/pause. Answer/hang up calls. Long press to reject calls or disconnect wireless.

Ports:



MULTIPLE PLAYBACK MODES

In addition to wireless mode, it also supports TF card playback, AUX wired input playback

Image: A close-up of the speaker's side panel, showing the TF card slot, AUX input, and Type-C charging port.

- **Type-C Charging Port:** For charging the speaker.
- **TF Card Slot:** For playing music directly from a TF (MicroSD) card.
- **AUX Input:** For wired audio connection using the 3.5mm audio cable.

SETUP

Charging the Speaker:

1. Connect the provided Type-C charging cable to the speaker's charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light will change or turn off.

Powering On/Off:

- To power on, press and hold the Power button until you hear an audible prompt and the indicator lights illuminate.
- To power off, press and hold the Power button again until you hear an audible prompt and the lights turn off.

OPERATING INSTRUCTIONS

Splittable Design and True Wireless Stereo (TWS) Pairing:

The CYBORIS S10 speaker consists of two independent units that can be used together for stereo sound or separately.



Image: Two speaker units shown separated, with arrows indicating the rotation for splitting them apart.

1. To separate the speakers, gently twist and pull them apart.
2. To combine them, align the magnetic ends and push them together until they click into place.
3. When both speakers are powered on and within range, they will automatically attempt to pair with each other for True Wireless Stereo (TWS) mode. A successful TWS connection will be indicated by an audible prompt.
4. Once TWS paired, they will function as a single stereo system.



TWS INTERCONNECTION PLAYBACK

The split speakers can be automatically interconnected when turned on at the same time forming left and right channels, and a surround stereo field to create an immersive music scene

Image: Two separated speaker units wirelessly connected to a laptop, demonstrating the TWS interconnection playback.

Bluetooth Pairing:

1. Ensure the speaker(s) are powered on. If in TWS mode, only one speaker needs to be paired with your device.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue light.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "CYBORIS S10" from the list.
5. Once successfully paired, you will hear an audible confirmation, and the blue light will become solid.

WIRELESS 5.3 STABLE AT HIGH SPEED

Built-in V5.3 core chip, stable and fast transmission
straight-line connection distance of more than 18 meters
so that you can listen more freely
and enjoy the music fun brought by wireless



Image: A conceptual diagram illustrating the stable and fast transmission provided by the built-in Bluetooth V5.3 core chip.

Multiple Playback Modes:

The speaker supports various audio input methods:

- **Bluetooth Mode:** (Default) Connect wirelessly to your device as described above.
- **TF Card Playback:** Insert a TF (MicroSD) card with MP3/WAV/FLAC audio files into the TF card slot. The speaker will automatically switch to TF card mode and begin playback.
- **AUX Wired Input:** Connect one end of the 3.5mm audio cable to the speaker's AUX port and the other end to your audio source's headphone jack. The speaker will automatically switch to AUX mode.

Hands-Free Calling:

When connected via Bluetooth to a smartphone, the speaker's built-in microphone allows for hands-free calls:

- **Answer Call:** Short press the Play/Pause button.
- **End Call:** Short press the Play/Pause button during a call.
- **Reject Call:** Long press the Play/Pause button.

Dazzling Lighting Effects:

The speaker features colorful LED lights that can sync with music.



Image: A close-up of the speaker's top, showing the vibrant RGB breathing light effect in action.

- The breathing light is turned on by default when the speaker is active.
- The lights will dance with the rhythm of the music, enhancing the audio experience.

MAINTENANCE

Proper care will extend the life of your speaker:

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- While the speaker is IPX6 waterproof, avoid submerging it completely in water. If it gets wet, wipe it dry thoroughly before charging or using ports.
- Store the speaker in a cool, dry place when not in use.
- Charge the speaker at least once every three months to maintain battery health if not used regularly.

IPX6 WATERPROOF NOT AFRAID OF RAIN

The sealed waterproof cavity structure is not afraid of large area of water, and it can be used as usual after drying after falling into the water



Image: The speaker being splashed with water, demonstrating its IPX6 waterproof rating and suitability for outdoor use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode (flashing blue light). Turn on Bluetooth on your device. Move speaker closer to device (within 18 meters). Forget "CYBORIS S10" on your device and try pairing again.
No sound.	Volume too low; incorrect input mode; device not playing.	Increase speaker and device volume. Ensure correct playback mode (Bluetooth, TF, AUX). Check if audio is playing on the connected device.

Problem	Possible Cause	Solution
TWS pairing fails.	Speakers too far apart; one speaker already paired to a device.	Ensure both speakers are powered on and close to each other. Disconnect any existing Bluetooth connections from individual speakers before attempting TWS pairing.
Sound distortion.	Volume too high; low battery; interference.	Reduce volume. Charge the speaker. Move away from other electronic devices that may cause interference.

SPECIFICATIONS

Feature	Detail
Model Name	S10
Speaker Type	Outdoor
Special Features	Portable, Waterproof, Stereo Pairing, Splittable
Connectivity Technology	Bluetooth V5.3
Wireless Range	Up to 18 meters (59 feet)
Audio Output Mode	Stereo
Speaker Maximum Output Power	20 Watts
Water Resistance Level	IPX6 Waterproof
Battery Life	Up to 24 hours (2400mAh polymer lithium battery)
Product Dimensions	3"D x 3"W x 8.26"H
Item Weight	0.7 Kilograms (1.54 pounds)
Included Components	Instruction manual, TYPE-C charging cable, 3.5mm audio cable, Strap

WARRANTY AND SUPPORT

The CYBORIS S10 Portable Splittable Bluetooth Speaker comes with a full warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or contact CYBORIS customer support.

If you encounter any issues or have questions regarding your product, please contact CYBORIS customer support through the following channels:

- **Online Support:** Visit the official CYBORIS website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or the official website for the customer service email address.

Please have your model number (S10) and purchase information ready when contacting support.

