



[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Queen Size Upholstered Bed Frame with 4 Drawers and 1 Twin XL Trundle Instruction Manual

## Bellemave YZC614000714

# Bellemave Queen Size Upholstered Bed Frame with 4 Drawers and 1 Twin XL Trundle Instruction Manual

Model: YZC614000714

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Bellemave Queen Size Upholstered Bed Frame with 4 Drawers and 1 Twin XL Trundle. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

---

### WARNING:

- Do not exceed a total weight of 600 lbs on the bed frame.
- Ensure proper assembly to prevent collapse or instability.
- Be cautious around the trundle area, as it may have potential pinch points.
- Always use the bed frame on a flat, level surface.
- Keep small parts away from children during assembly.

## PACKAGE CONTENTS

---

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Upholstered Headboard
- Bed Frame Side Rails (2)

- Bed Frame Footboard
- Wooden Slats (for main bed)
- Storage Drawers (4) with wheels
- Twin XL Trundle Frame with wooden slats and wheels
- Support Legs
- Hardware Pack (screws, bolts, washers, Allen wrench)
- Assembly Instructions (this manual)

## SETUP AND ASSEMBLY

---

Assembly typically requires two adults. A power drill with appropriate bits is recommended for faster and more secure assembly, especially for pre-drilling pilot holes where indicated. Do not overtighten screws.

### Tools Required:

- Allen Wrench (provided)
- Phillips Head Screwdriver (not provided)
- Power Drill (recommended, not provided)

### Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list to ensure all pieces are present.
2. **Assemble Headboard and Footboard:** Attach the support legs to the upholstered headboard and footboard using the provided hardware. Ensure all connections are secure.
3. **Connect Side Rails:** Attach the side rails to the headboard and footboard using the appropriate bolts and washers. Do not fully tighten until the entire frame is assembled.
4. **Install Center Support Legs:** Attach any designated center support legs to the main bed frame.
5. **Place Wooden Slats:** Lay the wooden slats across the bed frame. Secure them to the side rails using the provided screws. Ensure even spacing for optimal mattress support.
6. **Assemble Storage Drawers:** Follow the specific instructions for assembling the four storage drawers. Attach the wheels to the bottom of each drawer.
7. **Assemble Twin XL Trundle:** Assemble the trundle frame and attach its wooden slats and wheels. Ensure the trundle can slide smoothly under the main bed.
8. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws on the entire bed frame.



Image: Detailed dimensions of the Bellemave Queen Bed Frame, including headboard height, frame length, width, and drawer/trundle measurements.



Image: The Bellemeve Queen Bed Frame with the four storage drawers removed, showing the under-bed storage compartments and the main bed's slat support system.



Image: The Bellemeve Queen Bed Frame with the Twin XL trundle bed fully extended from underneath the main frame, showcasing its additional sleeping capacity.

## OPERATING INSTRUCTIONS

---

### Using the Storage Drawers:

The four storage drawers are designed to slide smoothly on wheels. To access, gently pull the fabric handle on the front of the drawer. To close, push the drawer back into its compartment until it is fully recessed under the bed frame.

### Using the Twin XL Trundle:

The Twin XL trundle is located under the main bed frame. To use, grasp the handle on the trundle front and pull it out smoothly. The trundle is equipped with wheels for easy movement. To store, push the trundle back under the main bed until it is fully hidden.

## **MAINTENANCE**

---

### **Cleaning the Upholstery:**

- Regularly vacuum the velvet upholstery using a soft brush attachment to remove dust and debris.
- For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain.
- For stubborn stains, use a mild fabric cleaner specifically designed for velvet, testing on an inconspicuous area first. Follow the cleaner's instructions carefully.
- Avoid direct sunlight to prevent fading.

### **Frame and Slats Care:**

- Wipe down the wooden and engineered wood components with a damp cloth. Avoid harsh chemicals.
- Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability.
- Ensure the area under the bed and around the trundle/drawers is clear of obstructions to allow smooth operation.



Image: A close-up view of the wooden slat support system within the Bellemave bed frame, showing the sturdy construction for mattress support.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose connections; uneven floor.	Ensure all bolts and screws are fully tightened. Check if the bed is on a level surface.
Drawers do not slide smoothly.	Obstruction in track; damaged wheels; misaligned drawer.	Clear any debris from the drawer tracks. Inspect wheels for damage. Re-align the drawer if necessary.
Trundle is difficult to pull out or push in.	Obstruction; misaligned trundle frame; damaged wheels.	Check for items blocking the trundle's path. Verify the trundle frame is assembled correctly and wheels are intact.

Problem	Possible Cause	Solution
Squeaking noises from the bed.	Loose connections; friction between parts.	Re-tighten all assembly hardware. Ensure slats are properly seated and not rubbing against the frame.

## SPECIFICATIONS

---

- **Product Dimensions (L x W x H):** 84.6" x 64.7" x 45.8"
- **Compatible Mattress Size (Main Bed):** Queen Size
- **Compatible Mattress Size (Trundle):** Twin XL
- **Material:** Engineered Wood, Velvet Upholstery
- **Color:** Beige
- **Maximum Weight Recommendation:** 600 Pounds
- **Included Components:** Headboard, Frame, Slats, 4 Drawers, 1 Twin XL Trundle
- **Assembly Required:** Yes
- **Item Weight:** 71.87 Pounds
- **Model Number:** YZC614000714
- **UPC:** 733805191924

## WARRANTY INFORMATION

---

Specific warranty details for this product may vary. Please refer to the documentation included with your purchase or contact the retailer/manufacturer directly for information regarding warranty coverage, terms, and conditions.

## CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bellemave customer support through the retailer where the product was purchased. Have your model number (YZC614000714) and purchase date ready for faster service.