

Generic MP-007

Generic Heat Resistant Honeycomb Silicone Placemat User Manual

Model: MP-007

INTRODUCTION

This manual provides instructions for the safe and effective use of your Generic Heat Resistant Honeycomb Silicone Placemats. These versatile silicone mats are designed for various kitchen applications, offering heat resistance, non-slip properties, and ease of cleaning.

PRODUCT OVERVIEW

The Generic Honeycomb Silicone Placemat features a unique honeycomb texture that enhances grip and heat distribution. It is made from durable, food-grade silicone, suitable for high temperatures.




Image: A single Nordic Grey honeycomb silicone placemat, circular in shape, with a small hole for hanging.

SETUP

Before first use, it is recommended to wash the silicone placemats thoroughly with warm soapy water or place them in a dishwasher. Rinse well and allow to air dry completely.

OPERATING INSTRUCTIONS

Your silicone placemats can be used in multiple ways:

- **Trivet/Hot Pad:** Place under hot pots, pans, or dishes to protect countertops and tables from heat damage. The honeycomb design provides excellent insulation.
- **Jar Opener:** The non-slip texture provides a firm grip, making it easier to open stubborn jar lids.
- **Spoon Rest:** Use to rest cooking utensils, keeping your countertops clean.
- **Pot Holder:** The flexible and heat-resistant material allows for safe handling of hot cookware.
- **Non-slip Mat:** Place under cutting boards or mixing bowls to prevent them from sliding during use.



Image: A person using two honeycomb silicone placemats, one orange and one beige, to safely lift a large hot pot from a surface. Another grey placemat is visible on the table.



Image: A hand demonstrating the flexibility of the honeycomb silicone placemat by squeezing it into a crumpled shape.



Image: Two honeycomb silicone placemats on a white surface. One is grey, and the other is blue, with a white bowl placed on top of the blue one. A red pot is also visible in the background.

MAINTENANCE AND CARE

To ensure the longevity of your silicone placemats, follow these care instructions:

- **Cleaning:** The placemats are dishwasher safe. Alternatively, wash by hand with warm water and mild dish soap.
- **Drying:** Allow to air dry completely before storing to prevent moisture buildup.
- **Storage:** Store in a clean, dry place. The integrated hanging hole allows for convenient storage on hooks.
- **Avoid Sharp Objects:** Do not use sharp objects on the placemats, as this may damage the silicone.

TROUBLESHOOTING

- **Stains:** For stubborn food stains, soak the placemat in warm soapy water for a few minutes before scrubbing. A paste of baking soda and water can also be used for tougher stains.
- **Odor:** If the silicone develops an odor, wash it thoroughly and then bake it in an oven at 250°F (120°C) for about an

hour. Ensure the placemat is clean before baking.

SPECIFICATIONS

Brand	Generic
Model	MP-007
Colour	Nordic Grey
Material	Silicone
Product Dimensions	15.6L x 15.6W x 1.3Th Centimetres (approx. 6.14 x 6.14 x 0.5 inches)
Item Weight	41 g (per placemat)

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not provided in the product details. Please refer to the retailer or manufacturer's website for any available warranty information or support contacts.

© 2024 Generic. All rights reserved.