

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Coleshome](#) /
- › [Coleshome 71 Inch Computer Desk with USB Ports Instruction Manual](#)

Coleshome c489682e-487a-4d57-8925-c25fd9183c8e

Coleshome 71 Inch Computer Desk with USB Ports Instruction Manual

Model: c489682e-487a-4d57-8925-c25fd9183c8e

1. PRODUCT OVERVIEW

The Coleshome 71 Inch Computer Desk with USB Ports is designed to provide a spacious and functional workspace for various activities, including office work, studying, gaming, and creative projects. It features a large desktop surface and integrated power outlets with USB and Type-C charging ports for convenient device charging.



Image: The Coleshome 71 Inch Computer Desk provides ample space for multiple monitors and accessories in a home office environment.

2. SETUP AND ASSEMBLY

This desk is designed for quick and straightforward assembly. All necessary tools and hardware are included in the package. Please follow the instructions carefully to ensure proper setup.

2.1 Unpacking and Component Check

Carefully unpack all components and verify against the parts list provided in your package. Ensure no parts are missing or damaged before proceeding.

2.2 Assembly Steps

Assembly typically takes approximately 30 minutes. Refer to the visual guide below and the detailed instructions in your package for step-by-step guidance.

Dimensions

Ergonomic Height and Width.





Image: Visual guide for quick assembly of the desk components.

2.3 Assembly Video Guide

For a visual walkthrough of the assembly process and product features, please refer to the official seller video below:

Your browser does not support the video tag.

Video: Official product overview and assembly highlights for the Coleshome 71 Inch Computer Desk with USB Ports.

3. OPERATING INSTRUCTIONS

The Coleshome 71 Inch Computer Desk is designed for versatile use and includes integrated power features for convenience.

3.1 Utilizing the Integrated Power Outlets

The desk is equipped with 3 AC power outlets, 1 USB charging port, and 1 Type-C charging port. These are recessed into the desktop for easy access and to keep your workspace tidy.

- **AC Outlets:** 3 outlets (125V/12A) for standard electronic devices.
- **USB Port:** 1 USB-A charging port (5V-2A) for smartphones, tablets, and other USB-powered devices.
- **Type-C Port:** 1 Type-C charging port (5V-2A) for modern devices requiring USB-C connectivity.

The power strip can be installed on either the left or right side of the desk during assembly to suit your preference.



Image: Integrated power outlets and charging ports for convenient device power.

Recessed Power Strip



3 AC Outlets
125V/12A



1 Type-C
5V-2A



1 USB Port
5V-2A



Image: Devices charging directly from the desk's built-in power strip.

3.2 General Use

The large desktop provides ample space for multiple monitors, laptops, keyboards, and other office or gaming equipment. The sturdy metal frame ensures stability for all your items.

Your browser does not support the video tag.

Video: Demonstration of the large computer desk with power outlets in various settings.

4. MAINTENANCE

To ensure the longevity and appearance of your Coleshome computer desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desktop surface and metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood surface.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat marks.
- **Weight Distribution:** Distribute weight evenly across the desktop to maintain stability and prevent stress on the frame.

5. TROUBLESHOOTING

If you encounter any issues with your desk, please refer to the following common solutions:

- **Wobbling:** Ensure all screws are tightened securely. Check the adjustable feet pads on the bottom of the legs and adjust them to stabilize the desk on uneven floors.
- **Power Outlets Not Working:** Verify that the desk's main power cord is securely plugged into a functional wall outlet. Check for any tripped circuit breakers.
- **Missing Parts:** If any parts were missing upon delivery, please contact customer support immediately for assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Number	c489682e-487a-4d57-8925-c25fd9183c8e
Product Dimensions (D x W x H)	23.6"D x 70.9"W x 29"H
Color	Black
Top Material Type	Engineered Wood
Base Material	Metal (Feet Pad)
Special Feature	Built-In USB Outlet, Built-in Type-C Port, Headphone Hook
Power Outlets	3 AC Outlets (125V/12A)
USB Charging Port	1 USB-A (5V-2A)
Type-C Charging Port	1 Type-C (5V-2A)
Assembly Required	Yes
Includes All Assembly Tools	Yes

7. WARRANTY AND SUPPORT

Coleshome offers a **1-year warranty** for this product. In case your desk arrives damaged, has missing parts, or is scratched, please contact our professional customer support team. We are committed to resolving any issues within 24 hours, offering fast refunds or replacements for quality problems.

For further assistance, please visit the [Coleshome Store on Amazon](#) or refer to the contact information provided in your product packaging.