

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AutoBot](#) /

› [AutoBot VX4 MAX Car Vacuum Cleaner Instruction Manual](#)

## AutoBot VX4 MAX-20KPA Vacuum & Clean

# AutoBot VX4 MAX Car Vacuum Cleaner Instruction Manual

Model: VX4 MAX-20KPA Vacuum & Clean

## INTRODUCTION

The AutoBot VX4 MAX is a versatile 4-in-1 cordless handheld vacuum cleaner designed for comprehensive cleaning. It offers vacuuming, blowing, inflating, and pumping functionalities, making it suitable for various tasks from car detailing to home and outdoor use. Featuring a powerful 20000Pa suction and a long-lasting battery, this lightweight and portable device ensures efficient and convenient cleaning.



Image: AutoBot VX4 MAX Cordless Car Vacuum highlighting its 4-in-1 functionality, 20KPA power suction, 70 minutes runtime, ultra-lightweight design, washable filter, and 3.5 hours charge time.

## WHAT'S IN THE Box

Before starting, please ensure all components are present:

- Car Vacuum Cleaner
- User Manual
- Narrow Slit Nozzle

- Brush
- Small Blow Nozzle
- Medium Blow Nozzle
- Large Blow Nozzle
- Storage Bag
- Type-C Charging Cable



Image: An exploded view of the AutoBot VX4 MAX Car Vacuum Cleaner and its accessories, clearly labeling each component included in the package.

## SETUP

---

### 1. Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the Type-C charging cable to the device and a compatible power source (15W charger recommended, not included). A full charge takes approximately 3.5 hours. The indicator lights will show charging status.

# TYPE-C FAST CHARGE FOR 3.5 HOURS

(15W CHARGER FOR 3.5H,CHARGER NOT INCLUDED )



Image: The AutoBot VX4 MAX Car Vacuum connected to a Type-C charging cable, illustrating the charging process within a car interior.

## 2. Attaching Nozzles

Select the appropriate nozzle for your task. The crevice nozzle is ideal for tight spaces, while the brush attachment helps with stubborn dust. For blowing or inflating, attach the corresponding blow nozzle to the exhaust port.



Image: The AutoBot VX4 MAX Car Vacuum with its array of attachments, including crevice tool, brush, and various blow nozzles, ready for different cleaning and inflation tasks.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off and Suction Modes

Press the power button to turn on the vacuum. The device features three suction modes: Eco (70 minutes runtime), Medium (40 minutes runtime), and Max (20 minutes runtime). Press the power button repeatedly to cycle through these modes. The indicator lights will show the current mode.



Image: A detailed view of the AutoBot VX4 MAX's control interface, illustrating the three distinct suction power modes and their corresponding battery life.

## 2. Vacuuming

Attach the desired vacuum nozzle. Turn on the device and select the appropriate suction power. Move the nozzle over the area to be cleaned. The powerful 20000Pa suction is effective against sand, dust, and debris.

# 4 IN 1 FOR VARIOUS SCENARIOS



Image: The AutoBot VX4 MAX Car Vacuum in action, demonstrating its effectiveness in cleaning car seats and tight spaces with its specialized nozzle.

### 3. Blowing and Inflating

To use the blowing function, attach a blow nozzle to the rear exhaust port. This can be used to clear dust from surfaces or to inflate items like air mattresses or swim rings. Ensure the correct size nozzle is used for inflation.



Image: The AutoBot VX4 MAX Car Vacuum demonstrating its air duster function, effectively blowing away debris from a car's surface.



Image: The AutoBot VX4 MAX Car Vacuum inflating an air mattress, showcasing its air pump capability with a suitable nozzle.

## 4. Deflating Storage Bags

In VACUUM mode, the device can also be used to deflate storage bags, helping to save space. Attach the appropriate nozzle to the vacuum inlet and apply it to the storage bag's valve.



Image: The AutoBot VX4 MAX Car Vacuum demonstrating its ability to vacuum air from a storage bag, aiding in space-saving.

## MAINTENANCE

---

### 1. Emptying the Dust Cup

To empty the dust cup, press the ring latch to automatically open the lid. Dispose of the collected debris. This design prevents direct contact with dirt.

# 11000RPM

## UPGRADED SUPER BRUSHLESS MOTOR



Image: A hand demonstrating the one-touch dust cup emptying mechanism of the AutoBot VX4 MAX Car Vacuum, showing debris falling into a bin.

## 2. Cleaning the HEPA Filter

The HEPA filter captures 99.99% of dust and particles. For optimal performance and extended lifespan, regularly clean the filter. Open the dust cup, pull out the filter system, and clean the pre-filter and HEPA filter with the provided cleaning brush. Ensure filters are completely dry before reassembling.



Image: A visual guide detailing the five steps to clean the filter of the AutoBot VX4 MAX Car Vacuum, from opening the dust cup to drying the filter.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device fully using the Type-C cable.
Weak suction power.	Dust cup is full or filter is clogged.	Empty the dust cup and clean the HEPA filter. Ensure it is dry before reassembly.
Device stops unexpectedly.	Battery depleted or overheating.	Recharge the battery. If overheating, allow the device to cool down before resuming use.
Blowing function is weak.	Incorrect nozzle attached or obstruction.	Ensure the correct blow nozzle is securely attached and check for any blockages in the exhaust port.

## SPECIFICATIONS

Feature	Detail
Brand	AutoBot
Model Name	VX4 MAX-20KPA Vacuum & Clean
Special Feature	Compact, Cordless, Lightweight, Portable, Washable Filter
Filter Type	HEPA Filter
Suction Power	20000Pa (Max Mode)
Motor Speed	110000rpm (Brushless)
Runtime	Up to 70 minutes (Eco Mode)
Charging Time	3.5 Hours (with 15W charger)
Battery Type	Lithium-Ion

Feature	Detail
Capacity	81 Milliliters (Dust Cup)
Item Weight	12.2 ounces (588g)
Product Dimensions	1.81" L x 10.62" W x 1.81" H
Noise Level	70 Decibels
Connectivity Technology	USB (Type-C)

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the official AutoBot website or contact the seller directly. Keep your purchase receipt for any warranty claims.

Optional protection plans are available for purchase separately to extend coverage beyond the standard warranty period. These plans typically offer 2-year or 3-year protection.

## PRODUCT VIDEOS

---

### AutoBot 20000PA High Power Car Vacuum Portable Cordless

Your browser does not support the video tag.

Video: An official product video showcasing the AutoBot 20000PA High Power Car Vacuum's portable and cordless features.

### AutoBot VX4 MAX Car Vacuum 20000PA High Power Portable

Your browser does not support the video tag.

Video: An official product video demonstrating the high power and portability of the AutoBot VX4 MAX Car Vacuum with 20000PA suction.