

IHO5M6L66254A5RVAT

Vibrating Alarm Clock User Manual

Brand: Generic

Model: IHO5M6L66254A5RVAT

1. PRODUCT OVERVIEW

The Generic Vibrating Alarm Clock is a portable and silent digital clock designed to effectively wake heavy sleepers, individuals with hearing impairments, and teenagers without disturbing others. Its compact design allows it to be placed under a pillow for a personal, strong vibration alarm. It also features a convenient backlight for visibility in the dark and a low battery reminder.





Figure 1.1: Front view of the Vibrating Alarm Clock.

2. KEY FEATURES

- **Vibrating Alarm:** Wakes deep sleepers and the hearing impaired with a strong vibration, ideal for placing under a pillow.
- **Dual Alarm Settings:** Allows for setting two independent alarm times.
- **Adjustable Vibration Intensity:** Choose from 3 levels of vibration intensity for a personalized wake-up experience.
- **10-Minute Snooze Function:** Easily activate snooze with a single button press.
- **12/24 Hour Display:** Switch between standard 12-hour and military 24-hour time formats.
- **Backlight Display:** Press the 'SNZ' button to illuminate the display for 10 seconds, featuring a charming cartoon cat design.
- **Low Battery Reminder:** An icon on the display indicates when batteries need replacement.
- **Compact and Portable:** Small size for easy travel and discreet placement.

Cartoon Cat Design

Press the "SNZ" button and the cat's backlight will light up for 10 seconds



Figure 2.1: Cartoon Cat Design and Backlight Function. Pressing the 'SNZ' button activates the backlight for 10 seconds.

Two sets of vibrating alarm clocks

An extra alarm clock makes bedtime more reassuring



Figure 2.2: Dual Alarm Settings and Snooze Function. The clock supports two independent alarms and a 10-minute snooze.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Vibrating Alarm Clock
- 1 x User Manual
- 1 x Screwdriver (for battery compartment)

4. SPECIFICATIONS

Attribute	Value
Model Number	IHO5M6L66254A5RVAT

Attribute	Value
Brand	Generic
Color	Standard
Material	ABS Plastic
Dimensions (L x W x H)	9.3 cm x 10.5 cm x 3.4 cm (3.66 in x 4.13 in x 1.34 in)
Weight	168 g
Power Source	3 x AA Batteries (not included)
Display Type	Digital LED
Special Features	Snooze, Alarm, Vibration, Backlight, Low Battery Indicator



Figure 4.1: Product Dimensions.

5. SETUP

5.1 Battery Installation

1. Locate the battery compartment on the back of the alarm clock.
2. Use the provided screwdriver to open the battery compartment cover.
3. Insert 3 new AA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screwdriver.

Note: The alarm clock requires 3 AA batteries for operation. Ensure batteries are inserted correctly to avoid damage.



Figure 5.1: Battery Compartment. Insert 3 AA batteries as shown.

6. OPERATING INSTRUCTIONS

6.1 Setting the Time

1. Press the 'SET' button once to enter time setting mode. The hour digits will flash.
2. Use the 'UP' or 'DOWN' buttons to adjust the hour.
3. Press 'SET' again to move to minute setting. The minute digits will flash.
4. Use the 'UP' or 'DOWN' buttons to adjust the minutes.
5. Press 'SET' a third time to confirm and exit time setting mode.

6.2 Setting Alarms (Alarm 1 & Alarm 2)

The clock supports two independent alarms.

1. Press the 'ALARM SET' button once to enter Alarm 1 setting mode. The Alarm 1 icon and hour digits will flash.
2. Use the 'UP' or 'DOWN' buttons to adjust the Alarm 1 hour.
3. Press 'ALARM SET' again to move to Alarm 1 minute setting.
4. Use the 'UP' or 'DOWN' buttons to adjust the Alarm 1 minutes.
5. Press 'ALARM SET' a third time to enter Alarm 2 setting mode (repeat steps for Alarm 2).
6. After setting Alarm 2 minutes, press 'ALARM SET' to confirm and exit alarm setting mode.

6.3 Snooze Function

When an alarm sounds/vibrates, press the 'SNZ' button to activate the snooze function. The alarm will pause for 10 minutes and then reactivate.

6.4 Adjusting Vibration Strength

The vibration strength can be adjusted to 3 levels. While in time display mode, press the 'DOWN/Vibration Strength' button repeatedly to cycle through the vibration intensity levels. The display will show an indicator for the current strength.

6.5 Backlight Activation

To temporarily illuminate the display, press the 'SNZ' button. The backlight will turn on for 10 seconds, making it easy to read the time in the dark.



Figure 6.1: Backlight Display. The cat icon illuminates when the backlight is active.

6.6 Placing for Optimal Vibration

For the most effective vibration, place the alarm clock directly under your pillow or mattress. Ensure there are no

obstructions that could dampen the vibration.



Figure 6.2: Recommended placement under a pillow for effective vibration.

7. MAINTENANCE

7.1 Cleaning

Wipe the alarm clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the surface.

7.2 Battery Replacement

When the low battery indicator appears on the display, it is time to replace the batteries. Follow the instructions in Section 5.1 to replace the 3 AA batteries. Always use new batteries and dispose of old batteries responsibly.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Alarm does not sound/vibrate.	Alarm is not set or turned off. Batteries are low or dead.	Ensure alarm is set correctly. Replace batteries if low battery indicator is on.
Display is dim or blank.	Low batteries.	Replace batteries.
Time is incorrect.	Time was not set correctly.	Refer to Section 6.1 to reset the time.
Vibration is too weak.	Vibration intensity setting is low. Clock is not placed optimally.	Adjust vibration strength (Section 6.4). Ensure clock is directly under pillow/mattress.

9. WARRANTY AND SUPPORT

This product is covered by standard consumer warranty laws in your region. For specific warranty details, please refer to the purchase documentation or contact the seller directly.

If you encounter any issues or have questions regarding your Vibrating Alarm Clock, please contact the seller or retailer from whom you purchased the product. Please have your model number (IHO5M6L66254A5RVAT) and purchase information ready when seeking support.