

[Manuals.plus](#) /

> [IMAGIC](#) /

> IMAGIC Replacement Brush Roller for M3 & M3 Combo Wet Dry Vacuum Cleaner

IMAGIC M3-BR

IMAGIC Replacement Brush Roller Instruction Manual

For M3 & M3 Combo Wet Dry Vacuum Cleaners

1. INTRODUCTION

This manual provides essential information for the proper installation, maintenance, and optimal use of your IMAGIC Replacement Brush Roller. Designed for compatibility with IMAGIC M3 and M3 Combo Wet Dry Vacuum Cleaners, this brush roller ensures effective cleaning performance on various sealed hard floor surfaces.

2. PRODUCT OVERVIEW

The IMAGIC Replacement Brush Roller is engineered to vacuum and wash simultaneously, efficiently tackling both dry debris and liquid spills. Its soft bristles are suitable for multi-surface cleaning, providing a thorough clean without damaging your floors.






Figure 1: IMAGIC Replacement Brush Roller

The brush roller features a brush roll tab for easy removal, absorbent fabric for effective cleaning, and a fitted slot for secure installation.




Figure 2: Detailed view of the Soft Brush Roller components, including the brush roll tab, absorbent fabric, and fitted slot.

3. COMPATIBILITY

This replacement brush roller is specifically designed for use with the **IMAGIC M3** and **IMAGIC M3 Combo** Cordless Wet Dry Vacuum Cleaners. Please verify your vacuum cleaner model before purchasing to ensure proper fit and function.



Figure 3: Visual guide for IMAGIC M3/M3 Combo compatibility. The image clearly indicates that the brush roller is exclusively for these models and not for other vacuum types.

4. INSTALLATION & REPLACEMENT

Replacing the brush roller is a straightforward process, similar to replacing the original parts. Follow these steps:

1. Ensure your IMAGIC M3/M3 Combo vacuum cleaner is turned off and unplugged.
2. Locate the brush roller cover on the vacuum head.
3. Open the brush roller cover. Depending on your model, this may involve pressing a release button or lifting a latch.
4. Carefully remove the old brush roller by grasping its tab and pulling it out.
5. Insert the new IMAGIC Replacement Brush Roller into the designated slot, ensuring it clicks securely into place.
6. Close the brush roller cover until it latches firmly.

For optimal cleaning performance, it is recommended to replace the brush roller every 3-6 months, depending on usage frequency.

5. OPERATING CONSIDERATIONS

The replacement brush roller is designed to work seamlessly with your IMAGIC M3/M3 Combo vacuum cleaner, enabling its vacuum and wash functions. It effectively removes various types of dirt and sticky messes from sealed hard floors.



Figure 4: The brush roller efficiently cleans dust, hair, lint, chips, and oil stains. For best results, use with IMAGIC Cleaning Solution.

The versatile design allows for cleaning on multiple sealed hard floor surfaces, including hardwood, marble, tile, and laminate.




Figure 5: The brush roller is effective on hardwood, marble, tile, and laminate floors.

6. MAINTENANCE

Proper maintenance of your brush roller extends its lifespan and ensures consistent cleaning quality:

- **Cleaning:** After each use, remove the brush roller and rinse it thoroughly under running water to remove any trapped debris or residue.
- **Drying:** Ensure the brush roller is completely air-dried before reassembling it into the vacuum cleaner. This prevents odors and maintains hygiene.
- **Replacement:** Replace the brush roller every 3-6 months for optimal cleaning efficiency.



Figure 6: The brush roller is washable and reusable. Always air-dry after washing to prevent odors.

7. TROUBLESHOOTING

If you experience issues with your replacement brush roller, consider the following:

- **Reduced Cleaning Performance:** Check if the brush roller is clogged with hair or debris. Clean it thoroughly. If performance does not improve, it may be time for a replacement.
- **Unusual Noise:** Ensure the brush roller is correctly installed and free from obstructions. Remove and re-install to confirm proper seating.
- **Improper Fit:** Double-check that your vacuum cleaner model is indeed an IMAGIC M3 or M3 Combo. This brush roller is not compatible with other models.

8. SPECIFICATIONS

Attribute	Detail
Product Dimensions	2.76 x 2.76 x 13.58 inches
Item Weight	5.4 ounces
Manufacturer	IMAGIC
Item Model Number	M3-BR
Material	ABS, Nylon
Number of Pieces	1

9. SUPPORT

For any inquiries or assistance, IMAGIC offers prompt customer service:

- **Online Phone Support:** Monday to Friday, 8:00 AM to 8:00 PM PST
- **Email Service:** Available 24/7

Please refer to your product packaging or the official IMAGIC website for specific contact details.

