

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chivari](#) /

› [Chivari Plastic Folding Chair Instruction Manual](#)

## Chivari Plastic Folding Chair

# Chivari Plastic Folding Chair Instruction Manual

Model: Plastic Folding Chair

## 1. INTRODUCTION

Thank you for choosing the Chivari Plastic Folding Chair. This manual provides essential information for the safe and effective use, setup, and maintenance of your new chairs. Please read these instructions carefully before use and retain them for future reference.

## 2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- **Maximum Weight Capacity:** The chair is designed to support a maximum weight of **650 lbs (approximately 295 kg)**. Do not exceed this limit to prevent injury or damage to the chair.
- **Assembly:** Always ensure the chair is fully unfolded and locked into position before use. Refer to the setup instructions.
- **Stacking:** When stacking chairs, exercise caution to prevent tipping. Stack chairs on a flat, stable surface.
- **Surface Use:** Ensure the chair is placed on a stable, level surface to prevent wobbling or tipping.
- **Children:** Supervise children when they are using or near the chairs.
- **Inspection:** Before each use, inspect the chair for any signs of damage, loose parts, or wear. Do not use a damaged chair.

## 3. PRODUCT OVERVIEW

The Chivari Plastic Folding Chair is a versatile and durable seating solution suitable for both indoor and outdoor environments. Its robust steel frame and high-density plastic construction ensure longevity and stability. The chair's foldable design allows for easy storage and transport, while its stackable feature optimizes space when not in use.



Image 3.1: An unfolded Chivari Plastic Folding Chair next to a stack of ten folded chairs, demonstrating its compact storage capability.

## 4. SETUP AND FOLDING INSTRUCTIONS

---

### 4.1. Unfolding the Chair

1. Place the folded chair on a flat, stable surface with the seat facing upwards.
2. Gently pull the backrest upwards and away from the seat.
3. As the backrest moves up, the front legs will extend downwards.
4. Push the seat downwards until it is fully flat and the chair legs are securely locked in their open position. You should hear or feel a click indicating it is locked.
5. Before sitting, ensure all four legs are firmly on the ground and the chair is stable.



Image 4.1: A single Chivari Plastic Folding Chair in its fully unfolded and ready-to-use state.

## 4.2. Folding the Chair for Storage

1. Ensure no one is sitting on the chair.
2. Lift the backrest slightly upwards.
3. Gently push the seat upwards towards the backrest. The legs will begin to fold inwards.
4. Continue folding until the chair is compact.
5. For storage, stack folded chairs vertically to save space.

## 5. OPERATING AND USAGE GUIDELINES

---

- **Intended Use:** These chairs are designed for temporary seating for adults.
- **Indoor/Outdoor:** Suitable for both indoor and outdoor use. For outdoor use, avoid prolonged exposure to extreme weather conditions to extend product life.
- **Sitting Posture:** Sit centrally on the seat with your back against the backrest for optimal comfort and stability.
- **Avoid Standing:** Do not stand on the chair, as this can lead to instability and potential injury.
- **Movement:** Do not drag the chair across rough surfaces, as this may damage the leg caps or frame. Lift and carry when moving.

## 6. MAINTENANCE AND CARE

---

- **Cleaning:** Wipe down the plastic seat and backrest with a damp cloth and mild soap. Rinse with clean water and dry thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Frame Care:** The steel frame is powder-coated for durability. If scratches occur, touch up with rust-inhibiting paint to prevent corrosion.
- **Storage:** When not in use, store chairs in a dry, protected area to prolong their lifespan, especially if used outdoors.
- **Regular Checks:** Periodically check all bolts and connections to ensure they are tight. Tighten if necessary.

## 7. TROUBLESHOOTING

---

- **Chair Wobbles:**
  - Ensure the chair is placed on a flat, even surface.
  - Check that all legs are fully extended and locked into position.
  - Inspect for any bent frame components or damaged leg caps.
- **Difficulty Folding/Unfolding:**
  - Ensure there are no obstructions in the folding mechanism.
  - Apply a small amount of silicone-based lubricant to moving parts if stiffness persists, avoiding contact with seating surfaces.
- **Rust Spots on Frame:**
  - Clean the area thoroughly and apply rust-inhibiting paint.
  - Store chairs in a dry environment to prevent future rust.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Chivari
<b>Model</b>	Plastic Folding Chair
<b>Maximum Weight Capacity</b>	650 lbs (295 kg)
<b>Material</b>	High-Density Plastic (Seat/Back), Powder-Coated Steel (Frame)
<b>Features</b>	Foldable, Stackable, Portable
<b>Usage</b>	Indoor, Outdoor

<b>Dimensions (Unfolded)</b>	<i>(Specific dimensions not provided in source data, approximate standard folding chair size)</i>
<b>UPC</b>	810168611198
<b>ASIN</b>	B0D74GPFGW

## 9. WARRANTY AND SUPPORT

---

For warranty information, product support, or to report any issues, please contact Chivari customer service through the retailer where the product was purchased. Please have your purchase receipt and product model information (B0D74GPFGW) available when contacting support.

For additional information, you may visit the [product page on Amazon](#).

© 2024 Chivari. All rights reserved.