

Aiwa AWKF4B

Aiwa AW-KF4 Portable Bluetooth Speaker User Manual

Model: AW-KF4 (AWKF4B)

Brand: Aiwa

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Aiwa AW-KF4 Portable Bluetooth Speaker. Please read this manual thoroughly before using the product and retain it for future reference.

The Aiwa AW-KF4 is a portable Bluetooth speaker designed for robust audio performance with dynamic LED lighting, a rechargeable battery, and resistance to water and dust (IPX6). It offers versatile connectivity options including Bluetooth, USB, and AUX input.

PACKAGE CONTENTS

Carefully unpack your speaker and ensure all items are present and in good condition. If any items are missing or damaged, please contact your retailer.

- Aiwa AW-KF4 Portable Bluetooth Speaker
- USB-C Charging Cable
- Instruction Manual



Image: The Aiwa AW-KF4 speaker in its retail packaging, showing the speaker and branding.

PRODUCT OVERVIEW

The Aiwa AW-KF4 speaker features a compact, cylindrical design with integrated controls and dynamic LED lighting. It is built for portability and durability.




Image: A red Aiwa AW-KF4 speaker showing its approximate dimensions: 21 cm in length and 8.7 cm in diameter.



Image: Two Aiwa AW-KF4 speakers (red and black) illustrating key features: 20W output, LED lighting, TWS function, IPX6 water resistance, Bluetooth, USB, and SD card compatibility.



Resistencia IPX6

Apto para exteriores resistente al agua y al polvo.

Batería

Hasta 10 horas de reproducción con batería de 2000 mAh

Manos Libres

Con micrófono integrado, mantente siempre conectado sin dejar de lado la música.

Image: A collage showing the Aiwa AW-KF4 speaker in various outdoor settings, emphasizing its IPX6 water resistance, up to 10 hours of battery life, and hands-free calling capability with an integrated microphone.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB-C cable to connect the speaker to a compatible USB power adapter (not included) or a computer's USB port.

- The charging indicator light will illuminate during charging.
- A full charge takes approximately 3 hours.
- Once fully charged, the indicator light may change or turn off.

A fully charged battery provides up to 10 hours of playback, depending on volume level and usage.

2. Power On/Off

- To power on: Press and hold the Power button for a few seconds until you hear an audible prompt and the LED lights activate.
- To power off: Press and hold the Power button for a few seconds until you hear an audible prompt and the LED lights turn off.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is connected. The LED indicator will flash, indicating it's ready to pair.

1. Ensure the speaker is powered on and in pairing mode.
2. Enable Bluetooth on your smartphone, tablet, or other audio device.
3. Search for "AW-KF4" in the list of available Bluetooth devices.
4. Select "AW-KF4" to connect. You will hear a confirmation sound once paired.
5. The LED indicator will stop flashing and remain solid.

The speaker has a Bluetooth range of up to 10 meters (33 feet).

2. True Wireless Stereo (TWS) Function

The TWS function allows you to pair two Aiwa AW-KF4 speakers together for a stereo sound experience.



Image: A visual representation of the TWS (True Wireless Stereo) function, showing two Aiwa AW-KF4 speakers

being used together for synchronized sound.

1. Ensure both AW-KF4 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available, or a designated button as per specific model instructions) until you hear a pairing tone.
3. The two speakers will automatically connect to each other. A confirmation tone will sound once connected.
4. Now, connect your Bluetooth device to the primary speaker as described in the "Bluetooth Pairing" section.

Note: Refer to the specific button layout on your speaker for the exact TWS pairing button.

3. USB and AUX Playback

- **USB Playback:** Insert a USB flash drive containing audio files into the USB port. The speaker will automatically detect and begin playing music from the drive.
- **AUX Playback:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX input port. The speaker will switch to AUX mode.

4. LED Lights

The speaker features dynamic LED lights. These lights typically activate automatically when the speaker is powered on. Specific controls for changing light modes or turning them off may be available via a dedicated button on the speaker (refer to your speaker's button layout).

5. Controls

The speaker features tactile controls for various functions:

- **Power Button:** Press and hold to power on/off.
- **Play/Pause Button:** Press to play or pause music.
- **Volume Up/Next Track:** Press to increase volume. Press and hold for next track.
- **Volume Down/Previous Track:** Press to decrease volume. Press and hold for previous track.
- **Mode Button:** Press to switch between Bluetooth, USB, and AUX modes.
- **Call Button (if applicable):** Press to answer/end calls. Press and hold to reject calls.

Note: Button functions may vary slightly. Consult the diagrams in your physical manual for precise button identification.

MAINTENANCE

To ensure the longevity and optimal performance of your Aiwa AW-KF4 speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Water Resistance (IPX6):** The speaker is resistant to strong water jets. It is not designed for submersion. Ensure all port covers are securely closed before exposing the speaker to water or dust. After exposure to water, wipe the speaker dry before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme

temperatures.

- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.



Image: The Aiwa AW-KF4 speaker positioned near a pool, illustrating its IPX6 water resistance feature, suitable for outdoor and poolside use.

TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Speaker does not power on.	<ul style="list-style-type: none">• Battery is depleted. Charge the speaker fully.• Power button not pressed long enough. Press and hold for a few seconds.
Cannot pair via Bluetooth.	<ul style="list-style-type: none">• Speaker is not in pairing mode. Power cycle the speaker.• Bluetooth is off on your device. Enable Bluetooth.• Speaker is already connected to another device. Disconnect from other devices.• Device is out of range. Move your device closer to the speaker (within 10 meters).

Problem	Possible Cause / Solution
No sound.	<ul style="list-style-type: none"> • Volume is too low on the speaker or connected device. Increase volume. • Speaker is not properly connected (Bluetooth, USB, AUX). Re-establish connection. • Incorrect mode selected. Press the Mode button to cycle through inputs.
Sound distortion.	<ul style="list-style-type: none"> • Volume is too high. Reduce volume on the speaker or connected device. • Low battery. Charge the speaker. • Device is too far from the speaker (Bluetooth). Move closer.
TWS pairing fails.	<ul style="list-style-type: none"> • Ensure both speakers are AW-KF4 models and not connected to any other Bluetooth device. • Ensure both speakers are within close proximity to each other. • Try powering both speakers off and on again, then re-attempt TWS pairing.

SPECIFICATIONS

Model Name	AW-KF4 (AWKF4B)
Brand	Aiwa
Speaker Output Power	20 Watts RMS
Frequency Response	80 Hz (minimum specified)
Connectivity Technology	Bluetooth 5.0, USB, AUX
Audio Output Mode	Stereo
Housing Material	Plastic
Speaker Type	Woofers
Water Resistance Level	IPX6 (Resistant to strong water jets)
Bluetooth Range	Up to 10 meters (33 feet)
Microphones	1 (for hands-free calling)
Battery Capacity	2000 mAh Lithium Ion
Battery Life	Up to 10 hours (varies with volume and usage)
Charging Time	Approximately 3 hours

Input Voltage	5 Volts
Impedance	4 Ohms
Control Method	Tactile Buttons
Dimensions (L x D)	Approx. 21 cm x 8.7 cm
Compatible Devices	Smartphones, Tablets
Origin	China

WARRANTY AND SUPPORT

Your Aiwa AW-KF4 Portable Bluetooth Speaker comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

The warranty does not cover:

- Damage caused by misuse, abuse, negligence, or accident.
- Damage from unauthorized repairs or modifications.
- Normal wear and tear.

For warranty claims or technical support, please contact your retailer or the official Aiwa customer service in your region. Please have your proof of purchase and product model number (AW-KF4) ready when contacting support.