



[Manuals.plus](#) /

> [HOFFREE](#) /

> [HOFFREE N102-Max Gaming Chair Instruction Manual](#)

## HOFFREE N102-Max

# HOFFREE N102-Max Gaming Chair Instruction Manual

Model: N102-Max

[Safety Information](#)   [Package Contents](#)   [Setup & Assembly](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. SAFETY INFORMATION

---

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Weight Limit:** Do not exceed the maximum weight capacity of 350 lbs (158 kg).
- **Height Recommendation:** Suitable for users between 5 ft and 6 ft 3 in (152 cm - 190 cm).
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Regularly check for loose screws and tighten as necessary.
- **Stability:** Avoid standing on the chair or using it as a step stool. Do not lean excessively to one side when reclining.
- **Children:** Keep children away from moving parts during assembly and adjustment. Adult supervision is recommended when children are near the chair.
- **Electrical Components:** The RGB LED lights and massage function are USB powered. Ensure proper connection and avoid exposing electrical components to liquids.
- **Cleaning:** Use a soft, damp cloth for cleaning. Avoid harsh chemicals or abrasive cleaners.

## 2. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Image: All components of the HOFFFREE Gaming Chair laid out for assembly. This includes the seat, backrest, armrests, base, wheels, gas lift, footrest, lumbar cushion, headrest pillow, and hardware kit.

The package typically includes:

- Backrest
- Seat Cushion with attached mechanism
- Armrests (Left and Right)
- Star Base
- Casters (Wheels)
- Gas Lift Cylinder with cover
- Footrest Assembly
- Lumbar Massage Cushion
- Headrest Pillow
- Hardware Kit (screws, Allen wrench)
- RGB LED Remote Control

### 3. SETUP & ASSEMBLY

---

Follow these steps to assemble your HOFFFREE Gaming Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

#### 3.1. Assemble the Chair Base

1. Insert the five legs into the central hub of the star base. Secure them with the provided screws using the Allen wrench.
2. Push the five casters (wheels) into the holes at the end of each leg until they click into place.
3. Insert the gas lift cylinder into the center hole of the assembled star base. Place the gas lift cover over the cylinder.

Your browser does not support the video tag.

Video: Assembly instructions for the HOFFFREE Gaming Chair, demonstrating the attachment of the base, casters, and gas lift. This video also shows the attachment of the footrest, armrests, and cushions.

#### 3.2. Attach the Footrest

1. Locate the footrest assembly. Align the metal bars with the designated attachment points on the underside of the

seat cushion.

2. Secure the footrest to the seat using the provided screws.

### **3.3. Attach the Seat Mechanism**

1. Align the seat mechanism with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat.
2. Secure the mechanism using the provided screws.

### **3.4. Connect Seat to Base**

1. Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and firmly seated.

### **3.5. Attach the Armrests**

1. Identify the left (L) and right (R) armrests.
2. Align each armrest with the corresponding holes on the side of the seat and backrest.
3. Secure the armrests using the provided screws.

### **3.6. Connect Electrical Components**

1. Locate the USB cables for the RGB LED lights and the massage function.
2. Connect the corresponding cables. The RGB lights typically have a separate controller for the remote.
3. Plug the USB cable into a power source (e.g., computer USB port, USB wall adapter, power bank).

### **3.7. Attach Lumbar Cushion and Headrest Pillow**

1. Attach the lumbar massage cushion to the backrest using its straps and buckles. Position it to support your lower back.
2. Attach the headrest pillow to the top of the backrest using its straps.

## **4. OPERATING INSTRUCTIONS**

---

### **4.1. Height Adjustment**

To adjust the chair height, pull the lever located on the right side of the seat mechanism upwards. While holding the lever, apply weight to lower the chair or lift your weight to raise it. Release the lever to lock the height.

### **4.2. Backrest Recline**

To recline the backrest, pull the lever located on the left side of the seat mechanism upwards. Lean back to your desired angle (90° to 135°). Release the lever to lock the backrest in position.



Image: Illustration of the chair's recline functionality, showing working (90°), gaming (115°), and resting (135°) positions.

### 4.3. Footrest Operation

To extend the footrest, pull it out from underneath the seat. To retract, push it back in until it is fully stored.



Image: A close-up view demonstrating the retractable footrest mechanism, showing arrows indicating extension and retraction.

### 4.4. RGB LED Lights

The RGB LED lights are controlled by the included remote. Ensure the USB power cable is connected. The remote allows you to:

- Turn lights On/Off
- Adjust Speed Control
- Adjust Brightness Control
- Change Color Control (338 modes including Dot Light, Cycle Color, Single Color, Multiple Color)
- Select Auto Mode or 7 Static Monochrome Modes




Image: The HOFFFREE Gaming Chair with its remote control, highlighting the various functions for adjusting LED light modes, speed, and brightness.

The effective distance for the remote control is approximately 32 feet (10 meters).

#### 4.5. Lumbar Massage Function

The lumbar cushion features a 2-point vibrating massage function. Ensure the USB power cable for the massage function is connected. The massage function is typically activated via an on/off switch located on its power cord.



Image: A close-up view of the lumbar massage cushion, showing the two vibrating motors designed to relieve fatigue.

Your browser does not support the video tag.

Video: Demonstration of the HOFFFREE LED Gaming Chair, showcasing the RGB lighting effects and the lumbar massage function.

## 5. MAINTENANCE

- **Cleaning:** Wipe the chair's surface with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Do not use abrasive cleaners or solvents.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten any loose hardware to maintain stability and safety.
- **Caster Care:** Keep the casters clean from hair and debris to ensure smooth movement.

- **Gas Lift:** The gas lift is maintenance-free. Do not attempt to disassemble it.
- **Electrical Components:** Ensure USB cables are not pinched or damaged. Disconnect power when cleaning or moving the chair.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift not engaged or faulty.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact support.
Backrest does not recline or lock.	Recline lever not fully engaged or mechanism jammed.	Ensure the recline lever is fully pulled. Check for any obstructions in the recline mechanism.
RGB LED lights are not working.	USB power disconnected, remote battery low, or faulty connection.	Verify the USB cable is securely plugged into a power source. Check the remote control battery. Ensure all electrical connections are secure.
Lumbar massage function is not working.	USB power disconnected or on/off switch not activated.	Ensure the USB cable for the massage function is connected and the on/off switch on the cord is in the 'on' position.
Chair is wobbly or unstable.	Loose screws or improper assembly.	Check and tighten all assembly screws, especially those connecting the seat to the mechanism and the armrests. Ensure the gas lift is properly seated in the base.

## 7. SPECIFICATIONS

Feature	Detail
Model Name	N102-Max
Brand	HOFFREE
Color	Red + Black
Product Dimensions (D x W x H)	17.72" x 16.93" x 51.57" (45 cm x 43 cm x 131 cm)
Maximum Weight Recommendation	350 lbs (158 kg)
Recommended User Height	5 ft - 6 ft 3 in (152 cm - 190 cm)
Material	Leather (PU), Cotton, Foam, Metal Frame
Special Features	Adjustable Lumbar, Colorful RGB LED Lights, Ergonomic Design, Foot Rest, Heavy Duty, Linkage Armrest, 2-Point Lumbar Massage
Reclining Angle	90° to 135°

Feature	Detail
Swivel	360-degree
Gas Lift	SGS Certified
Power Source (Lights/Massage)	USB
Product Care	Wipe Clean



Image: Technical drawing illustrating the various dimensions of the HOFFFREE Gaming Chair, including height, width, and depth, along with the 350 lbs load capacity.

## 8. WARRANTY & SUPPORT

HOFFFREE provides an **18-month service period** for this product. If you encounter any problems during assembly or use,

please contact our customer service team.

Our service team aims to reply within 24 hours to assist you with any inquiries or issues.

For support, please visit the HOFFREE Store on Amazon or contact us through the platform where you purchased the product.

**HOFFREE Store:** [HOFFREE Official Store](#)

