

Herdio HE-RS6BTB

Herdio Outdoor Rock Bluetooth Speakers User Manual

Model: HE-RS6BTB | Brand: Herdio

INTRODUCTION

Thank you for choosing Herdio Outdoor Rock Bluetooth Speakers. These speakers are designed to provide high-quality audio in outdoor environments, featuring IPX7 waterproofing and a durable resin material that blends seamlessly with your garden or patio. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your speakers to ensure optimal performance and longevity.

SAFETY INFORMATION

- Ensure all connections are secure and waterproof before exposing speakers to moisture.
- Do not attempt to open or repair the speakers yourself. Refer all servicing to qualified personnel.
- Keep speakers away from extreme heat sources or open flames.
- Position cables safely to prevent tripping hazards.
- Unplug the speakers from the power source during lightning storms or when unused for long periods.

WHAT'S IN THE BOX




The image above displays the typical contents of your Herdio Outdoor Rock Bluetooth Speakers package.

- Main Speaker (Active) x 1
- Sub Speaker (Passive) x 1
- 5M Waterproof Speaker Connection Cable x 1

- 2.5M Waterproof Charging Power Cable x 1
- Instruction Manual x 1

SETUP

1. Placement



This image illustrates ideal placement scenarios for the Herdio rock speakers in different outdoor environments.

Place the speakers in your desired outdoor location, such as a garden, patio, or by the pool. For optimal stereo separation, speakers should typically be spaced between 8 and 12 feet apart. The realistic rock design allows them to blend naturally into the landscape.

2. Connection



The diagram above demonstrates the simple plug-and-play connection process for the speakers.


1. Connect the Main Speaker (Active) to a suitable outdoor power outlet using the provided 2.5M Waterproof Charging Power Cable.
2. Connect the Sub Speaker (Passive) to the Main Speaker using the 5M Waterproof Speaker Connection Cable. Ensure the arrows on the connectors are aligned for a proper waterproof seal.



This image highlights the importance of aligning the arrows on the waterproof cable connectors during setup to ensure a secure and sealed connection.

OPERATING INSTRUCTIONS

Bluetooth Pairing



The diagram illustrates the stable Bluetooth connection process between your device and the speakers.

1. Once the speakers are powered on, they will automatically enter Bluetooth pairing mode.
2. On your smartphone, tablet, or laptop, navigate to the Bluetooth settings.
3. Look for "Herdio RS6BTB" (or similar) in the list of available devices and select it to pair.
4. A confirmation sound will indicate successful pairing.
5. You can now play audio from your device through the Herdio speakers. The Bluetooth range is approximately 20 meters (65 feet) for stable connection.

Note: There is no physical power button on the speakers. They are designed to be continuously powered when plugged in. To turn them off, unplug the power cable.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to wipe down the speaker surfaces. Avoid abrasive cleaners or solvents.
- **Weather Protection:** While IPX7 waterproof, it is recommended to bring the speakers indoors during extreme weather conditions (e.g., heavy snow, prolonged freezing temperatures) to extend their lifespan.
- **Cable Inspection:** Periodically check the power and connection cables for any signs of wear or damage. Replace if necessary.

TROUBLESHOOTING


Problem	Possible Cause	Solution
No Sound	Speakers not powered on. Bluetooth not connected. Volume too low. Cables not properly connected.	Ensure speakers are plugged into a live power outlet. Re-pair Bluetooth device. Increase volume on both the speaker and your device. Check all cable connections, ensuring they are secure.
Bluetooth Disconnection	Device out of range. Interference.	Move your Bluetooth device closer to the speakers (within 65 feet). Avoid placing speakers near other strong wireless devices.
Distorted Sound	Volume too high. Poor audio source quality.	Reduce volume on both the speaker and your device. Try a different audio source or file.

SPECIFICATIONS



This image provides a visual overview of the speaker's internal structure and its technical specifications.

- **Model Name:** HE-RS6BTB
- **Speaker Type:** Outdoor Rock Bluetooth Speaker
- **Power Output:** 400 Watts Peak Power (200 Watts per speaker)
- **Bluetooth Version:** 5.3
- **Bluetooth Range:** Up to 20 meters (65 feet)
- **Water Resistance:** IPX7 Waterproof
- **Material:** Resin and Fiber
- **Impedance:** 4 Ohm
- **Frequency Response:** 65 Hz - 10 KHz
- **Sensitivity:** 88 dB
- **Product Dimensions:** 12.9"D x 11"W x 10.6"H (approx.)
- **Item Weight:** 23.7 pounds (pair)
- **Color:** Black



This image provides a detailed view of the speaker's dimensions.

WARRANTY AND SUPPORT

Herdio products come with a limited warranty. For specific warranty details and duration, please refer to the warranty card included with your product or contact Herdio customer support.





For technical assistance, troubleshooting, or any inquiries regarding your Herdio Outdoor Rock Bluetooth Speakers, please visit the official Herdio website or contact their customer service department. Contact information can typically be found on the product packaging or the Herdio brand store on Amazon.

Herdio Direct: [Seller Information](#)



Related Documents - HE-RS6BTB

	<p>Herdio Waterproof Indoor Outdoor Speakers Owner's Manual HOS-401 HOS-501 HOS-601</p> <p>This owner's manual provides detailed instructions for the Herdio HOS-401, HOS-501, and HOS-601 waterproof indoor/outdoor speakers, covering installation, wiring, setup, specifications, and warranty information.</p>
	<p>Herdio High Performance In-Ceiling/In-Wall Speakers - Owner's Manual and Installation Guide</p> <p>This document provides installation instructions, technical specifications, and warranty information for Herdio's high-performance in-ceiling and in-wall speaker systems, including models like HCS418, HCS528, HCS628, and HCS828, with and without Bluetooth connectivity.</p>

 <p>Herdio® 6.5 inch / 8 inch Bluetooth Rock Speaker Series Quick Start Guide</p> <p>MODELS: RS6 / RS8 / RS6G / RS8G</p> <p>Wiring the Speakers</p> <ol style="list-style-type: none"> 1. Connect the speakers to the amplifier using the provided speaker cables. Make sure the polarity is correct. 2. The speakers should be connected to the amplifier in the following order: RS6 (Left), RS8 (Right), RS6G (Left), RS8G (Right). 3. The speakers should be connected to the amplifier in the following order: RS6 (Left), RS8 (Right), RS6G (Left), RS8G (Right). 4. The speakers should be connected to the amplifier in the following order: RS6 (Left), RS8 (Right), RS6G (Left), RS8G (Right). <p>Initial Set-Up</p> <ol style="list-style-type: none"> 1. Turn on the power to the amplifier. 2. Turn on the power to the speakers. 3. Turn on the power to the Bluetooth device. 4. Turn on the power to the Bluetooth device. <p>WARRANTY</p> <p>Herdiotech, Inc. warrants that the product is free from defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty is void if the product is damaged, altered, or misused. For more information, please contact Herdiotech, Inc. at sales@herdiotech.com or www.Herdiotech.com.</p>	<p>Herdio 6.5 & 8 Inch Bluetooth Rock Speaker Series Quick Start Guide</p> <p>This guide provides setup and wiring instructions for Herdio 6.5-inch and 8-inch Bluetooth Rock Speaker Series, including models RS6GBT, RS8GBT, RS6G, and RS8G. Learn how to connect your speakers, pair Bluetooth devices, and understand the product's technical specifications and warranty.</p>
 <p>Herdio® Home Bluetooth Ceiling/Wall Speakers (2 Pair) Dual Amplifier System Wiring Program</p> <p>Bluetooth Operations</p> <ol style="list-style-type: none"> 1. Turn on the power to the amplifier. 2. Turn on the power to the speakers. 3. Turn on the power to the Bluetooth device. 4. Turn on the power to the Bluetooth device. <p>WARRANTY</p> <p>Herdiotech, Inc. warrants that the product is free from defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty is void if the product is damaged, altered, or misused. For more information, please contact Herdiotech, Inc. at sales@herdiotech.com or www.Herdiotech.com.</p>	<p>Herdio Home Bluetooth Ceiling/Wall Speakers Dual Amplifier System Wiring Program</p> <p>This document outlines the wiring program and Bluetooth operations for Herdio Home Bluetooth In Ceiling/Wall Speakers, featuring a dual amplifier system. It provides step-by-step instructions for connecting speakers, amplifier boxes, and power adapters, along with guidance on pairing Bluetooth devices.</p>
 <p>Herdio® 6.5 inch / 8 inch Bluetooth Rock Speaker Series Quick Start Guide</p> <p>MODELS: RS6 / RS8 / RS6G / RS8G</p> <p>Wiring the Speakers</p> <ol style="list-style-type: none"> 1. Connect the speakers to the amplifier using the provided speaker cables. Make sure the polarity is correct. 2. The speakers should be connected to the amplifier in the following order: RS6 (Left), RS8 (Right), RS6G (Left), RS8G (Right). 3. The speakers should be connected to the amplifier in the following order: RS6 (Left), RS8 (Right), RS6G (Left), RS8G (Right). 4. The speakers should be connected to the amplifier in the following order: RS6 (Left), RS8 (Right), RS6G (Left), RS8G (Right). <p>Initial Set-Up</p> <ol style="list-style-type: none"> 1. Turn on the power to the amplifier. 2. Turn on the power to the speakers. 3. Turn on the power to the Bluetooth device. 4. Turn on the power to the Bluetooth device. <p>WARRANTY</p> <p>Herdiotech, Inc. warrants that the product is free from defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty is void if the product is damaged, altered, or misused. For more information, please contact Herdiotech, Inc. at sales@herdiotech.com or www.Herdiotech.com.</p>	<p>Herdio 6.5 inch / 8 inch Bluetooth Rock Speaker Series Quick Start Guide</p> <p>Quick start guide for Herdio Bluetooth Rock Speakers, covering setup, wiring, and technical specifications for the 6.5-inch and 8-inch series. Includes warranty information and model details.</p>
 <p>Herdio® 1618 In-Wall Bluetooth Audio Amplifier Receiver System User Manual & Specifications</p> <p>Model 2AYZ2-1618</p> <p>Features</p> <ul style="list-style-type: none"> • Bluetooth pairing • FM/AM radio • USB/AUX input • 160W power output <p>Specifications</p> <ul style="list-style-type: none"> • Power: 160W • Frequency: 20Hz - 20kHz • Impedance: 16Ω <p>WARRANTY</p> <p>Herdiotech, Inc. warrants that the product is free from defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty is void if the product is damaged, altered, or misused. For more information, please contact Herdiotech, Inc. at sales@herdiotech.com or www.Herdiotech.com.</p>	<p>Herdio 1618 In-Wall Bluetooth Audio Amplifier Receiver System - User Manual & Specifications</p> <p>Detailed user manual and technical specifications for the Herdio 1618 In-Wall/Wall Mount BT Audio Control Amplifier Receiver System (Model 2AYZ2-1618). Learn about features, installation, power, Bluetooth pairing, and FCC compliance.</p>