

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lyromix](#) /

› [Lyromix 36-Inch Mini Trampoline with Handle Instruction Manual](#)

Lyromix Lyromix 36-Inch Mini Trampoline with Handle

Lyromix 36-Inch Mini Trampoline with Handle Instruction Manual

INTRODUCTION

Welcome to your new Lyromix 36-Inch Mini Trampoline with Handle. This manual provides essential information for the safe assembly, operation, and maintenance of your trampoline. Please read all instructions carefully before use to ensure a safe and enjoyable experience for your child.

IMPORTANT SAFETY INFORMATION

General Safety Guidelines

- Adult supervision is required at all times.
- Only one user at a time.
- Ensure the trampoline is placed on a flat, stable surface.
- Keep clear of walls, furniture, and other obstacles.
- Do not attempt somersaults or other dangerous maneuvers.
- Inspect the trampoline regularly for wear and tear.

Product Specific Safety Features

The Lyromix Mini Trampoline is designed with enhanced safety features:

- **Cushioned Handrail:** Provides extra stability and a secure grip for users.
- **Six Additional Legs:** Offers increased stability and helps prevent tipping or rollovers.
- **Gap-Free Design:** The spring cover ensures no gaps, protecting users from springs.
- **Non-slip Rubber Tips:** On the legs to prevent movement during use.



Image: Lyromix Mini Trampoline with detailed view of safety features: foam for firm grip, gap-free design, sturdy metal frame, and non-slip rubber tips.

WHAT'S IN THE BOX

Your Lyromix Mini Trampoline package includes:

- 1 x Toddler Trampoline (main frame, jumping mat, springs, safety pad)
- 6 x Legs with non-slip rubber tips
- 1 x Cushioned Handrail assembly
- Assembly Hardware (bolts, washers, tools)
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Assembly is straightforward and typically takes about 10-15 minutes. Two adults are recommended for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the "What's in the Box" list.

2. **Attach Legs:** Securely bolt the six legs to the main trampoline frame. Ensure all bolts are tightened.
3. **Install Handrail:** Attach the cushioned handrail to the designated points on the trampoline frame. Ensure it is firmly in place and stable.
4. **Final Check:** Before first use, ensure all connections are secure and the trampoline is stable on a flat surface.

OPERATING INSTRUCTIONS

Using the Trampoline

- Ensure the trampoline is placed on a level, non-slip surface, indoors or outdoors.
- Children should always be supervised by an adult.
- Encourage children to hold onto the handrail for stability, especially when first learning to jump.
- Teach children to jump in the center of the mat.
- Do not allow more than one child on the trampoline at a time.




Image: A child jumping on the Lyromix Mini Trampoline indoors and another child jumping outdoors, illustrating versatile use.



Image: A child happily jumping on the Lyromix Mini Trampoline, with icons indicating benefits like improved mental wellness, enhanced physical fitness, and enjoying happy childhood.

MAINTENANCE

- **Regular Inspection:** Periodically check all bolts, nuts, and connections to ensure they are tight. Inspect the jumping mat, springs, and safety pad for any signs of wear, tears, or damage.
- **Cleaning:** Clean the jumping mat and frame with a damp cloth and mild soap. Avoid harsh chemicals.
- **Storage:** If used outdoors, consider storing the trampoline indoors during harsh weather conditions to prolong its lifespan. The handrail can be easily removed for more compact storage.



Image: Main product image of the Lyromix 36-Inch Mini Trampoline in bright blue with a handle.

TROUBLESHOOTING

Common Issues and Solutions

- **Trampoline is unstable:** Ensure all legs are securely attached and tightened. Verify the trampoline is on a flat, level surface.
- **Squeaking noises:** Check all connections and apply a small amount of lubricant (e.g., silicone spray) to moving parts if necessary, avoiding the jumping mat.
- **Reduced bounce:** Over time, springs may lose some tension. Ensure all springs are intact and properly attached. Replace any damaged springs.

Maximize Fun
Minimize Space

Meet your kids' bouncing needs



Image: Lyromix Mini Trampoline with dimensions labeled: 36 inches width, 32.3 inches height, and 7.5 inches mat height.

SPECIFICATIONS

Feature	Detail
Brand	Lyromix
Model Name	Kids Trampoline for Toddler
Color	Bright Blue
Frame Size	36 Inches
Product Dimensions	36"L x 36"W x 30"H
Frame Material	Metal
Jumping Mat Material	High Tensile Steel Springs, PP Cover

Feature	Detail
Item Weight	6 Pounds
Maximum Weight Recommendation	150 Pounds
Number Of Springs	30
UPC	797424037780
Included Components	1 Toddler Trampoline

WARRANTY AND SUPPORT

Warranty Information

This Lyromix Mini Trampoline comes with a 3-month warranty. Please retain your proof of purchase for any warranty claims.

Customer Support

For further assistance, questions, or to report any issues, please contact Lyromix customer support through the retailer's platform or visit the official Lyromix store online.

[Visit the Lyromix Store](#)