

Lenovo ThinkCentre M75s Gen 2 SFF Desktop

Lenovo ThinkCentre M75s Gen 2 SFF Desktop User Manual

Model: ThinkCentre M75s Gen 2 SFF Desktop

INTRODUCTION

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Lenovo ThinkCentre M75s Gen 2 SFF Desktop. This compact and powerful desktop is designed for professional and personal use, featuring an AMD Ryzen 5 Pro processor, ample RAM, and a large SSD for high performance and storage capacity.



Figure 1: Lenovo ThinkCentre M75s Gen 2 SFF Desktop with peripherals.

SETUP

Follow these steps to set up your ThinkCentre M75s Gen 2 SFF Desktop:

1. **Unpacking:** Carefully remove the desktop and all accessories from the packaging. Verify that all components listed in the packing slip are present.
2. **Placement:** Place the desktop on a stable, flat surface with adequate ventilation. Ensure that air vents are not obstructed.
3. **Connect Peripherals:**
 - Connect your monitor to the appropriate video output port (e.g., DisplayPort, HDMI) on the rear of the desktop.
 - Connect your keyboard and mouse to the available USB ports.
 - If using wired internet, connect an Ethernet cable to the LAN port.
 - Connect any other desired peripherals such as speakers, printers, or external drives.



Figure 2: Rear view of the desktop illustrating available ports for connectivity.

4. **Power Connection:** Connect the power cord to the desktop's power input and then to a grounded electrical outlet.
5. **First Boot:** Press the power button on the front of the desktop. The system will boot into Windows 10 Pro. Follow the on-screen instructions for initial Windows setup, including language, region, and network configuration.

OPERATING INSTRUCTIONS

This section covers basic operation of your desktop.

Power On/Off

- **Power On:** Press the power button located on the front panel of the desktop.
- **Power Off:** To shut down the system, click the Start button in Windows, then select "Power" and choose "Shut down." Avoid directly unplugging the power cord while the system is running to prevent data loss.
- **Restart:** To restart the system, click the Start button, then select "Power" and choose "Restart."
- **Sleep Mode:** To put the system into sleep mode, click the Start button, then select "Power" and choose "Sleep."

Using the Operating System

Your desktop comes pre-installed with Windows 10 Pro. Familiarize yourself with the Windows interface, including the Start Menu, Taskbar, File Explorer, and Control Panel for system settings.

Connecting to Networks

- **Wired Connection:** Connect an Ethernet cable from your router or modem to the LAN port on the desktop. The connection should be automatically established.
- **Wireless Connection:** If your model includes Wi-Fi, click the network icon in the system tray, select your desired Wi-Fi network, enter the password, and click "Connect."

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your desktop.

- **Cleaning:**
 - Use a soft, dry cloth to clean the exterior of the desktop.
 - For stubborn marks, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
 - Periodically use compressed air to clear dust from vents and ports to maintain proper airflow.
- **Software Updates:** Regularly check for and install Windows updates and driver updates for your hardware. This helps improve security, performance, and compatibility.
- **Data Backup:** Regularly back up important data to an external drive or cloud storage to prevent data loss in case of system failure.
- **Antivirus Protection:** Ensure your antivirus software is up-to-date and perform regular scans to protect against malware.

TROUBLESHOOTING

This section provides solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Desktop does not power on.	No power, faulty power cord, power supply issue.	Ensure power cord is securely connected to both the desktop and the outlet. Try a different outlet. Check power supply unit.
No display on monitor.	Monitor not connected, incorrect input source, faulty cable.	Verify monitor cable is securely connected to both desktop and monitor. Select correct input source on monitor. Test with a different cable or monitor if possible.
System is slow or unresponsive.	Too many programs running, low disk space, malware, outdated drivers.	Close unnecessary applications. Free up disk space. Run a full antivirus scan. Update drivers and Windows. Restart the system.

Problem	Possible Cause	Solution
Peripheral (keyboard/mouse) not working.	Loose connection, faulty device, driver issue.	Try connecting to a different USB port. Test the peripheral on another computer. Reinstall or update drivers for the device.

SPECIFICATIONS

Detailed technical specifications for the Lenovo ThinkCentre M75s Gen 2 SFF Desktop:

Feature	Detail
Model Number	ThinkCentre M75s Gen 2 SFF Desktop
Processor	AMD Ryzen 5 Pro - 4650G (6 cores @ 4.2 GHz)
RAM	64 GB DDR SDRAM
Hard Drive	8 TB SSD (Solid State Drive)
Operating System	Windows 10 Pro
Hardware Platform	PC
Product Dimensions (LxWxH)	16.73 x 6.69 x 14.65 inches
Processor Count	6
First Available Date	March 15, 2025
UPC	657070545926

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Lenovo support website. Keep your proof of purchase for warranty claims.
Lenovo Support Website: www.lenovo.com/support

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What types of Wi-Fi and Bluetooth cards are compatible with my Lenovo ThinkCentre M75s Gen 2 SFF Desktop (Model 11AAS0DM1N, Serial PC1E9BGR)?

For the Lenovo ThinkCentre M75s Gen 2 SFF Desktop, compatibility for Wi-Fi and Bluetooth cards depends on the available expansion slots on your motherboard. According to the product specifications for this series:M.2 Slot:
This...

[Read full answer](#)