

[Manuals.plus](#) /

› [Xilingol](#) /

› Xilingol 6-in-1 Baby Walker Instruction Manual

Xilingol B0D78LV5K3

Xilingol 6-in-1 Baby Walker Instruction Manual

Model: B0D78LV5K3 | Brand: Xilingol

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.


- This product is designed for babies aged 6-18 months.
- Maximum weight recommendation: 33 pounds.
- Always supervise your child when using the walker.
- Ensure all locking mechanisms are securely engaged before placing your child in the walker.
- Keep the walker away from stairs, steps, heat sources, and open flames.
- The walker is certified by ASTM and CPSIA for safety.
- Features a protective safety bumper to shield your baby's head from collisions.
- Ergonomic high backrest provides optimal spine support.
- Five anti-slip foot pads prevent falls and slips.
- Wide wheel spacing ensures stable and secure movement.




Robust and Safe Protection




Ensures Baby's Safety and Comfort



Protective Bumper 2"



Ergonomic 95° Seat



5 Anti-Skip Pads

Figure 1: Robust and Safe Protection features of the walker.

2. PRODUCT OVERVIEW

2.1. 6-in-1 Convertible Design

This versatile baby walker transitions through six modes to support your child's development:

- **Parent Assist Mode:** For guided walking.
- **Self-Walking Mode:** Allows baby to move independently.
- **Dining Chair Mode:** Converts for mealtime.
- **Push Walker Mode:** For toddlers learning to walk.
- **Push Cart Mode:** For pushing and playing.
- **Toy Airplane Mode:** Engaging play mode.



Figure 2: The six convertible modes of the Xilingol Baby Walker.

2.2. Adjustable Height

The walker offers 3 adjustable height positions to accommodate your growing child. The curved seat cushion is designed to prevent O-shaped legs and is removable and washable for easy cleaning. Made from breathable, high-quality PP material, it ensures comfort.



3-Level Adjustable Heights



Grows with Your Child

Recommended Age: 6 -18 Months

Supports Up to

33 LBS



Figure 3: Three adjustable height positions for the walker.

2.3. Music & Lights Activity Center

The walker features realistic airplane controls, including a steering wheel, shifter, rear-view mirrors, and light buttons. Vivid music and lights stimulate your child's senses. The control panel is removable and can be used as a standalone toy or dining tray.



Figure 4: Detachable control panel with interactive features.

3. SETUP AND ASSEMBLY

The Xilingol 6-in-1 Baby Walker is designed for straightforward assembly. Most components snap into place, with a few requiring screws. Typical assembly time is approximately 30 minutes.

3.1. Assembly Video Guide

Your browser does not support the video tag.

Video 1: A detailed guide on assembling the Xilingol 6-in-1 Baby Walker and showcasing its various features.

3.2. Folding for Storage

The walker features a compact folding design for easy storage under a sofa or bed, making it convenient for travel.



Figure 5: Steps for easy folding and storage.

4. OPERATING INSTRUCTIONS

4.1. Switching Modes

Refer to the assembly instructions for detailed steps on converting the walker between its six modes. Ensure all components are correctly secured for each mode.

4.2. Adjusting Height

To adjust the walker's height, locate the adjustment knobs on the side supports. Press the knobs and slide the walker frame up or down to one of the three desired height positions. Ensure both sides are adjusted evenly and securely locked.

4.3. Wheel Adjustment

The walker is equipped with 4 smooth universal wheels. The rear wheels can be adjusted for speed:

- Turn counterclockwise for faster movement.
- Turn clockwise for slower movement.
- Lock the wheels for added safety or stationary play.

The 360° swivel front wheels provide effortless steering.



Figure 6: Details of the adjustable and universal wheels.

4.4. Activity Center Use

To activate music and lights, ensure 2 AA batteries (not included) are installed in the control panel. Press the buttons on the panel to engage sounds and lights. The steering wheel can be rotated, and the shifter moved for interactive play.

5. MAINTENANCE

- The curved seat cushion is removable and washable. Hand wash with mild soap and water, then air dry.
- Wipe down plastic surfaces with a damp cloth and mild soap. Avoid abrasive cleaners.
- Regularly check all parts for wear and tear, especially wheels and locking mechanisms. Replace any damaged parts immediately.
- Ensure the activity panel is kept dry. If batteries are not used for an extended period, remove them to prevent leakage.

6. TROUBLESHOOTING

- **Walker not moving smoothly:** Check if the rear wheels are locked or set to the slowest speed. Ensure no debris is caught in the wheels.
- **Music/Lights not working:** Verify that 2 AA batteries are correctly installed and not depleted. Check the on/off switch on the activity panel.
- **Unstable movement:** Ensure all height adjustment points are securely locked on both sides. Confirm the walker is on a flat, even surface.
- **Difficulty converting modes:** Review the assembly instructions to ensure all release buttons or levers are correctly engaged or disengaged.

7. SPECIFICATIONS

Feature	Detail
Brand	Xilingol
Model Number	B0D78LV5K3
Age Range	6-18 Months
Maximum Weight Recommendation	33 Pounds
Material Type	Acrylonitrile Butadiene Styrene (ABS), Polypropylene (PP)
Item Dimensions (L x W x H)	29"L x 24"W x 22"H
Adjustable Height Positions	3 (20", 21", 22")
Battery Requirement	2 AA Batteries (Not Included)
Color	Grey



Figure 7: Product dimensions and materials.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Xilingol customer service. Refer to the product packaging or the official Xilingol website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D78LV5K3>

More documents and user manuals: **<https://manuals.plus/>**