

[Manuals.plus](#) /

› [VEVSHAO](#) /

› VEVSHAO V30 Mini Projector User Manual

VEVSHAO V30

VEVSHAO V30 Mini Projector User Manual

Model: V30

1. INTRODUCTION

Thank you for choosing the VEVSHAO V30 Mini Projector. This portable DLP projector offers a 1920x1080P resolution, smart Android 9.0 system, built-in 15000mAh battery, auto-focus, and 3D support. This manual provides detailed instructions to help you set up, operate, and maintain your projector for optimal performance.



2. SAFETY INFORMATION

Please read all safety instructions carefully before using the projector. Keep this manual for future reference.

- Do not look directly into the projector lens when the lamp is on, as it may cause eye damage.
- Do not place the projector in unstable locations.
- Avoid exposing the projector to rain, moisture, or extreme temperatures.
- Ensure proper ventilation to prevent overheating. Do not block ventilation openings.
- Use only accessories specified by the manufacturer.
- Do not attempt to repair the projector yourself. Refer all servicing to qualified personnel.
- Keep the projector away from heat sources and open flames.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- VEVSHAO V30 Mini Projector
- Power Adapter/Charger
- Remote Control
- Storage Bag
- User Manual (this document)
- (Optional: HDMI Cable, USB Cable, Tripod - check your specific package)

4. SETUP

4.1 Powering On and Charging

The VEVSHAO V30 features a built-in 15000mAh rechargeable battery, providing 2 to 3 hours of usage on a single charge.

- **To Power On:** Press and hold the power button on the projector or remote control.
- **To Charge:** Connect the power adapter to the projector's DC input port and plug it into a power outlet. The battery indicator will show charging status.

يتم شحنه مرة واحدة، ويمكن استخدامه لمدة تصل إلى 3 ساعات



Power Bank
charging



3*
5000mAh



Up to
2~3Hours



Image 4.1: Projector showing battery and charging capabilities.

4.2 Placement and Positioning

Position the projector on a stable, flat surface or mount it on a tripod. Ensure the projection path is clear of obstructions. The V30's compact size (9.5 x 9.5 x 16.2 cm, 0.87 Kg) makes it highly portable.

حجم الجيب، اذهب إلى أي مكان



Image 4.2: The VEVSHAO V30's portable design.

4.3 Auto-Focus and Keystone Correction

The VEVSHAO V30 features ultra-fast TOF autofocus and automatic all-round keystone correction. This eliminates the need for manual adjustments, ensuring a clear and rectangular image automatically.



Image 4.3: Automatic focus and keystone correction in action.

4.4 Connectivity

The projector supports various input methods:

- **Wi-Fi:** For wireless screen projection from smartphones, tablets, and laptops.
- **HDMI:** Connect external devices like laptops, gaming consoles, or TV boxes.
- **USB:** Play media directly from USB flash drives.
- **DC Input:** For power and charging.



Image 4.4: Available connectivity ports on the VEVSHAO V30.

5. OPERATING INSTRUCTIONS

5.1 Smart System Navigation

The VEVSHAO V30 runs on Android 9.0, providing access to various applications. Pre-installed apps include YouTube and Netflix.

- Use the remote control to navigate the Android interface.
- You can download additional applications from the app store.
- **Important:** Do not upgrade pre-installed programs, as this may cause errors.

5.2 Wireless Screen Projection

Connect your iPhone, Android smartphone, tablet, or laptop wirelessly to the projector via Wi-Fi for screen mirroring.

1. Ensure both the projector and your device are connected to the same Wi-Fi network.
2. Select the screen mirroring/wireless display function on the projector's menu.
3. On your mobile device, activate screen mirroring (e.g., AirPlay for iOS, Smart View/Cast for Android) and select the VEVSHAO V30 from the list of available devices.

دعم الهاتف الذكي/الكمبيوتر اللوحي/الكمبيوتر المحمول واي فاي العرض



Image 5.1: Wireless screen projection from a smartphone.

5.3 3D Functionality

The VEVSHAO V30 supports shutter 3D function, allowing for an immersive cinematic experience.

- To enjoy 3D content, you will need compatible active shutter 3D glasses (sold separately).
- Ensure your media content is in a supported 3D format.
- Activate the 3D mode in the projector settings if it doesn't automatically detect 3D content.

قم ببناء مسرحك الخاص ثلاثي الأبعاد



Image 5.2: Immersive 3D viewing experience.

5.4 Audio Output

The projector includes built-in stereo speakers for audio playback. You can also connect external audio devices via Bluetooth or the audio output port (if available).



Image 5.3: Projector with integrated stereo speakers.

6. MAINTENANCE

6.1 Cleaning the Projector

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Body:** Wipe the projector's exterior with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water.
- **Ventilation:** Periodically check and gently clean the ventilation openings to ensure proper airflow and prevent dust buildup.

6.2 Storage

When not in use for extended periods, store the projector in its included storage bag in a cool, dry, and dust-free environment.

7. TROUBLESHOOTING

If you encounter issues with your VEVSHAO V30 projector, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No Power / Projector Not Turning On	• Ensure the power adapter is securely connected and plugged into a working outlet. • Check if the battery is charged. Charge the projector for at least 30 minutes. • Press and hold the power button for a few seconds.

Problem	Possible Cause / Solution
Image is Blurry / Out of Focus	• The projector has auto-focus. Ensure the projector is stable and allow it a moment to adjust. • If the issue persists, try moving the projector slightly or restarting it. • Clean the projector lens if it appears dirty.
Image is Distorted / Not Rectangular (Keystone)	• The projector features automatic keystone correction. Ensure the projector is placed on a level surface and facing the screen directly. • Avoid extreme angles. If the issue persists, a restart might help recalibrate.
No Signal / No Picture from Input Source	• Ensure the HDMI or USB cable is securely connected to both the projector and the source device. • Select the correct input source on the projector's menu. • Check if the source device is powered on and outputting a signal.
Wi-Fi Connectivity Issues	• Ensure the projector and your device are within range of the Wi-Fi router. • Verify that both devices are connected to the same Wi-Fi network. • Restart the projector and your Wi-Fi router.
Volume Glitch (Volume changes unexpectedly)	• This may indicate a software issue. Try restarting the projector. • If the problem persists, ensure the projector's firmware is up to date (if updates are available and recommended by VEVSHAO). • Contact customer support if the issue cannot be resolved.
Pre-installed Apps Not Working After Update	• As stated in the manual, avoid updating pre-installed applications. • If an update has caused issues, try resetting the projector to factory settings (refer to system settings for this option). Note that this will erase all personal data and installed apps.

8. SPECIFICATIONS

Key technical specifications for the VEVSHAO V30 Mini Projector:

Feature	Detail
Brand	VEVSHAO
Model Number	V30
Display Technology	DLP
Native Resolution	1920 x 1080 Pixels (1080P Full HD)

Feature	Detail
Operating System	Android 9.0
Battery Capacity	15000mAh (approx. 2-3 hours usage)
Connectivity	Wi-Fi, HDMI, USB
Special Features	3D-Ready, Auto Focus, Built-In 3D, Built-In Speaker, Wi-Fi Ready
Product Dimensions	9.5 x 9.5 x 16.2 cm
Item Weight	1.91 Kilograms
Voltage	5 Volts
Wattage	18 watts
Form Factor	Portable
Mounting Type	Tripod Mount



Image 8.1: Visual representation of 1080P Full HD resolution.

9. WARRANTY AND SUPPORT

The VEVSHAO V30 projector comes with a **1-year warranty**.

For any questions, technical assistance, or warranty claims, please contact VEVSHAO customer support. Refer to the contact information provided with your purchase or visit the official VEVSHAO website for support details.

VEVSHAO - Light Every Dream.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I update the VEVSHAO V30 projector from Android 9 to Android 12?

Based on the official manual for the VEVSHAO V30, the device is designed to run on Android 9.0. There are currently no official instructions or firmware packages provided by the manufacturer to upgrade the...

[Read full answer](#)