Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOOER SD10i

MOOER SD10i Intelligent Guitar Amplifier User Manual

Model: SD10i | Brand: MOOER

Product Overview

The MOOER SD10i is a versatile 10W practice guitar amplifier combo designed for musicians seeking a portable and feature-rich practice solution. It offers immersive stereo sound, a powerful subwoofer, and a wide selection of effects, all controllable via a smart app.

- **10W Stereo Sound:** Features two four-inch speakers for an immersive stereo experience, suitable for various room sizes.
- **Powerful Subwoofer:** Combines guitar amp capabilities with superior bass performance, enhanced by a home speaker-like design.
- **Wide Effects Selection:** Includes 6 effect types and a total of 109 effects, comprising 52 Amp Simulate, 4 dynamics, 19 overdrive, 15 modulation, 6 delay, and 5 reverb.
- **Practice Aids:** Integrated tuner, 80-second looper, 40 drum machine rhythms with tempo control, and 10 metronomes.
- **LED Light Show:** Customizable LED light strip with 9 color options and breathing/constant light modes via the app.
- **Portable and Rechargeable:** Equipped with a removable carrying handle and a 3000 mAh battery for over 5 hours of use, ideal for practice and parties.
- **Multiple Compatible Output:** USB-C for fast charging and OTG sound/picture synchronization recording. Supports headphone output for silent practice.
- **Wireless Footswitch Support:** Compatible with MOOER F4 wireless footswitch for enhanced control.

Getting Started

Package Contents

Please ensure all items are present in your package: MOOER SD10i Amplifier, Power Adapter, User Manual.

Charging the Amplifier

The SD10i features a built-in 3000 mAh battery. Connect the USB-C cable to the amplifier's USB-C port and a compatible power source. The LED indicator will show charging status. A full charge provides over 5 hours of battery life.



Image: Close-up of the MOOER SD10i's top panel, showing the USB-C port for charging and OTG recording.

Initial Setup

Before first use, fully charge the amplifier.

Power On/Off: Press and hold the power button located on the top panel.



Image: Diagram of the MOOER SD10i's control panel, detailing the power button, input/output jacks, and control knobs.

Operating Instructions

Connecting Your Guitar

Plug your guitar cable into the 6.35mm INPUT jack on the top panel of the amplifier.



Image: A person playing an electric guitar, with the guitar cable connected to the MOOER SD10i amplifier, demonstrating typical usage.

Bluetooth Connectivity

The SD10i supports Dual Bluetooth for connecting to your cell phone for music playback and to the iAMP app for control.

To connect, enable Bluetooth on your device and select "MOOER SD10i" from the available devices.



Image: A visual representation of the MOOER SD10i's connectivity, showing a guitar plugged in and a smartphone connected via Bluetooth for audio streaming.

MOOER iAMP App

Download the MOOER iAMP app from your device's app store to unlock the full potential of the SD10i. The app provides access to 52 amp models, 49 effects, and various practice tools.

Through the app, you can customize effects, manage presets, and utilize features like the drum machine, looper, and tuner.




Image: The MOOER SD10i amplifier positioned next to a smartphone, which displays the user interface of the MOOER iAMP application, highlighting app integration.

Amp Models and Effects

The SD10i boasts 52 amp models and 109 effects, including dynamics, overdrive, modulation, delay, and reverb. These can be accessed and adjusted via the iAMP app.



Image: A collage of screenshots from the MOOER iAMP app, illustrating the extensive range of customizable sound effects and amplifier models available.

Practice Tools

Utilize the built-in tuner for accurate tuning, the 80-second looper for practice phrases, and the drum machine with 40 rhythms and 10 metronomes to enhance your practice sessions.




Image: Visuals representing the high-quality tone simulation and sound customization features, including preset tones, drum machine, and looper functions.

LED Light Show

Personalize your amplifier with the integrated LED light strip. Choose from 9 colors and select between breathing or constant light modes through the iAMP app.



Image: The MOOER SD10i amplifier showcasing its dynamic LED light strip, with multiple color options displayed below, indicating customizable lighting.

OTG Recording

The USB-C port supports OTG (On-The-Go) for direct sound and picture synchronization recording to your mobile device, allowing you to capture your performances easily.



Image: A diagram illustrating the OTG recording capability of the MOOER SD10i, showing a smartphone connected via USB-C for direct audio and video synchronization.

Wireless Footswitch Support

For hands-free control during performances or practice, the SD10i supports the MOOER F4 wireless footswitch (sold separately).

Official Product Video

Your browser does not support the video tag.

Video: An official product video showcasing the MOOER SD10i Smart Guitar Practice Amp in use, highlighting its features and sound capabilities.

Maintenance and Care

- Keep the amplifier clean by wiping it with a soft, dry cloth.
- Avoid exposing the amplifier to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or repair the unit yourself. Refer to qualified service personnel.
- Store in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
No Sound	Guitar cable not connected properly.	Ensure guitar cable is fully inserted into the INPUT jack.
No Sound	Amplifier volume too low.	Increase the Instrument Volume knob.

Problem	Possible Cause	Solution
No Sound	Battery is low or depleted.	Charge the amplifier using the provided USB-C cable.
Bluetooth Disconnection	Device is out of range or interference.	Move your device closer to the amplifier. Avoid obstacles.
App Not Connecting	Bluetooth not enabled or app issue.	Ensure Bluetooth is on and the app is updated. Restart the app or amplifier.
Distorted Sound	Input signal too high or effect settings.	Reduce guitar volume or adjust gain/overdrive settings in the iAMP app.

Specifications

Feature	Detail
Output Wattage	10W
Speakers	2 x 4-inch
Battery	3000 mAh Lithium Ion (included)
Battery Life	>5 hours
Connectivity	Bluetooth 5.0, USB-C (OTG), 6.35mm Input, 3.5mm Output
Amp Models	52
Effects Types	6 (109 total effects)
Dimensions	4.53 x 8.66 x 5.31 inches
Item Weight	4 pounds
Color	Red

Warranty and Support

For warranty information and technical support, please visit the official MOOER website or contact MOOER customer service directly.

You can also visit the MOOER Store on Amazon for additional resources and product information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D78TBN5R

More documents and user manuals: **https://manuals.plus/**