

[manuals.plus](#) /

- › [PRITECH](#) /
- › [PRITECH LD-8001 Rechargeable Electric Shaver User Manual](#)

PRITECH LD-8001

PRITECH LD-8001 Rechargeable Electric Shaver

USER MANUAL

INTRODUCTION

Thank you for choosing the PRITECH LD-8001 Rechargeable Electric Shaver. This manual provides essential information for the safe and effective use of your new shaver. Please read these instructions carefully before use and retain them for future reference. This shaver is designed for gentle and efficient hair removal from various body areas, including legs, arms, underarms, and bikini line.



Image of the PRITECH LD-8001 Rechargeable Electric Shaver, a compact device with a pink and white body, featuring a foil shaver head.

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the device:

- **Caution:** Avoid use near water. Keep away from heat sources.
- Do not use while charging.
- Always hold the shaver away from the skin while turning it on or off to prevent nicks and cuts.
- Discontinue use if skin irritation occurs.
- This appliance is intended for household use only.
- Do not use this appliance if it has been dropped into water or if it is damaged.

- Keep out of reach of children.
- Ensure the shaver head is properly attached before use.

PRODUCT OVERVIEW

The PRITECH LD-8001 electric shaver features a compact, ergonomic design for comfortable handling. It includes a durable foil shaver head for close and gentle hair removal. The device is rechargeable, offering cordless convenience.

Components

- Shaver Body (main unit with power button)
- Foil Shaver Head (detachable for cleaning)
- Protective Cap
- Cleaning Brush
- Charging Cable/Dock (not explicitly shown but implied by 'Rechargeable')

SETUP

Before first use, ensure the shaver is fully charged. Connect the charging cable to the shaver and a suitable power source. The indicator light will show charging status. A full charge typically takes several hours.

Your browser does not support the video tag.

Video demonstrating the PRITECH LD-8001 electric shaver, including its charging process and general use.

OPERATING INSTRUCTIONS

To operate your PRITECH LD-8001 shaver:

1. Ensure the shaver is charged.
2. Remove the protective cap from the shaver head.
3. Press the power button to turn on the shaver.
4. Gently press the shaver head against your skin and move it slowly against the direction of hair growth. For best results, hold the skin taut.
5. After shaving, press the power button to turn off the shaver.
6. Replace the protective cap to protect the shaver head.

MAINTENANCE

Regular cleaning and proper maintenance will extend the life of your shaver and ensure optimal performance.

Cleaning the Shaver Head

1. Ensure the shaver is turned off and disconnected from any power source.
2. Gently press the release buttons on the sides of the shaver head to detach it from the main body.
3. Use the provided cleaning brush to remove any trapped hair from the foil and the internal blades.

4. Rinse the shaver head under running water if it is designed for wet cleaning (refer to product specifications for water resistance). Allow it to air dry completely.
5. Reattach the shaver head to the main body until it clicks into place.

Your browser does not support the video tag.

Video tutorial on how to clean the PRITECH LD-8001 electric shaver, including removing and cleaning the shaver head and blades.

Blade Replacement

For optimal performance, it is recommended to replace the shaver head and blades every 6-12 months, depending on usage. Replacement heads can be purchased separately.

TROUBLESHOOTING

If you encounter any issues with your shaver, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery or no charge.	Charge the shaver fully. Ensure the charging cable is properly connected.
Poor shaving performance.	Blades are dull or dirty.	Clean the shaver head and blades. Consider replacing the shaver head if blades are dull.
Shaver makes unusual noise.	Hair trapped in the shaver head.	Clean the shaver head thoroughly.
Skin irritation after shaving.	Improper shaving technique or sensitive skin.	Ensure skin is clean and dry. Shave gently against hair growth. If irritation persists, discontinue use.

SPECIFICATIONS

Feature	Detail
Model Name	LD-8001
Power Source	Corded Electric (for charging)
Special Feature	Detachable Head, Portable
Recommended Uses	Leg, Arm, Underarm, Bikini Line
Brand	PRITECH
Manufacturer	Wenzhou Pritech Industrial Co., Ltd.
Package Dimensions	6 x 3 x 1 inches; 1.15 ounces

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included in your product packaging or contact PRITECH customer support. Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

For technical assistance, troubleshooting, or to inquire about replacement parts, please visit the official PRITECH website or contact their customer service department.

© 2024 PRITECH. All rights reserved.