

SOUYIE 22mm Quick Release Silicone Replacement Watch Strap

SOUYIE 22mm Quick Release Silicone Watch Band

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the SOUYIE 22mm Quick Release Silicone Watch Band. This manual provides essential information for the proper installation, use, and maintenance of your new watch strap. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

2. Product Features

- **Material:** High-quality, durable silicone for comfort and flexibility.
- **Buckle:** Secure black stainless steel tang buckle.
- **Quick Release Pins:** Integrated spring bars for easy installation and removal without tools.
- **Compatibility:** Designed for watches with a 22mm lug width, including the SW-7 Smart Watch.

3. Package Contents

- 1 x SOUYIE 22mm Quick Release Silicone Watch Band (two strap pieces)

4. Installation Instructions

Follow these steps to install or replace your watch band:

1. **Prepare Your Watch:** If replacing an old band, gently remove it from your watch. Most watch bands can be removed by compressing the spring bar pins.
2. **Identify Band Sections:** The SOUYIE watch band consists of two sections: a shorter section with the buckle and a longer section with adjustment holes.
3. **Attach the Buckle Section:** Locate the quick-release pin on one end of the buckle section. Slide the pin into one of the lug holes on your watch case.

4. **Compress the Pin:** While holding one end of the pin in the lug hole, use your finger to slide the small lever on the quick-release pin inwards, compressing the pin.
5. **Insert into Second Lug Hole:** Carefully align the other end of the compressed pin with the second lug hole on the watch case. Release the lever to allow the pin to extend and secure itself into the hole. Gently tug on the band to ensure it is firmly attached.
6. **Attach the Longer Section:** Repeat steps 3-5 for the longer section of the watch band on the opposite side of your watch case.



Figure 1: Both sections of the SOUYIE 22mm Quick Release Silicone Watch Band, illustrating the quick release pins for easy installation.



Figure 2: Detail of the black stainless steel buckle on the SOUYIE silicone watch band.

5. Care and Maintenance

To ensure the longevity and appearance of your silicone watch band, follow these care guidelines:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth. For deeper cleaning, use mild soap and water, then rinse thoroughly and air dry.

- **Avoid Harsh Chemicals:** Do not expose the band to strong chemicals, solvents, or abrasive cleaners, as these can damage the silicone material.
- **Storage:** Store the band in a cool, dry place away from direct sunlight when not in use to prevent material degradation.
- **Water Exposure:** While silicone is water-resistant, prolonged exposure to saltwater or chlorinated water should be followed by a rinse with fresh water and drying.

6. Troubleshooting

Problem: The band does not fit my watch.

Solution: Ensure your watch has a 22mm lug width. This band is specifically designed for 22mm lug widths. Measure your watch's lug width carefully if unsure.

Problem: The quick-release pin does not engage properly.

Solution: Make sure the pin is fully compressed and aligned with both lug holes before releasing the lever. Sometimes a slight wiggle or adjustment is needed to ensure the pin snaps securely into place.

Problem: The band feels loose after installation.

Solution: Double-check that both ends of the quick-release pins are fully seated in the lug holes. Gently pull on the band to confirm it is securely attached to the watch case.

7. Specifications

Item Type Name	Watch band
Material	Silicone
Clasp Type	Tang Buckle (Black Stainless Steel)
Lug Width	22mm
Approximate Package Dimensions	8.46 x 2.36 x 0.39 inches
Approximate Item Weight	0.88 ounces

8. Warranty and Support

SOUYIE products are manufactured with quality and durability in mind. For any questions, concerns, or support needs regarding your watch band, please contact SOUYIE customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question