

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ufree](#) /

› [Ufree 5-in-1 Curling Iron and Hair Straightener User Manual \(Model B0D78VM364\)](#)

## Ufree B0D78VM364

# Ufree 5-in-1 Curling Iron and Hair Straightener User Manual

Model: B0D78VM364

## IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Burn Hazard:** Surfaces become extremely hot during use. Avoid direct contact with skin, especially the scalp, neck, and face. Use the included heat-resistant glove.
- **Electric Shock Risk:** Keep the appliance away from water. Do not use it near bathtubs, showers, sinks, or other water-filled containers. Do not immerse the appliance in water or any other liquid. If the appliance falls into water, unplug it immediately and do not reach into the water.
- **Fire Risk:** Unplug the appliance immediately after use and when not in use. Do not leave the appliance unattended when plugged in. Ensure the appliance is placed on a heat-resistant surface when hot. Keep away from flammable materials.
- **Children:** This appliance is not intended for use by children. Keep out of reach of children.
- **Damage:** Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged in any way. Contact customer support for assistance.
- **Storage:** Allow the appliance to cool completely before storing. Do not wrap the power cord around the appliance.

## PRODUCT OVERVIEW

The Ufree 5-in-1 Curling Iron and Hair Straightener set provides versatile styling options with interchangeable ceramic barrels and a flat iron attachment. This set is designed for various hair types and styles, offering convenience and efficiency.



**Image Description:** A complete view of the Ufree 5-in-1 styling set, including the main handle, four interchangeable curling barrels (tapered, 0.5-inch with clip, 1-inch wand, 1.25-inch with clip), a flat iron attachment, a heat-resistant glove, two hair clips, a storage bag, and two scrunchies.

### Components Included:

- Main Handle with Power Cord
- 0.35-0.71 inch Tapered Curling Barrel
- 0.5 inch Curling Barrel with Clip
- 1 inch Curling Wand
- 1.25 inch Curling Barrel with Clip
- Hair Straightener Attachment
- Heat-Resistant Glove
- Hair Clips (2)
- Storage Bag

## SETUP AND ASSEMBLY

1. **Select Attachment:** Choose the desired curling barrel or flat iron attachment for your styling needs.
2. **Attach to Handle:** Align the pins on the base of the chosen attachment with the corresponding slots on the main handle. Insert the attachment firmly until it clicks into place.
3. **Secure Attachment:** Ensure the attachment is securely locked. Some models may have a lock/unlock switch; refer to the diagram below.

# Easy to Switch



**Image Description:** A visual guide demonstrating the "Easy to Switch" mechanism for attaching and detaching the curling barrels from the main handle. One panel shows the barrel being inserted and locked, while the other shows it being unlocked and removed.

4. **Plug In:** Plug the power cord into a standard electrical outlet (110-240V AC).

## OPERATING INSTRUCTIONS

### Power On and Temperature Settings:

1. **Power On:** Press and hold the power button (usually located on the handle) to turn on the appliance.
2. **Select Temperature:** This appliance features two temperature settings:
  - **Low Temp:** Approximately 350°F (177°C) - Suitable for delicate or fine hair.
  - **High Temp:** Approximately 410°F (210°C) - Suitable for coarse or thick hair.

Adjust the temperature using the designated switch or button on the handle.

3. **Heat Up:** The appliance will heat up rapidly, typically within 30 seconds, thanks to double MCH heating technology.



**Image Description:** An illustration highlighting the rapid 30-second heat-up feature of the curling iron, along with visual indicators for the two temperature settings: 356°F (Low Temp) and 410°F (High Temp).

### Using the Curling Barrels:

Always wear the heat-resistant glove provided when using the curling barrels to protect your hand from heat.

1. Ensure hair is clean, dry, and tangle-free. Apply a heat protectant spray.
2. Section your hair into manageable strands.

3. For barrels with a clip: Open the clip, place a section of hair under it, and wrap the hair around the barrel, starting from the ends. Close the clip to secure.
4. For wands (no clip): Wrap a section of hair around the barrel, holding the end of the hair with your gloved hand.
5. Hold for 5-10 seconds, depending on hair type and desired curl intensity.
6. Release the hair gently. Allow curls to cool before styling for better hold.

## Switch Up Your Look Effortlessly



**Image Description:** A visual guide showcasing various curl patterns achievable with the different interchangeable barrels: 0.35"-0.71" tapered barrel for tight curls, 0.5" curl barrel for defined curls, 1" curl barrel for loose waves, and 1.25" curl barrel for soft waves. It also shows the flat iron for straight hair.

### Using the Hair Straightener Attachment:

1. Ensure hair is clean, dry, and tangle-free. Apply a heat protectant spray.
2. Section your hair into manageable strands, typically 1-2 inches wide.
3. Place a section of hair between the plates of the straightener, close to the roots.
4. Gently glide the straightener down the hair section from root to tip in one smooth motion. Avoid holding the

straightener in one place for too long.

5. Repeat on other sections until desired straightness is achieved.



**Image Description:** A close-up image demonstrating the hair straightener in use, showing hair being straightened. Insets highlight key features like "3D Floating Plates" for even pressure and "Thumb Grip" for comfortable handling.

### **Dual Voltage Feature:**

This appliance supports dual voltage (110-240V AC), making it suitable for international travel. An adapter may be required for different plug types, but a voltage converter is not needed.



**Image Description:** An image illustrating the "Dual Voltage for Worldwide" feature (110-240V) and the "360° Swivel Cord" for tangle-free operation. It also shows the included heat-resistant glove and storage bag.

## MAINTENANCE AND CARE

1. **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the ceramic barrels and plates with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
2. **Storage:** Store the appliance and its attachments in the provided storage bag in a cool, dry place. Do not wrap the power cord tightly around the appliance, as this can damage the cord.
3. **Inspection:** Regularly inspect the power cord and plug for any signs of damage. If any damage is observed, discontinue use and contact customer support.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly, power outlet issue, or appliance malfunction.	Ensure the plug is fully inserted into a working outlet. Check if the outlet has power. If the issue persists, contact customer support.
Appliance not heating up.	Temperature setting too low, or internal heating element issue.	Verify the temperature setting is selected. Allow sufficient time for heating (approx. 30 seconds). If still not heating, contact customer support.
Attachment is loose or falls off.	Attachment not properly secured to the handle.	Ensure the attachment is fully inserted and locked into place. Refer to the "Setup and Assembly" section.
Hair is not curling/straightening effectively.	Hair is wet, sections are too large, or temperature is too low for hair type.	Ensure hair is completely dry. Use smaller sections of hair. Increase the temperature setting if your hair is coarse or thick.

## SPECIFICATIONS


- **Brand:** Ufree
- **Model:** B0D78VM364
- **Material:** Ceramic
- **Color:** Rose Gold
- **Product Dimensions:** 9.06 x 6.69 x 6.69 inches
- **Weight:** 2.34 Pounds
- **Voltage:** Dual Voltage (110-240V AC)
- **Temperature Settings:** 350°F (Low), 410°F (High)
- **Heat-up Time:** Approximately 30 seconds
- **Cord:** 360° Swivel Cord
- **Included Barrels:** 0.35-0.71 inch Tapered, 0.5 inch with Clip, 1 inch Wand, 1.25 inch with Clip
- **Additional Attachments:** Hair Straightener

## WARRANTY AND SUPPORT

Ufree is committed to providing quality products and customer satisfaction.

- **Money Back Guarantee:** 30-Day Money Back policy.
- **Warranty:** This product is covered by a 1-Year Warranty from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact Ufree customer support. Support is available 24 hours.
- **Seller Information:** Ufree Inc.

For further assistance, please visit the official Ufree store or contact their customer service directly.



**Image Description:** An image showing customer support representatives and icons indicating "30 Day Money Back", "24 H Support", and "1 Year Warranty".