

[Manuals.plus](#) /

> [Mcilpoog](#) /

> Mcilpoog WS-D5 Super Automatic Coffee Machine User Manual

## Mcilpoog WS-D5

# Mcilpoog WS-D5 Super Automatic Coffee Machine User Manual

Model: WS-D5

## 1. INTRODUCTION

Thank you for choosing the Mcilpoog WS-D5 Super Automatic Coffee Machine. This machine is designed to provide a convenient and high-quality coffee experience, offering 12 different drink options with a 20-bar pressure system and integrated WIFI functionality for smart control. Please read this manual thoroughly before operation to ensure proper use, maintenance, and longevity of your appliance.

## 2. SAFETY INFORMATION

- Always connect the machine to a grounded power outlet.
- Do not immerse the machine, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug the machine before cleaning and when not in use for extended periods.
- Do not operate the machine if the power cord or plug is damaged.
- Use only clean, cold water in the water tank.
- Avoid touching hot surfaces during operation.

## 3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Mcilpoog WS-D5 coffee machine.



**Figure 3.1:** Front view of the McilpooG WS-D5 coffee machine, showing the main unit, external milk frother container, and a prepared coffee drink.

# Automatic Coffee Machine



Smart One-Touch  
controls for easy selection

4.5" Inch full-touch  
colorful display

**Figure 3.2:** The machine features a 4.5-inch full-touch colorful display for intuitive control and easy selection of various functions and drinks.

## 4. SETUP

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Placement:** Place the machine on a stable, flat, and heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
3. **Water Tank:** Fill the water tank with fresh, cold water up to the MAX level. Ensure the tank is properly seated.
4. **Bean Hopper:** Open the bean hopper lid and fill with whole coffee beans. Avoid overfilling. For optimal performance, use non-flavored coffee beans. Flavored beans may cause issues with the grinder mechanism.
5. **Milk Container (if applicable):** Connect the milk container to the designated port if you plan to use milk-based drinks.
6. **Power Connection:** Plug the power cord into a grounded electrical outlet.
7. **Initial Rinse:** Before first use, perform an initial rinse cycle as instructed on the display to clean the internal system.

## 5. OPERATING INSTRUCTIONS

### 5.1. Making a Drink

The WS-D5 offers 12 types of drinks. Use the touch screen to select your desired beverage.



**Figure 5.1:** The touch screen interface displays 12 distinct coffee and hot water options for easy selection.

1. Ensure the water tank is filled and the bean hopper contains coffee beans.
2. Place a cup under the coffee spout.
3. On the touch display, select your desired drink. You can customize settings like coffee strength and volume if prompted.
4. Press the START button to begin brewing.
5. The machine will automatically grind beans, pre-soak the coffee grounds for optimal extraction, and brew your drink.

# Perfect Grinding

15 gear grinding, removable cutter head



**Figure 5.2:** The machine features a 15-gear grinding adjustment for precise control over coffee fineness, ensuring perfect extraction. The cutter head is removable for cleaning.



**Figure 5.3:** The low-pressure pre-soaking function ensures coffee powder is fully wetted and extracted, preventing channeling and improving flavor.

## 5.2. WIFI Function and App Control

The Mcilpoo WS-D5 features WIFI connectivity, allowing for remote control via a dedicated mobile application. To use this feature:

1. Download the official Mcilpoo app (or compatible SmartLife/Tuya app) from your device's app store.
2. Follow the in-app instructions to connect your coffee machine to your home WIFI network.
3. Once connected, you can select drinks and initiate brewing from your mobile device.
4. Note: If the machine enters standby or sleep mode, it may require manual interaction (double-pressing the touch screen to wake up and hitting START) on the machine itself before remote commands can be executed.

## 6. MAINTENANCE


Regular cleaning and maintenance are crucial for the performance and lifespan of your coffee machine.

## 6.1. Daily Cleaning

- **Drip Tray:** Empty and rinse the drip tray daily.
- **Coffee Grounds Container:** Empty and clean the coffee grounds container daily.
- **Milk System (if used):** After each milk-based drink, perform a quick rinse of the milk system as prompted by the machine or manually.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth.

## 6.2. Removable Brewer Cleaning

The brewing unit is designed for easy removal and cleaning.



**Figure 6.1:** The brewing system features a removable brewer for thorough cleaning and a linear extraction design for consistent coffee quality.

# Easy to clean

Small size and easy to disassemble



**Figure 6.2:** The brewing unit is small, easy to disassemble, and can be rinsed under running water for simple and effective cleaning.

1. Turn off and unplug the machine.
2. Open the service door and remove the brewing unit by pressing the 'PUSH' button and pulling it out.
3. Rinse the brewing unit thoroughly under lukewarm running water. Do not use detergents.
4. Allow the brewing unit to air dry completely before reinserting it into the machine.

## 6.3. Descaling

The machine will prompt you when descaling is required. Follow the on-screen instructions and use a suitable descaling solution designed for coffee machines.

## 7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Mcilpoo WS-D5 coffee machine.

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Machine displays error messages (e.g., brewing system error, coffee bean error).	Internal system blockage, sensor issue, or temporary malfunction.	Power cycle the machine: Turn off, unplug for 30 seconds, then plug back in and turn on. Ensure all removable parts (brewer, drip tray, grounds container) are correctly seated. If the error persists, consult customer support.
Coffee beans not grinding or getting stuck in the bean bin.	Beans are too oily or flavored, causing them to clump.	For optimal performance, use non-flavored, non-oily coffee beans. If using flavored beans, manually push them into the grinder if they get stuck. Clean the bean hopper regularly.
Mobile app not responding or machine not waking up via app.	Machine is in standby/sleep mode, or app connection issue.	Double-press the touch screen on the machine to wake it up, then press the START button. Ensure your mobile device and coffee machine are connected to the same WIFI network. Restart the app if necessary.
Coffee is not hot enough.	Cup not pre-heated, or machine temperature setting.	Pre-heat your cup with hot water. Check the temperature settings on the machine's display and adjust if available.
No coffee dispenses.	Water tank empty, brewing unit blocked, or machine needs descaling.	Fill water tank. Clean the brewing unit. Perform descaling if prompted.

## 8. SPECIFICATIONS

Technical details for the Mcilpoog WS-D5 Super Automatic Coffee Machine.



Figure 8.1: Dimensions of the Mclilpoo WS-D5 coffee machine.

- **Model Number:** WS-D5
- **Product Dimensions:** 19.02 x 7.44 x 12.4 inches (48.3 x 18.9 x 31.5 cm)
- **Item Weight:** 18.7 pounds (8.48 kg)
- **Operation Mode:** Fully Automatic
- **Pressure:** 20 Bar
- **Voltage:** 220 Volts
- **Human Interface Input:** Buttons, Touch Screen
- **Connectivity:** WIFI Function
- **Grinding Settings:** 15-gear adjustable grinding
- **Heating System:** Dual heating system for rapid and stable temperature control.



**Figure 8.2:** The machine incorporates a dual heating system for efficient and precise temperature management during brewing.

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Mcilpog website. If you encounter any issues not covered in this manual, please contact our customer service team for assistance.

**Contact Information:** Please refer to the product packaging or official brand website for the most current contact details.