

binROC 1

binROC Conical Burr Coffee Grinder Electric

Model: 1

1. INTRODUCTION

Thank you for choosing the binROC Conical Burr Coffee Grinder. This manual provides essential information for the safe and efficient operation of your new coffee grinder. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.

3. PACKAGE CONTENTS

Please check the package for the following items:

PACKAGE INCLUDE



Image: All components included in the binROC coffee grinder package.

1. Bean Hopper
2. Main Body of the Grinder
3. Portafilter Holder Base
4. Cleaning Brush
5. Portafilter Holder
6. Portafilter Holder Pad
7. Grinding Chamber

4. PRODUCT OVERVIEW

The binROC Conical Burr Coffee Grinder is designed for precision and convenience, offering a superior grinding experience for various coffee brewing methods.

4.1 Premium Conical Burr



Image: Stainless steel conical burr for uniform grinding.

Equipped with high-quality stainless steel conical burrs, this grinder minimizes heat generation during grinding, preserving the essential oils and flavor of your coffee beans. The conical design ensures uniform and precise grinding for optimal extraction.

4.2 Adjustable Grind Settings

48 PRECISE GRINDING SETTINGS

Enjoy your coffee from Espresso to French Press



Image: The grind setting dial with 48 options for various brewing methods.

With 48 adjustable grind settings, you can fine-tune the coarseness of your coffee grounds to match your preferred brewing method, from fine espresso to coarse French press.

4.3 Precision Grinding Timer

ADJUSTABLE GRINDING TIME

35s digital timer to ground coffee accurately and consistently



Image: The digital timer control for precise grinding duration.

The integrated precision timer allows you to set grinding durations up to 35 seconds, ensuring consistent and accurate dosing. The grinder automatically stops once the set time is reached.

4.4 Anti-Static Technology

ANTI-STATIC DESIGN

Mess-free grinding chamber and the worktop



Image: Demonstration of the anti-static design for a cleaner grinding experience.

Advanced anti-static technology prevents coffee grounds from sticking to the chamber, reducing mess and ensuring a cleaner workspace.

4.5 Portafilter Holder


DESIGN FOR ESPRESSO

★ **PORTAFILTER
NOT INCLUDED**

Note: The portafilter shown in images is for demonstration purposes only.



Portafilter holder pad



Portafilter holder



Image: The 48mm & 51mm portafilter holder for direct grinding.

The grinder includes a 48mm & 51mm portafilter holder, allowing you to grind coffee directly into your portafilter for a faster and more convenient espresso preparation. (Note: Portafilter not included).

4.6 Compact Design

COMPACT & SAVE SPACE

Smaller footprint than most grinders, efficient in size to save your countertop space.



Image: The compact size of the grinder, saving countertop space.

Its compact footprint ensures it fits comfortably on most kitchen countertops, optimizing your space.

5. SETUP

1. Unpack all components and remove any packaging materials.
2. Place the main body of the grinder on a stable, flat surface.
3. Insert the bean hopper onto the top of the grinder and rotate it clockwise until it locks into place. Ensure the hopper is securely fastened.
4. Choose your preferred grinding method:
 - For direct grinding into a portafilter: Attach the portafilter holder to the base.
 - For grinding into the chamber: Ensure the grinding chamber is correctly inserted into its slot.
5. Plug the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

6.1 Filling the Bean Hopper

Open the lid of the bean hopper and pour whole coffee beans into it. Close the lid securely after filling.

6.2 Adjusting Grind Settings

Rotate the grind setting dial located at the base of the bean hopper to select your desired fineness. Refer to the 'Grind Settings Guide' section for recommendations based on your brewing method.

6.3 Setting Grinding Time

Use the timer knob on the front panel to select the desired grinding duration (up to 35 seconds). The selected time will be displayed.

6.4 Starting and Stopping Grinding

- Place your portafilter (with holder) or the grinding chamber under the dispenser.
- Press the 'START/STOP' button to begin grinding. The grinder will operate for the preset time and automatically stop.
- To manually stop grinding before the preset time, press the 'START/STOP' button again.

7. GRIND SETTINGS GUIDE

The binROC coffee grinder offers 48 settings to accommodate various brewing methods. Use the following as a general guide:

Brewing Method	Recommended Grind Setting Range	Grind Fineness
Espresso	4 - 12	Fine
Drip / Pour Over	16 - 32	Medium
French Press	36 - 48	Coarse

Adjust within these ranges to find your personal preference and optimize extraction for your specific coffee beans.

8. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your grinder. The anti-static design helps minimize residue.

EASY TO CLEAN

Built-in brush for easy clean



Image: Easy cleaning process with the included brush and removable parts.

1. **Unplug the Grinder:** Always ensure the grinder is unplugged from the power outlet before cleaning.
2. **Remove Bean Hopper:** Rotate the bean hopper counter-clockwise to unlock and lift it off.
3. **Remove Upper Burr:** Gently lift out the removable upper burr.
4. **Clean Burrs:** Use the included cleaning brush to remove any coffee grounds from both the upper and lower burrs.
5. **Clean Grinding Chamber:** Remove the grinding chamber and empty any residual grounds. Wipe it clean with a dry cloth.
6. **Wipe Main Body:** Wipe the exterior of the grinder with a damp cloth. Do not use abrasive cleaners or immerse the main body in water.
7. **Reassemble:** Once all parts are dry, reassemble the grinder by placing the lower burr back, then the upper burr, and finally locking the bean hopper into place.

9. TROUBLESHOOTING

- **Grinder does not start:**
 - Ensure the power cord is securely plugged into a working outlet.
 - Check if the bean hopper is correctly locked into place. The grinder has a safety mechanism that prevents operation if the hopper is not secure.
 - Verify the grinding chamber is properly inserted.
- **Inconsistent grind or no grounds dispensed:**
 - Check if the bean hopper is empty.
 - The burrs might be clogged with old coffee grounds. Refer to the 'Maintenance and Cleaning' section to clean the burrs and grinding path.
 - Ensure the grind setting is appropriate for the beans and desired output.
- **Excessive static cling of grounds:**
 - While the grinder features anti-static technology, some static may occur depending on humidity and bean type. Ensure the grinding chamber is clean and dry.

10. SPECIFICATIONS

Feature	Detail
Brand	binROC
Model Number	1
Color	Upgraded Silver
Grind Settings	48 Adjustable Settings
Timer	Up to 35 seconds Precision Timer
Burr Type	Conical Burr (Stainless Steel)
Anti-Static	Yes
Product Dimensions	8.8 x 5.9 x 16 inches
Item Weight	5.63 pounds

11. WARRANTY AND SUPPORT

binROC is committed to providing high-quality products and excellent customer service. We have a professional after-sales service team ready to assist you.

If you encounter any problems with your binROC Conical Burr Coffee Grinder, please contact our customer support team. We aim to reply to all inquiries within 24 hours.

For support, please visit the [binROC Store on Amazon](#) or refer to your purchase documentation for direct contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question