Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YIRISO FK-375S

YIRISO Electric Razor User Manual

Model: FK-375S

Introduction

The YIRISO Electric Razor (Model FK-375S) is designed to provide a precise and comfortable shaving experience for men. Featuring an advanced 4D floating shaving head, this wet and dry shaver effortlessly glides along facial contours for an efficient shave. Its premium stainless steel blades are self-sharpening, ensuring long-lasting sharpness. The double-track cutter design allows for more facial hair to be cut in a single pass, saving time. An ergonomic V-Track Shaving Angle of 152 degrees adapts to your face for a smooth feel. The razor is 100% waterproof, allowing for both dry and wet shaving, and features an LCD digital power display to show available battery capacity.



Image: The YIRISO Electric Razor, Model FK-375S, showcasing its sleek design, three rotary shaving heads, power button, and an LCD screen displaying "USAGE TIME 99 sec".

Safety Information

Please read all safety instructions carefully before using the YIRISO Electric Razor to ensure safe operation and prevent injury.

- Always unplug the razor before using it in or near water.
- Exercise caution when handling the razor to avoid cuts from the sharp blades.
- Follow all cleaning and care instructions diligently to prevent bacterial growth and ensure the safe operation of the razor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Components

The YIRISO Electric Razor consists of the following main components:

- **4D Floating Shaving Head:** Adapts to facial contours for a close shave.
- **Pop-up Trimmer:** Integrated for precise trimming of sideburns and longer hairs.
- **Power Button:** Located on the front for easy on/off operation.
- **LCD Digital Display:** Shows usage time and remaining battery percentage.
- **Charging Port:** Located at the bottom of the unit.

Setup

Initial Charging

1. Before first use, fully charge the electric razor.
2. Connect the provided charging cable to the charging port at the bottom of the shaver.
3. Plug the USB-A end of the cable into a compatible USB power adapter (not included) or a USB port.
4. The LCD display will indicate charging status. A full charge typically takes a few hours.
5. Once fully charged, disconnect the shaver from the power source.

Note: The charging cable is proprietary. Ensure you keep it safe as a standard USB-C cable will not fit this device.

Operating Instructions

Basic Shaving

1. Press the power button to turn on the shaver. The LCD display will illuminate.
2. For a dry shave, ensure your face is clean and dry. For a wet shave, you may use shaving foam or gel.
3. Gently press the shaving head against your skin and move the shaver in small, circular motions.
4. Allow the 4D floating heads to adapt to the contours of your face, neck, and chin.
5. After shaving, press the power button again to turn off the shaver.

Using the Pop-up Trimmer

1. Locate the pop-up trimmer switch on the back or side of the shaver.
2. Slide the switch upwards to activate the trimmer.
3. Use the trimmer for precise shaping of sideburns, mustaches, or for trimming longer hairs before a close shave.
4. After use, slide the switch downwards to retract the trimmer.

Maintenance

Cleaning the Shaver

The YIRISO Electric Razor is 100% waterproof, making cleaning simple and hygienic.

1. Ensure the shaver is turned off and unplugged from any charging source.

2. Open the shaving head assembly by twisting or pressing the release button (refer to diagrams if available on product packaging).
3. Rinse the shaving heads and the internal hair chamber under running tap water.
4. For a more thorough clean, you may use the provided cleaning brush to remove stubborn hair particles.
5. Allow the components to air dry completely before reassembling the shaving head.
6. Periodically, you may apply a drop of lubricating oil (not included) to the blades to maintain optimal performance.

Blade Replacement

Replacement blades are essential for maintaining shaving performance over time. Specific instructions for purchasing replacement blades are not provided in this manual. Please refer to the manufacturer's website or contact customer support for information on obtaining genuine replacement parts.

Troubleshooting

If you encounter issues with your YIRISO Electric Razor, please consult the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Shaver pulls hair or causes irritation.	Blades may be dull or hair is too long.	Ensure blades are clean. Use the pop-up trimmer for longer hairs before shaving. Consider replacing shaving heads if performance does not improve.
Not getting a close shave.	Incorrect shaving technique or dull blades.	Move the shaver in small, circular motions. Ensure the shaver is fully charged. Clean the shaving heads.
Charging cable missing or not working.	Proprietary cable required.	Contact YIRISO customer support for a replacement cable. Standard USB-C cables are not compatible.

Specifications

Feature	Detail
Model Name	FK-375S
Power Source	Battery Powered
Special Features	Waterproof, TYPE-C Rechargeable, Floating Head, LED Display, Cordless, Travel Lock
Recommended Uses	Face
Brand	YIRISO
Country of Origin	China
ASIN	B0D796D71N
Manufacturer	YIRISO

Feature	Detail
Batteries	1 Lithium Ion battery required (included)
Package Dimensions	7.48 x 3.35 x 2.76 inches; 10.58 ounces

Warranty and Support

The YIRISO Electric Razor typically comes with a 12-month warranty from the date of purchase, covering manufacturing defects. For warranty claims, technical support, or inquiries regarding replacement parts (such as blades or charging cables), please contact YIRISO customer service. Specific contact information is often provided with the product packaging or can be found on the official YIRISO brand website.
For further assistance, you may visit the YIRISO Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D796D71N

More documents and user manuals: **https://manuals.plus/**