

[manuals.plus](#) /

› [VOWNER](#) /

› [VOWNER Shoe Cabinet with 4 Flip Drawers & 2 Drawers, Model VOWNER-332 Instruction Manual](#)

VOWNER VOWNER-332

VOWNER Shoe Cabinet with 4 Flip Drawers & 2 Drawers, Model VOWNER-332 Instruction Manual

Brand: VOWNER

Model: VOWNER-332

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your VOWNER Shoe Cabinet. Please read thoroughly before use to ensure proper installation and safe handling.

IMPORTANT SAFETY INFORMATION

- Do not place heavy items on top of the cabinet to prevent tipping over.
- Secure the cabinet to the wall using the provided anti-dumping device to prevent accidental tipping, especially in households with children or pets.

PRODUCT FEATURES

- **Large Capacity:** Features 4 flip drawers for shoe storage. The panels within each compartment can be adjusted or removed to accommodate various shoe types and sizes. Additionally, 2 top drawers provide storage for smaller items.
- **Space-Saving Design:** This ultra-thin, vertical shoe cabinet is designed to stand against a wall, optimizing space in entryways, hallways, or living rooms.
- **Durable Construction:** Constructed from high-quality MDF (Medium-Density Fiberboard) and equipped with robust metal accessories, ensuring a stable structure and excellent load-bearing capacity.
- **Practical Design:** The hidden shoe cabinet utilizes a space-saving pull-down drawer design for easy access. An anti-dumping device is included for enhanced safety.



Image: The VOWNER Shoe Cabinet in white, showcasing its design with four flip-down shoe compartments and two top drawers, ideal for an entryway.



Image: The VOWNER Shoe Cabinet with all four flip-down compartments open, revealing various shoes stored within, alongside the two accessible top drawers.



Image: A close-up view of a VOWNER Shoe Cabinet flip-down compartment, illustrating the two-position adjustable shelf feature designed to accommodate various shoe sizes.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following components are included:

- 1 x VOWNER Shoe Cabinet (disassembled components)
- 1 x Instruction Manual
- All necessary assembly accessories (screws, dowels, etc.)

SETUP AND ASSEMBLY INSTRUCTIONS

The VOWNER Shoe Cabinet requires assembly. Please ensure all parts are present and refer to the detailed assembly instructions provided in the package. A power drill is recommended for efficient assembly, but exercise caution to avoid overtightening screws, which could damage the material.




Image: A detailed diagram illustrating the overall dimensions of the VOWNER Shoe Cabinet (41.3"W x 39.3"H x 9.4"D) and specific measurements for its drawers.




1



Handy Handle

2



Anti-Tipping Kits

3



Vent Design

4



Flip Panel

Image: A visual guide highlighting the key components and features of the VOWNER Shoe Cabinet, including handles, anti-tipping kits, ventilation, and the flip-down panel design.

Video: Official product video demonstrating the VOWNER Shoe Cabinet's features and providing a visual overview of its functionality.

OPERATING INSTRUCTIONS

Using the Flip Drawers

To access your shoes, gently pull the knob on each flip drawer. The drawer will tilt forward, revealing two tiers for shoe storage. The internal panels can be adjusted to two different height positions or removed entirely to accommodate various shoe types, including taller boots or high heels.

Using the Top Drawers

The two top drawers are designed for convenient storage of smaller items such as keys, wallets, sunglasses, or other entryway essentials. Simply pull the knob to open and push to close.



Image: The VOWNER Shoe Cabinet with its two top drawers open, illustrating the storage space for small items, alongside the closed flip-down shoe compartments.



Image: The VOWNER Shoe Cabinet showcasing shoes neatly stored in its open flip-down compartments, with the top drawers also open to reveal additional storage for accessories.

MAINTENANCE

- **Cleaning:** Wipe the surfaces of the cabinet with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Dusting:** Regularly dust the cabinet to maintain its clean appearance.
- **Hardware:** Periodically check and tighten all screws and fittings to ensure the cabinet remains stable and secure.
- **Spills:** Clean any spills immediately with a dry cloth to prevent staining or damage to the engineered wood material.

TROUBLESHOOTING

Drawers are Stiff or Not Closing Smoothly

- **Check for Obstructions:** Ensure no items inside the drawers or along the tracks are blocking the mechanism.
- **Verify Assembly:** Confirm that all screws and slides for the drawers are correctly installed and tightened

according to the assembly instructions.

- **Lubrication:** If necessary, apply a small amount of silicone spray or wax to the drawer slides to improve smoothness.

Cabinet Feels Unstable

- **Wall Anchoring:** Ensure the anti-dumping device is securely attached to both the cabinet and a wall stud. This is crucial for safety.
- **Level Surface:** Place the cabinet on a flat, level surface. Use shims if the floor is uneven.
- **Tighten Fasteners:** Re-tighten all assembly fasteners throughout the cabinet structure.

PRODUCT SPECIFICATIONS

Brand	VOWNER
Model Name	VOWNER Shoe Cabinet
Item Model Number	VOWNER-332
Color	White
Product Dimensions	9.4"D x 41.3"W x 39.3"H
Item Weight	74.8 pounds (34 Kilograms)
Material	Engineered Wood
Mounting Type	Freestanding
Special Feature	Adjustable Shelf
Number of Compartments	6 (4 flip drawers, 2 regular drawers)
Assembly Required	Yes

WARRANTY AND CUSTOMER SUPPORT

For warranty information or assistance with your VOWNER Shoe Cabinet, please contact VOWNER customer service. Refer to your purchase documentation for specific warranty terms and contact details. Our team is available to help with any questions or concerns you may have.