

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [PARTPHONER](#) /

› PARTPHONER PAFP115AB1 RGBW Display Shelf Floor Lamp Instruction Manual

PARTPHONER PAFP115AB1

PARTPHONER PAFP115AB1 RGBW Display Shelf Floor Lamp Instruction Manual

Model: PAFP115AB1 | Brand: PARTPHONER

1. SAFETY INFORMATION

Important: Do not exceed the maximum weight capacity of 20 pounds per shelf. Ensure the product is assembled correctly and securely for stability and safety. Always unplug the lamp before cleaning or performing any maintenance.

2. SETUP AND ASSEMBLY

The PARTPHONER PAFP115AB1 Display Shelf is designed for easy assembly, typically taking around 10 minutes. All necessary tools and an instruction manual are included in the package.

2.1 Assembly Steps

1. Unpack all components and verify against the parts list in the included manual.
2. Begin by attaching the bottom shelf to the base poles. Ensure all connections are secure.
3. Continue adding subsequent shelves and poles, following the numerical order indicated in the manual.
4. Connect the lighting wires between each shelf as you assemble.
5. Once all shelves and poles are in place, connect the main power cable.
6. Use the provided cable clips to neatly secure any loose wires along the poles.

2.2 Product Overview



Image 1: Product dimensions and material overview.

3. OPERATING INSTRUCTIONS

The display shelf features smart control lighting with an included remote. It offers adjustable colors, lighting modes, and brightness levels.

3.1 Remote Control Functions



Image 2: Remote control layout and button descriptions.

- **Power Button:** Turns the lamp ON/OFF.
- **1H Timer:** Activates a 1-hour timer for automatic shut-off.
- **BRT+ / BRT-:** Adjusts brightness (stepless dimming from 10% to 100%).
- **CCT (Color Temperature):** Cycles through 4 white light color temperatures (2700K-6500K).
- **RGB:** Cycles through 6 static RGB colors (Red, Blue, Green, Yellow, Purple, Light Blue).
- **M (Mode):** Cycles through 3 dynamic lighting modes (Flashing, Gradient, Breathing).
- **L1, L2, L3, L4:** Individually controls the lights on each shelf (L1 for bottom, L4 for top).

- **Moon Icon:** Activates a night light mode (2700K, 10% brightness).

3.2 Lighting Features

- **Adjustable Colors:** Choose from 6 vibrant colors to match your mood or decor.
- **Multiple Modes:** Select from Flashing, Gradient, or Breathing modes for dynamic lighting effects.
- **Stepless Dimming:** Adjust brightness from 10% to 100% for optimal illumination.
- **Color Temperature:** Four distinct white light temperatures are available, from warm (2700K) to cool (6500K).
- **Individual Control:** Each of the four illuminated shelves can be controlled independently using the remote.

6 Adjustable Colors



Red



Blue



Green



Yellow



Purple



Light Blue


3 Lighting Modes



Flashing



Gradient



Breathing



Image 3: Demonstration of 6 adjustable colors and 3 lighting modes.

Adjustable Color Temperatures



Stepless Dimming



Image 4: Demonstration of adjustable color temperatures and stepless dimming.

Your browser does not support the video tag.

Video 1: Demonstration of the smart RGBW display shelf functions, including color changes and modes.

4. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the shelves and metal poles. Avoid abrasive cleaners or

solvents that may damage the finish.

- **Light Care:** The integrated LED lights are designed for long-term use. Do not attempt to replace individual LED components.
- **Stability Check:** Periodically check all screw connections to ensure they remain tight and secure.

5. TROUBLESHOOTING

5.1 Remote Control Issues

If your remote control buttons (L1, L2, L3, L4) cannot control the corresponding light layer, you may need to re-pair the remote with the specific light.

1. **Unpairing:** Only connect power to the light you wish to unpair. Press and hold the corresponding L button on the remote until the light flashes.
2. **Re-pairing:** With only the desired light connected to power, press and hold the corresponding L button on the remote until the light flashes again, indicating successful re-pairing.

Your browser does not support the video tag.

Video 2: Guide on how to repair your remote control if it cannot control the lights.

5.2 General Lighting Issues

- **Lights not turning on:** Check if the power adapter is securely plugged into both the wall outlet and the lamp. Ensure the wall outlet is functional.
- **Inconsistent lighting:** Verify all internal wire connections between the shelves are properly seated.

6. SPECIFICATIONS

Feature	Detail
Model Name	PAFP115AB1
Brand	PARTPHONER
Product Dimensions	11.8"D x 65.4"W x 15.7"H
Number of Shelves	5
Weight Limit per Shelf	20 Pounds
Material	Iron, Wood (Engineered Wood, Laminated Finish)
Light Type	RGBW LED
Color Temperature	2700K-6500K (Adjustable)
Dimming	10%-100% Stepless
Control Method	Remote Control

Feature	Detail
Included Components	Remote Control
Assembly Required	Yes

7. WARRANTY INFORMATION

Please refer to your purchase documentation or contact customer support for detailed warranty information regarding your PARTPHONER PAFP115AB1 Display Shelf Floor Lamp.

8. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your PARTPHONER PAFP115AB1 Display Shelf Floor Lamp, please feel free to contact us via Amazon message. Our customer support team is ready to help.