

[Manuals.plus](#) /

> [UGREEN](#) /

> UGREEN Magnetic Airplane Phone Holder (Model 45377) - Instruction Manual

UGREEN 45377

UGREEN Magnetic Airplane Phone Holder (Model 45377)

Instruction Manual

1. PRODUCT OVERVIEW

The UGREEN Magnetic Airplane Phone Holder (Model 45377) is designed to provide a hands-free viewing experience for your smartphone in various settings, including airplanes, trains, and desks. It features a strong magnetic attachment for MagSafe-compatible devices and a secure clamp for versatile mounting.

Key Features:

- **360° Adjustment:** Easily switch between horizontal and vertical viewing modes and adjust for optimal angles.
- **Portable and Versatile:** Lightweight and compact design allows mounting on tables, luggage handles, and use as a portable stand.
- **Strong Magnetic Design:** Upgraded magnetic power securely holds your phone in place.
- **Sturdy Construction:** Made from durable materials with a wide silicone pad for a superior grip.
- **Universal Compatibility:** Compatible with iPhone 12 series and newer (MagSafe) and other smartphones using an included magnetic metal ring.



Figure 1.1: UGREEN Magnetic Airplane Phone Holder with a smartphone.

2. SETUP INSTRUCTIONS

2.1 Attaching the Holder

1. Identify a suitable surface for clamping, such as an airplane tray table, desk edge, or luggage handle. Ensure the surface thickness does not exceed 0.98 inches (2.5 cm).
2. Pull the adjustable clamp mechanism to open the jaws. The clamp features anti-slip silicone pads for a secure grip.
3. Position the holder on the desired surface and release the clamp to secure it firmly. Ensure the holder is stable before attaching your phone.

Mini Size to Portable

3.34x1.65 in



✈️ **115g**



Figure 2.1: Secure clamp lock mechanism with a maximum opening of 0.98 inches.




Figure 2.2: Holder clamped to an airplane tray table.

2.2 Attaching Your Phone

1. For iPhones 12 series and newer with MagSafe: Simply align your phone with the magnetic ring on the holder. The strong magnets will automatically snap your phone into place.
2. For other smartphones or older iPhone models: Use the provided magnetic metal ring. Attach the metal ring to the back of your phone or phone case according to its instructions. Once the metal ring is securely attached, align your phone with the magnetic ring on the holder.

Ultra Strong Magnets




Figure 2.3: Magnetic phone attachment for hands-free use.



Figure 2.4: Universal compatibility with MagSafe and non-MagSafe phones using a metal ring.

3. OPERATION

3.1 Adjusting Viewing Angle

The UGREEN Phone Holder offers extensive adjustability for optimal viewing:

- The magnetic head can rotate 360 degrees, allowing for quick switching between portrait and landscape orientations.
- The arm of the holder can tilt up to 290 degrees, providing flexibility to find the perfect viewing angle.

Multi-Angle Adjustment



Figure 3.1: Multi-angle adjustment capabilities.

3.2 Usage Scenarios

This versatile holder can be used in various environments:

- **Travel:** Securely attach to airplane tray tables or train seatbacks for entertainment during journeys.
- **Home/Office:** Clamp to desks, shelves, or kitchen cabinets for hands-free video calls, recipes, or media consumption.



Kitchen

Figure 3.2: Examples of the phone holder in use across different environments.

4. MAINTENANCE

To ensure the longevity and optimal performance of your UGREEN Magnetic Airplane Phone Holder, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the holder with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish or silicone pads.
- **Storage:** When not in use, fold the holder into its compact form and store it in a dry, cool place away from direct sunlight.
- **Magnetic Surface:** Keep the magnetic surface clean and free of debris to ensure a strong and secure connection with your phone.



Figure 4.1: The holder's compact size for easy portability and storage.

5. TROUBLESHOOTING

If you encounter any issues with your UGREEN Magnetic Airplane Phone Holder, please refer to the following common solutions:

- **Phone Not Holding Securely:**
 - Ensure your phone or case is MagSafe compatible.
 - If using a metal ring, verify it is properly attached to your phone/case and aligned with the holder's magnet.
 - Check that the magnetic surfaces on both the holder and your phone/ring are clean and free of obstructions.
- **Clamp Not Holding Firmly:**
 - Verify that the surface thickness is within the maximum limit of 0.98 inches (2.5 cm).
 - Ensure the clamp is fully engaged and the anti-slip silicone pads are making good contact with the surface.
 - Avoid clamping on rounded or uneven surfaces that may prevent a secure grip.

- **Difficulty Adjusting Angle:**

- The joints are designed to be firm to maintain position. Apply gentle, consistent pressure when adjusting.

6. SPECIFICATIONS

Brand	UGREEN
Model Number	45377
Item Weight	5.3 ounces (150 grams)
Package Dimensions	3.7 x 2.64 x 2.05 inches (9.4 x 6.7 x 5.2 cm)
Max Clamp Opening	0.98 inches (2.5 cm)
Compatible Devices	iPhones 12 series and newer (MagSafe compatible), other smartphones with magnetic metal ring.
Special Features	Foldable, Magnetic, Multi-angle Adjustment, Portable

7. WARRANTY AND SUPPORT

UGREEN products are designed for reliability and performance. This product is subject to a 30-day return policy from the date of purchase. For detailed warranty information, product support, or assistance with any issues not covered in this manual, please contact UGREEN customer support through their official website or your point of purchase.