Deeyaple A10

Deeyaple Bluetooth Speaker User Manual

Model: A10

The Deeyaple A10 Bluetooth Speaker, designed for robust performance and portability.

1. INTRODUCTION

Thank you for choosing the Deeyaple Bluetooth Speaker. This portable speaker is engineered to deliver exceptional sound quality with dynamic lighting, designed for both indoor and outdoor use. Its rugged, waterproof, and dustproof construction ensures durability in various environments. This manual provides detailed instructions to help you get the most out of your new speaker.

2. KEY FEATURES

- **Exceptional Sound Quality:** Powerful 15W output for rich, crystal-clear sound with deep bass and crisp highs.
- **All-Day Battery Life:** Equipped with a 2500mAh battery, providing up to 10-12 hours of continuous playback on a single charge.
- **Portable and Convenient:** Compact design (3.15"D x 3.15"W x 4.33"H) and lightweight (12.3 ounces) with an included lanyard for easy carrying.
- **Rugged and Waterproof Design:** IP67 waterproof and dustproof rating, making it ideal for outdoor adventures, beach trips, and poolside use.
- **Dynamic Light Show:** Integrated LED lights sync with your music, changing according to audio frequency to create an immersive atmosphere.
- **True Wireless Stereo (TWS) Connection:** Wirelessly connect two Deeyaple speakers for a combined 30W output and a true stereo sound experience.
- **Advanced Bluetooth 5.3:** Ensures seamless connectivity, longer range (up to 33 feet), faster pairing, and stable audio streaming.
- **Built-in Microphone:** Allows for hands-free calling.

3. PACKAGE CONTENTS

- Deeyaple Bluetooth Speaker (Model A10)
- USB-C Charging Cable
- User Manual

4. CONTROLS AND INDICATORS

Portable and Convenient

Compact in size, comes with a lanyard, easy to carry around.

Side control panel with power, volume, and Bluetooth buttons.

Dynamic Light Show

Elevate your listening experience with dynamic lights that sync with your music.

Top light ring for dynamic light show.

Button/Indicator	Function
Power Button (①)	Press and hold for 2 seconds to Power ON/OFF. Short press to Play/Pause music or Answer/End calls.
Volume Up (ˆ)	Short press to increase volume. Long press for next track.
Volume Down (˅)	Short press to decrease volume. Long press for previous track.
Bluetooth/TWS Button (∞)	Short press to toggle light modes. Long press to enter TWS pairing mode.
LED Indicator	Indicates Bluetooth status (flashing blue for pairing, solid blue for connected) and charging status.
USB-C Port	For charging the speaker.

5. SETUP INSTRUCTIONS

5.1 Bluetooth Pairing

1. Ensure the speaker is fully charged before first use.

2. Press and hold the Power Button (①) for 2 seconds to turn on the speaker. The LED indicator will flash blue, indicating it's in pairing mode.

3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.

4. Select "Deeyaple A10" from the list. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation tone.

5. If pairing fails, turn off the speaker and your device's Bluetooth, then repeat the steps.

5.2 True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two Deeyaple A10 speakers together.

1. Ensure both speakers are powered on and not connected to any other Bluetooth devices.

2. On one speaker (this will be your primary speaker), long press the Bluetooth/TWS Button (∞) until you hear a pairing tone.

3. The two speakers will automatically search for and connect to each other. Once successfully paired, you will hear a confirmation tone, and the LED indicators on both speakers will turn solid blue.

4. Now, connect your device to the primary speaker via Bluetooth as described in Section 5.1. Both speakers will play audio in stereo.

---

6. OPERATING INSTRUCTIONS

6.1 Power ON/OFF

- **Power ON:** Press and hold the Power Button (①) for 2 seconds.
- **Power OFF:** Press and hold the Power Button (①) for 2 seconds.

6.2 Music Playback

- **Play/Pause:** Short press the Power Button (①).
- **Volume Up:** Short press the Volume Up Button (^).
- **Volume Down:** Short press the Volume Down Button (⌄).
- **Next Track:** Long press the Volume Up Button (^).
- **Previous Track:** Long press the Volume Down Button (⌄).

6.3 Call Handling

- **Answer/End Call:** Short press the Power Button (①).
- **Reject Call:** Long press the Power Button (①).

6.4 Dynamic Light Modes

The speaker features a dynamic light show that syncs with your music.

- **Change Light Mode:** Short press the Bluetooth/TWS Button (∞) to cycle through different light

modes.

- **Turn Lights OFF/ON:** Long press the Bluetooth/TWS Button (∞) to turn the lights off or on.

Experience the dynamic light show that enhances your music.

7. CHARGING THE SPEAKER

The speaker is equipped with a 2500mAh rechargeable battery.

- Connect the provided USB-C charging cable to the speaker's USB-C port and the other end to a USB power adapter (not included) or a computer's USB port.
- The LED indicator will light up during charging.
- A full charge takes approximately 3-4 hours.
- Once fully charged, the LED indicator will change color or turn off (refer to specific light behavior in the manual if available).
- The speaker provides up to 10 hours of playback time on a full charge, depending on volume level and light usage.

Can be recharged thousands of times

The speaker uses high-quality lithium battery, which is safe, reliable and has long battery life. It can be used normally after being charged thousands of times.

Charging the speaker via USB-C for extended playtime.

8. MAINTENANCE AND CARE

- **Waterproof & Dustproof:** The IP67 rating means the speaker can be submerged in up to 1 meter of water for 30 minutes and is fully protected against dust. Ensure the USB-C port cover is securely closed before exposure to water or dust.

- **Cleaning:** Use a soft, damp cloth to clean the speaker. Do not use harsh chemicals or abrasive cleaners.

- **Storage:** Store the speaker in a cool, dry place when not in use for extended periods. Avoid extreme temperatures.

- **Battery Care:** To prolong battery life, fully charge the speaker at least once every 3 months if not used regularly.

The IP67 rating ensures durability against water and dust.

9. TROUBLESHOOTING

- **Speaker won't turn on:** Ensure the battery is charged. Connect to a power source and try again.
- **No sound:** Check the volume level on both the speaker and your connected device. Ensure the speaker is properly paired via Bluetooth.
- **Bluetooth connection unstable/disconnects:** Ensure the speaker is within the 33-foot range of your device. Avoid obstacles between the speaker and device. Try re-pairing the speaker.
- **Cannot pair with a new device:** Ensure the speaker is not already connected to another device. Turn off Bluetooth on previously connected devices.
- **Distorted sound:** Lower the volume on both the speaker and your device. Ensure the speaker is not too far from your device.

9.1 Hard Reset

If you experience persistent issues, a hard reset may resolve the problem. This will clear all previous Bluetooth pairings.

1. Ensure the speaker is powered on.

2. Press and hold the Power Button (①) for approximately 8 seconds.

3. The speaker will power off and then power back on, indicating the reset is complete.

4. You can then proceed with new Bluetooth pairing.

Your browser does not support the video tag.

Watch this video for a visual guide on how to perform a hard reset on your Deeyaple Bluetooth Speaker.

10. SPECIFICATIONS

Feature	Specification
Model Name	P1S (Item model number: A10)
Bluetooth Version	V5.3
Output Power	15W (30W with TWS pairing)
Battery Capacity	2500mAh
Playback Time	Up to 10 hours
Charging Time	About 3-4 hours
Water Resistance Level	IP67 (Waterproof & Dustproof)
Wireless Transmission Distance	Up to 33 feet (10M)
Frequency Response	80Hz-20KHz
Signal-to-Noise Ratio (SNR)	75dB
Product Dimensions	3.15"D x 3.15"W x 4.33"H
Item Weight	12.3 ounces
Material	Acrylonitrile Butadiene Styrene (ABS)
Connectivity Technology	Bluetooth
Included Components	Power Cable

11. WARRANTY AND SUPPORT

The Deeyaple Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information, please refer to the warranty card included in your package or contact Deeyaple customer support.

For any questions, technical support, or warranty claims, please contact Deeyaple customer service through the contact information provided on the product packaging or the official Deeyaple website.

Related Documents - A10

	[A10 True Wireless Earphone User Manual](#) User manual for the A10 True Wireless Earphone, including component list, wearing method, function description, charging case usage, LED indicators, pairing instructions, specifications, and safety rules.
	[Deeyaple Magic Arm Quick Start Guide: Wireless Speaker and Phone Stand](#) A quick start guide for the Deeyaple Magic Arm, a wireless Bluetooth speaker and phone stand. Learn about its features, specifications, controls, indicator lights, pairing, and warranty.
	[P1S Wireless Bluetooth Speaker User Manual](#) User manual for the P1S Wireless Bluetooth Speaker by deeyaple, covering setup, operation, safety instructions, specifications, and features. Includes multilingual content.
	[A10 Wireless Guitar System Instruction Manual](#) Comprehensive instruction manual for the A10 Wireless Guitar System, detailing setup, operation, features, specifications, and FCC compliance for wireless audio transmission.
	[A10 Car Smart Screen User Manual](#) Comprehensive user manual for the A10 Car Smart Screen, detailing installation, connection methods, features like Apple CarPlay and Android Auto, troubleshooting tips, product specifications, and optional dashcam/reverse camera functions.
	[Audio Ltd. A10-TX Digital Transmitter User Guide](#) Comprehensive user guide for the Audio Ltd. A10-TX Digital Transmitter, covering setup, operation, features, specifications, and troubleshooting. Learn about frequency selection, audio input, recording, firmware updates, and more.