

[Manuals.plus](#) /

› [Lyromix](#) /

› Lyromix XXL Dog Crate Furniture Instruction Manual

Lyromix Lyromix Combination Dog Crate

Lyromix XXL Dog Crate Furniture Instruction Manual

MODEL: LYROMIX COMBINATION DOG CRATE (XXL 47.24"×29.13"×37.6")



Providing comfort and safety for your pets.

1. Introduction

This manual provides instructions for the assembly, operation, maintenance, and care of your Lyromix XXL Dog Crate Furniture. This product is designed to serve as both a comfortable enclosure for your dog and a functional piece of furniture, such as an end table. Its modular design allows for various configurations to suit different needs and spaces.



Image: The Lyromix XXL Dog Crate Furniture, featuring a spacious interior and a wooden top surface, with a golden retriever comfortably seated inside.

2. Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in injury to your pet or damage to the product.

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep children and pets away during assembly.
- **Proper Sizing:** Ensure the crate size is appropriate for your dog. Your dog should be able to stand, turn around, and lie down comfortably inside. Refer to the "Choosing the Right Size" section.
- **Supervision:** Do not leave your pet unsupervised for extended periods, especially during initial use.
- **Not for Anxious Dogs:** This crate is designed for crate-trained, calm dogs. It is not intended for dogs with severe separation anxiety or destructive chewing habits, as they may damage the crate or injure themselves.
- **Regular Inspection:** Periodically check all bolts, screws, and latches to ensure they are secure. Tighten as necessary.

- **Placement:** Place the crate on a flat, stable surface. Avoid placing near heat sources or in direct sunlight for prolonged periods.
- **Weight Limit:** Do not exceed the recommended weight capacity for the top surface.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Wooden Top Panel
- Wooden Bottom Panel
- Metal Side Panels (x2)
- Metal Back Panel
- Metal Front Panel with Doors (x3)
- Connecting Rods/Bolts
- Screws and Allen Wrench
- Adjustable Feet (x4)

4. Assembly Instructions

Follow these steps carefully to assemble your dog crate furniture. It is recommended to have two adults for assembly.

1. **Prepare the Base:** Place the wooden bottom panel on a clean, flat surface. Attach the adjustable feet to the designated holes on the underside of the bottom panel.
2. **Attach Side Panels:** Connect the two metal side panels to the wooden bottom panel using the provided screws. Ensure the door openings face the desired direction.
3. **Install Back Panel:** Secure the metal back panel to the side panels and bottom panel using screws.
4. **Attach Front Panel:** Attach the metal front panel, which includes the three doors, to the side panels and bottom panel. Ensure the door latches are functional.
5. **Secure Top Panel:** Place the wooden top panel onto the assembled frame. Align the holes and secure it with the remaining screws.
6. **Final Check:** Ensure all screws are tightened and the crate is stable. Adjust the feet to level the crate if necessary.

Multifunctional Dog Crate Furniture

Blend comfort and style in every corner



Image: An illustration demonstrating the step-by-step assembly of the Lyromix dog crate, highlighting the connection points for panels and the top surface.

5. Operating Instructions

5.1 Using the Doors

The Lyromix dog crate features three doors for convenient access. Each door is equipped with a secure latch mechanism. To open, slide the latch and pull the door outwards. To close, push the door shut and ensure the latch is fully engaged.



Image: A visual representation of the dog crate's three-door design, illustrating how each door can be opened for easy pet access.

5.2 Combination Options

This modular dog crate can be combined with other Lyromix units to create larger or multi-level enclosures. The middle partition can be removed after connecting units for an expanded space.

- **Large TV Dog Crate:** Combine two units side-by-side to create a wider enclosure suitable for larger dogs or multiple pets.
- **Stackable Dog Crates:** Stack units vertically to save floor space, creating a double-decker setup. Ensure proper securing mechanisms are used (not included, refer to combination kit instructions if applicable).
- **L-shaped Corner Crate:** Arrange units to form an L-shape, optimizing corner spaces in your home.

Switch Between Various Combinations As You Like



Single Dog Crate

Two dog cages for separate use



Large TV Dog Crates

Combination dog crate suitable for large dogs



Stackable Dog Crates

Space saving, suitable for multiple dogs



L-shaped Corner Dog Crates

No more worrying about corner space

Image: Illustrations depicting different ways to combine multiple Lyromix dog crates, including side-by-side, stacked, and L-shaped configurations.

5.3 Using as Furniture

The sturdy wooden top surface allows the crate to function as an end table or side table. You can place decorative items, lamps, or other household objects on top. The surface is designed to be waterproof for easy cleaning.

Spacious Desktop

All-metal structure is more sturdy



Spacious



Chewy



Flexible



Image: The dog crate functioning as a side table, adorned with books, a plant, and other decorative items, demonstrating its dual purpose.

6. Maintenance and Care

6.1 Cleaning

- **Wooden Surfaces:** Wipe with a damp cloth and mild detergent. Dry immediately to prevent water damage. The surface is waterproof, but prolonged exposure to liquids should be avoided.
- **Metal Bars:** Clean with a damp cloth. For stubborn stains, use a non-abrasive cleaner.
- Avoid harsh chemicals or abrasive cleaning tools that could damage the finish.

6.2 General Care

- Regularly check all connections and tighten screws as needed to maintain stability.
- Inspect the crate for any signs of wear or damage. Replace damaged parts immediately to ensure pet safety.

- Adjust the leveling feet periodically to ensure the crate remains stable on uneven floors.



Image: Detailed views highlighting the waterproof nature of the top surface, the secure safety door lock mechanism, and the adjustable feet for stability.

7. Troubleshooting

Problem	Possible Cause	Solution
Crate is wobbly or unstable.	Loose screws; uneven floor.	Tighten all assembly screws. Adjust the leveling feet on the bottom of the crate.

Problem	Possible Cause	Solution
Doors do not close or latch properly.	Misalignment; obstruction; damaged latch.	Check for any obstructions. Ensure the crate is level. Inspect the latch mechanism for damage; contact support if damaged.
Dog attempts to chew or escape.	Crate anxiety; improper training; crate too small.	Ensure the crate is the correct size for your dog. Consult a professional dog trainer for anxiety or escape behaviors. This crate is not suitable for dogs with severe destructive tendencies.

8. Specifications

Model Name: Lyromix Combination Dog Crate

ASIN: B0D7CKW7VX

Material: Engineered Wood, Metal

Color: Brown (for this specific model)

Item Weight: 87.8 pounds

Special Feature: Lockable doors, Multifunctional design

Target Audience: Dogs (All Life Stages)

Specific Uses: Indoor

8.1 Dimensions

Measurement	Value
Overall Product Dimensions (L x W x H)	47.24" x 29.13" x 37.6"
Internal Dimensions (W x D x H)	45.51" x 27.64" x 36.02"
Item Package Dimensions (L x W x H)	51" x 32" x 6"

8.2 Choosing the Right Size

To ensure your dog's comfort, measure your dog's length and height. Add 4 inches to both measurements to determine the minimum required crate dimensions. If your dog prefers to sprawl, measure them in that position.



Image: An infographic illustrating how to measure a dog's length and height to select the appropriate crate size, with a golden retriever demonstrating the measurements.

Brand Size	Item Length (in)	Item Width (in)	Item Height (in)
L (38.8"×25.2"×27.2")	38.8	25.2	27.1
XL (43.3"×29.9"×33.1")	43.3	29.9	33
XXL (47.2"×29.1"×37.6")	47.2	29.1	37.6

9. Warranty and Support

Warranty: This Lyromix product comes with a 1-year warranty from the date of purchase, covering manufacturing defects.

Customer Support: For assistance with assembly, missing parts, or any product-related inquiries, please contact Lyromix customer support through the retailer where the product was purchased or visit the official Lyromix store on Amazon: [Lyromix Amazon Store](#).

Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D7CKW7VX>

More documents and user manuals: <https://manuals.plus/>