KSADBOSSBO Bundle 1080p 128G BodyCam + 1080p 64G BodyCam

KSADBOSSBO Body Camera User Manual

Model: Bundle 1080p 128G BodyCam + 1080p 64G BodyCam

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your KSADBOSSBO Body Camera Bundle. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize its performance.



Image: The KSADBOSSBO Body Camera Bundle, showcasing both the 128GB and 64GB models along with their included accessories.

Setup

Included Components

Verify that all components are present in the package:

- KSADBOSSBO 1080p 128G BodyCam
- KSADBOSSBO 1080p 64G BodyCam
- Mini magnetic lanyard
- USB cables
- USB adapters
- Cycling mount
- Tripod mount

Charging the Device

Before first use, fully charge the body camera. Connect the camera to a power source using the provided USB cable. The charging indicator will show the charging status. A full charge provides approximately 6 hours of continuous recording.

Inserting the Memory Card

The cameras come with integrated memory (128GB and 64GB respectively). No additional memory card insertion is required. Ensure the camera has sufficient storage before recording.

Attaching the Magnetic Lanyard and Mounts

The magnetic lanyard allows for convenient and secure attachment of the camera to clothing or other magnetic surfaces. The bundle also includes a cycling mount for outdoor recording.



Image: Demonstrates the magnetic lanyard for easy camera carrying and the cycling mount for outdoor sports recording.

Operating Instructions

Basic Operation

To power on the camera, press and hold the power button. The 1.4-inch LCD screen will activate. To begin recording, use the one-key start recording feature. This ensures immediate recording without accidental button presses.



Image: Illustrates the one-key start recording function and the magnetic attachment method for discreet recording.

Screen and Menu Navigation

The 1.4-inch high-quality LED screen allows for instant replay and deletion of footage. Navigate through the detailed menu using the control buttons to adjust settings such as inverted screen mode, power display, loop recording duration (up to 10 minutes), and time stamp settings.

Recording Modes and Features

- **1080P HD Recording:** Captures clear and accurate video footage at 1080p resolution with a 12 million-pixel sensor.
- **180° Rotatable / 120° Lens:** Adjust the lens direction to ensure the correct recording angle and capture important evidence.

- **Motion Detection:** Activates recording only when motion is detected, conserving battery life and memory space.
- **Night Vision & Flashlight Mode:** Equipped with 4 fill lights for colorful night recording. Note: This model does not use an IR lens for night vision.
- **No LED Recording Mode:** Allows for discreet recording by automatically hiding the LED indicator.
- **Mirror Mode:** Provides an option for inverting the right and left sides of the video.



Image: Details the 180° rotating lens, 120° angle, motion detection, and high-quality auto night vision capabilities of the camera.

Connectivity and Data Transfer

The camera supports a Hotspot mode, enabling you to download recordings directly to your phone from the camera within a limited range (up to 32 feet). Connect the camera to a computer via USB for direct file transfer.



Image: Demonstrates the Hotspot mode for connecting the body camera to a smartphone to conveniently record and replay footage.



Image: Shows the 1.4-inch screen's capability for video playback, supporting loop recording and mirror image adjustments.

Maintenance

Cleaning

Use a soft, dry cloth to clean the camera body and lens. Avoid using liquid cleaners or abrasive materials, as they may damage the device.

Storage

Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before long-term storage to maintain battery health.

Battery Care

The camera is equipped with a 1300 mAh rechargeable battery. For optimal battery life, avoid fully discharging the battery frequently. The camera supports 24/7 recording when connected to a power bank or external power source.

Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Low battery; device malfunction.	Charge the camera fully. If the issue persists, perform a quick reset.
Recording stops unexpectedly.	Low battery; insufficient storage; loop recording limit reached.	Ensure battery is charged. Check available storage. Loop recording will overwrite oldest files when full.
Cannot connect to phone via Hotspot.	Out of range; incorrect Wi-Fi settings.	Ensure phone is within 32ft of the camera. Verify Wi-Fi settings and password.
Video quality is poor.	Dirty lens; low light conditions; incorrect settings.	Clean the lens. Ensure adequate lighting or use flashlight mode. Check video resolution settings.

If problems persist, please contact customer support.

Specifications

Model Name: Bundle 1080p 128G BodyCam + 1080p 64G BodyCam

Brand: KSADBOSSBO

Video Capture Resolution: 1080p

Video Capture Format: MP4 (H.264 encoding)

Supported Audio Format: AAC

Photo Sensor Technology: CCD

Maximum Aperture: 2.8 Millimeters

Screen Size: 1.4 Inches

Battery Capacity: 1300 mAh

Battery Life: Approximately 6 hours (continuous recording)

Lens Rotation: 180°

Lens Angle: 120°

Connectivity: USB, Wi-Fi Hotspot (up to 32ft)

Storage: 128GB (one camera), 64GB (one camera)

Features: Loop Recording, Time Stamp, Motion Detection, No LED Recording, Mirror Mode, Flashlight Mode (4 fill lights)



Image: Highlights key specifications including the 180° rotating lens, 1080P Full HD resolution, battery capacity, and various recording features.

Warranty Information

Specific warranty details for KSADBOSSBO products are typically provided with your purchase documentation or can be found on the official KSADBOSSBO website. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please visit the official KSADBOSSBO store on Amazon or contact their customer service directly. Refer to your product packaging or the Amazon product page for the most current contact information.

KSADBOSSBO Store: Visit the KSADBOSSBO Store on Amazon

© 2024 KSADBOSSBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question