



Manuals.plus /

› **wonlex** /

› wonlex 4G Kids Smart Watch User Manual - Model B0D7CMM391

wonlex B0D7CMM391

wonlex 4G Kids Smart Watch User Manual

Model: B0D7CMM391

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your wonlex 4G Kids Smart Watch. Please read this guide thoroughly to ensure proper use and to maximize the features of your device.

The wonlex 4G Kids Smart Watch is designed to offer communication and safety features for children, including GPS tracking, video calling, and an SOS emergency function.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Kids Smart Watch x1
- Speedtalk SIM Card x1
- Charging Cable x2
- Tempered Glass Screen Protector x1
- Alcohol Pad x1
- User Manual x1

SmartWatch SIM by speedtalk GSM mobile



ACTIVATE: You can activate it with a new number, the plan cycle will start from the time you first activate the SIM.



SpeedTalk Mobile utilizes T-Mobile network for its coverage and it's compatible with Wonlex 4G LTE smartwatches. If you use your own SIM card, T-Mobile network is the only one recommended.



REFILL: To avoid any service interruption, you can REFILL your SIM Card Account before your current plan expires. To Refill visit our website: Refill.SpeedTalkMobile.com

To start your new service, have your SIM card ready visit Activate.SpeedTalkMobile.com

IMPORTANT: After SIM activation, it might take up to 24 hours for GPRS and data settings to sync with your device (e.g., Smart watch, GPS tracking device). Ensure the device is turned ON and placed in a good reception area.

In certain cases, you need to configure the watch's APN for GPRS network access. Send this command to your watch by

SMS from your phone:
pw,123456,apn,mobilenet,,310260#
APN name MCC MNC

Note: Do not install your SIM card until Activation is done.

Figure 2.1: Package Contents

3. SETUP

3.1 SIM Card Installation

1. Locate the SIM card slot on the left side of the smartwatch.
2. Insert the Nano SIM card into the slot. Ensure the SIM card is correctly oriented as shown in the diagram.
3. If you are concerned about the SIM card being removed, an additional SIM card slot is provided for secure installation.

Note: Only Nano SIM cards are compatible. Standard, cut, or Micro SIM cards will not work.

SIM Card Installation



Figure 3.1: SIM Card Installation

3.2 SIM Card Activation

The package includes a Speedtalk SIM card. If you choose to use it, follow the activation instructions provided with the card. If you prefer an alternative, a T-Mobile 4G SIM card is recommended. Verizon is not compatible.

Important: After SIM activation, it may take up to 24 hours for GPRS and data settings to sync with your device. Ensure the watch is turned ON and placed in a good reception area. Do not install the SIM card until activation is complete.

Your browser does not support the video tag.

Video 3.1: How to insert a SIM card and exchange a wallpaper (Seller: Wonlex)

3.3 App Download and Pairing

Download the dedicated app for the wonlex Smart Watch on your smartphone. Follow the in-app instructions to pair your device and configure settings.

Your browser does not support the video tag.

Video 3.2: Product overview and features (Seller: Wonlex)

3.4 Charging the Watch

Connect the charging cable to the watch and a power source. The 680mAh battery typically charges fully in two hours, providing up to 72 hours of standby time.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The watch features a 1.4-inch OGS color touch screen. Swipe left/right or up/down to navigate through the menus and select applications.

4.2 Communication Features

- **Video Calling:** Initiate video calls with approved contacts directly from the watch.
- **Voice Chat:** Send and receive voice messages with family members or friends.
- **SMS:** Send and receive text messages.
- **Family Group Chat:** Participate in group chats with pre-approved family contacts.



Figure 4.1: Video Calling on the Smart Watch



Figure 4.2: Voice Chat Functionality

4.3 SOS Emergency Function

In case of an emergency, press and hold the SOS button for more than 3 seconds. The watch will automatically call pre-set family numbers and send emergency messages to guardians.

SOS Calling

One-click to ask for help by pressing the SOS button for more than 3 seconds, then the watch will call family numbers presented in the APP and send messages to the guardians.



Figure 4.3: SOS Emergency Calling

4.4 GPS Tracking and Safety Zones

The watch features a built-in Wi-Fi GPS LBS locator for accurate positioning. Parents can monitor the child's real-time location and view historical routes through the companion app. Safety zones can be set up around key locations like home and school. Notifications will be sent to the parent's app if the child leaves a designated safety zone.

Real-time GPS Tracker



Figure 4.4: Real-time GPS Tracking

Your browser does not support the video tag.

Video 4.1: GPS tracker and SOS safety alerts (Seller: SecuLife Inc.)

4.5 Camera Functionality

The watch includes a camera for taking photos and recording videos, allowing children to capture moments directly from their wrist.

Happy with Camera

Support to take photos, record videos, record beautiful moments



Video call



Camera



Remote Camera

Figure 4.5: Happy with Camera

4.6 Games and Educational Features

The watch comes with 7 pre-installed puzzle games designed to enhance reaction ability, logical thinking, and hand-eye coordination.

Puzzle Games




Logical thinking ability



Reaction ability



Hand-eye coordination ability



Training the reaction ability and get fun



Figure 4.6: Puzzle Games

4.7 Additional Tools

The watch includes various useful tools:

- **Clock & Alarms:** Set alarms and manage time.
- **Steps Counter (Pedometer):** Track daily steps and activity levels.
- **Stop Watch:** For timing activities.
- **Voice Recorder:** Record voice notes.
- **Calculator:** Basic arithmetic functions.

Camera

Children can easily capture beautiful pictures and record wonderful moments with the watch camera function.



Figure 4.7: Additional Smart Watch Tools

5. MAINTENANCE

5.1 Water Resistance

The wonlex 4G Kids Smart Watch is IP67 waterproof. This means it is resistant to splashes and brief immersion in water. However, it is **not** recommended to wear the watch while swimming or showering. It is best to remove the watch when washing hands or engaging in other water-contact activities to prevent damage.

5.2 Cleaning

Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid using harsh chemicals or abrasive materials.

6. TROUBLESHOOTING

6.1 Connectivity Issues

- **No Signal/Network:** Ensure the SIM card is correctly installed and activated. Check for good network reception in your area. If using your own SIM, ensure it is a T-Mobile 4G compatible card (Verizon is not supported).
- **Data Not Syncing:** After SIM activation, allow up to 24 hours for GPRS and data settings to fully sync. Ensure the watch is powered on and in an area with good signal.

6.2 GPS Location Inaccuracy

The watch uses Wi-Fi, GPS, and LBS for location tracking. For optimal accuracy, ensure the watch has a clear view of the sky for GPS signals and is within Wi-Fi range when available. LBS (Location Based Service) provides approximate location when GPS/Wi-Fi signals are weak.

7. SPECIFICATIONS

Feature	Specification
Model	B0D7CMM391
Display	1.4-inch OGS Color Touch Screen
Battery Capacity	680mAh
Standby Time	Up to 72 hours
Charging Time	Approx. 2 hours
Connectivity	4G
Location Technology	Wi-Fi, GPS, LBS
Water Resistance	IP67

8. WARRANTY AND SUPPORT

All smartwatches purchased from our official authorized store enjoy a one-year after-sales service. For any issues or support, please refer to the contact information provided in your package or visit the official wonlex website.